RG255C Series&RM255C-GL
AT Commands Manual

5G Module Series

Version: 1.0

Date: 2024-12-31

Status: Released

At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

Quectel Wireless Solutions Co., Ltd.
Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China
Tel: +86 21 5108 6236
Email: info@quectel.com

Or our local offices. For more information, please visit:
http://www.quectel.com/support/sales.htm.

For technical support, or to report documentation errors, please visit:
http://www.quectel.com/support/technical.htm.
Or email us at: support@quectel.com.

Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

Use and Disclosure Restrictions

License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

Disclaimer

a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

Copyright © Quectel Wireless Solutions Co., Ltd. 2024. All rights reserved.

About the Document

Revision History

Version	Date	Author	Description
-	2023-08-07	Sherlock ZHAO	Creation of the document
1.0	2024-12-31	Sherlock ZHAO/ Spawn ZHANG/ Demon YANG/ Matt YE	First official release

Contents

About the Document **3**
Contents **4**
Table Index **9**

1 Introduction **10**
1.1 Scope of the Document 10
1.2 Definitions 10
1.3 AT Command Syntax 10
1.3.1. Basic Syntax 11
1.3.2. S Parameter Syntax 11
1.3.3. Extended Syntax 11
1.3.4. Entering AT Commands 11
1.4 AT Command Responses 12
1.5 Supported Character Sets 12
1.6 AT Command Interface 13
1.7 URC (Unsolicited Result Code) 13
1.8 Module Turn-off Procedure 13
1.9 Declaration of AT Command Examples 13

2 General Commands **15**
2.1 ATI Request MT Identification Information 15
2.2 AT+GMI Request Manufacturer Identification 16
2.3 AT+GMM Request MT Model Identification 16
2.4 AT+GMR Request MT Firmware Version Identification 17
2.5 AT+CGMI Request Manufacturer Identification 17
2.6 AT+CGMM Request MT Model Identification 18
2.7 AT+CGMR Request MT Firmware Version Identification 18
2.8 AT&F Reset AT Command Settings to Factory Settings 19
2.9 AT&V Display Current AT Command Settings 19
2.10 ATZ Restore All AT Command Settings from User-defined Profile 21
2.11 ATQ Set Result Code Presentation Mode 21
2.12 ATV MT Response Format 22
2.13 AT&W Store Current AT Command Settings to User-defined Profile 23
2.14 ATE Set Command Echo Mode 24
2.15 A/ Repeat Previous Command Line 25
2.16 ATS3 Set Command Line Termination Character 25
2.17 ATS4 Set Response Formatting Character 26
2.18 ATS5 Set Command Line Editing Character 26
2.19 ATX Set CONNECT Result Code Format and Monitor Call Progress 27
2.20 AT+CFUN Set UE Functionality 28
2.21 AT+CMEE Error Message Format 29
2.22 AT+CSCS Select TE Character Set 30

2.23 AT+QURCCFG Configure URC Output Port 32

3 Status Control Commands 34
3.1 AT+CPAS ME Activity Status 34
3.2 AT+QCFG Extended Configuration Settings 35
3.2.1. AT+QCFG="pdp/duplicatechk" Establish Multi PDNs With a Single APN 36
3.2.2. AT+QCFG="risignaltype" RI Signal Output Carrier 37
3.2.3. AT+QCFG="data_interface" Set Network Port/Diagnostic Port Communication via PCIe/USB Interface 38
3.2.4. AT+QCFG="pcie/mode" Set PCIe RC/EP Mode 39
3.2.5. AT+QCFG="usbnet" Configure NIC Data Call Method 40
3.2.6. AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS 41
3.2.7. AT+QCFG="call_control" Enable/Disable Voice Call Features 42
3.2.8. AT+QCFG="ResetFactory" Restore to Factory Settings 43
3.2.9. AT+QCFG="usbcfg" Configure USB Composite Features 44
3.2.10. AT+QCFG="ntp" Specify Re-transmission Count and Interval for NTP Client 45
3.3 AT+QPLATCFG Configure and Query Platform Function Settings 46
3.3.1. AT+QPLATCFG="board_type" Query/Set Board Type 47
3.3.2. AT+QPLATCFG="periph_cfg" Enable/Disable Peripheral 48

4 (U)SIM Related Commands 50
4.1 AT+CIMI Request IMSI 50
4.2 AT+ICCID Get ICCID 51
4.3 AT+CLCK Facility Lock 51
4.4 AT+CPIN Enter PIN 54
4.5 AT+CPWD Change Password 56
4.6 AT+CSIM Generic (U)SIM Access 57
4.7 AT+CRSM Restricted (U)SIM Access 58
4.8 AT+CCHO Open Logical Channel 60
4.9 AT+CCHC Close Logical Channel 61
4.10 AT+CGLA Generic UICC Logical Channel Access 62
4.11 AT+QPINC Remaining PIN/PUK Retries 63
4.12 AT+QSIMDET (U)SIM Card Detection 64
4.13 AT+QSIMSTAT (U)SIM Card Insertion Status Report 65
4.14 AT+QUIMSLOT Set Card Slot 67

5 Network Service Commands 69
5.1 AT+COPS Operator Selection 69
5.2 AT+CEREG EPS Network Registration Status 71
5.3 AT+C5GREG 5GS Network Registration Status 72
5.4 AT+C5GNSSAI 5GS NSSAI Setting 75
5.5 AT+C5GNSSAIRDP Read 5GS NSSAI Dynamic Parameters 76
5.6 AT+CGDCONT Define PDP Contexts 79
5.7 AT+QRSRP Report RSRP 82
5.8 AT+QRSRQ Report RSRQ 83
5.9 AT+QSINR Report SINR 84

5.10 AT+QRSSI Report RSSI 85
5.11 AT+CPOL Preferred Operator List 86
5.12 AT+CTZU Automatic Time Zone Update 87
5.13 AT+CTZR Time Zone Reporting 88
5.14 AT+QLTS Query Latest Time Synchronized Through Network 90
5.15 AT+QENG Query Primary Serving Cell and Neighbour Cell Information 92
5.16 AT+QNWCFG Configure and Query Network Parameters 96
5.16.1 AT+QNWCFG="lte_cell_id" Read Cell ID Under LTE 96
5.16.2 AT+QNWCFG="nr5g_cell_id" Read Cell ID Under NR5G SA 97
5.16.3 AT+QNWCFG="data_roaming " Control Data Roaming 98
5.16.4 AT+QNWCFG="hplmn_search_timer" Set Higher Priority PLMN Search Timer 98
5.16.5 AT+QNWCFG="lte_cdrx" Enable/Disable CDRX Function Under LTE 99
5.16.6 AT+QNWCFG="nr5g_cdrx" Enable/Disable CDRX Function Under 5G 100
5.17 AT+QNWPREFCFG Configure Network Searching Preferences 101
5.17.1 AT+QNWPREFCFG="lte_band" Set LTE Band 102
5.17.2 AT+QNWPREFCFG="nr5g_band" Set NR5G SA Band 103
5.17.3 AT+QNWPREFCFG="mode_pref" Set Network Search Mode 104
5.17.4 AT+QNWPREFCFG="ue_usage_setting" Set UE Usage Setting 105
5.17.5 AT+QNWPREFCFG="policy_band" Read Carrier Policy Band 106
5.17.6 AT+QNWPREFCFG="ue_capability_band" Query UE Band Capability 107
5.17.7 AT+QNWPREFCFG="policy_mode" Read Carrier Policy Mode 107

6 Call Related Commands 109
6.1 ATA Answer an Incoming Call 109
6.2 ATD Originate a Call 110
6.3 ATH Disconnect Existing Connection 112
6.4 AT+CVHU Control Voice Call Hang Up 112
6.5 AT+CHUP Hang Up Voice Call 113
6.6 ATS0 Set Ring Count Before Automatic Answering 113
6.7 ATS6 Set Pause Before Blind Dialing 114
6.8 ATS7 Set Waiting Time for Connection Completion 115
6.9 ATS8 Set Waiting Time for Comma Dial Modifier 116
6.10 ATS10 Set Disconnection Delay After Indicating Data Carrier Absence 116
6.11 AT+CSTA Select Type of Address 117
6.12 AT+CLCC List Current Call of MT 118
6.13 AT+CRC Set Extended Format of Incoming Call Indication 119
6.14 AT+QECCNUM Configure Emergency Call Number 120
6.15 AT^DSCI Indicate Call Status 124
6.16 AT+VTS Generate DTMF Tone 126
6.17 AT+VTD Set DTMF Tone Duration 127

7 Phonebook Commands 128
7.1 AT+CNUM Get Subscriber Number 128

8 Short Message Service Commands 129
8.1 AT+CSMS Select Message Service 129

8.2 AT+CMGF Set Message Format 130
8.3 AT+CSCA Set Service Center Address 131
8.4 AT+CPMS Select Message Memory Storage 132
8.5 AT+CMGD Delete Message 134
8.6 AT+CMGL Read Message by Status 135
8.7 AT+CMGR Read Message By Index 139
8.8 AT+CMGS Send Message 143
8.9 AT+CMMS Send Multiple Messages 144
8.10 AT+CMGW Write Message to Memory Storage 145
8.11 AT+CMSS Send Messages from Memory Storage 147
8.12 AT+CNMA New Message Acknowledgement 149
8.13 AT+CNMI Set New Message Indication 151
8.14 AT+CSCB Select Cell Broadcast Message Type 153
8.15 AT+CSDH Show Text Mode Parameter 154
8.16 AT+CSMP Set Text Mode Parameter 155

9 Packet Domain Commands 157
9.1 AT+CGATT Attach to or Detach from PS 157
9.2 AT+CGACT Activate or Deactivate PDP Context 158
9.3 AT+CGPADDR Show PDP Address 160
9.4 AT+CGEREP Report Packet Domain Event 161

10 Supplementary Service Commands 164
10.1 AT+CCFC Call Forwarding Number and Conditions Control 164
10.2 AT+CCWA Call Waiting Control 166
10.3 AT+CHLD Call-Related Supplementary Services 169
10.4 AT+CLIP Present Calling Line Identification 171
10.5 AT+CLIR Restrict Calling Line Identification 172
10.6 AT+COLP Present Connected Line Identification 173
10.7 AT+CSSN Supplementary Service Notification 175
10.8 AT+CUSD Unstructured Supplementary Service Data 176

11 Hardware-Related Commands 178
11.1 AT+QPOWD Power off 178
11.2 AT+QADC Read ADC Value 179
11.3 AT+CBC Battery Charge 179
11.4 AT+QSCLK Set Sleep Mode 180

12 QMAP-Related Commands 182
12.1 AT+QMAP Configure QMAP-Related Parameters 182
12.2 AT+QMAP="WWAN" Query IP Address of Default QMAP Data Call 183
12.3 AT+QMAP="DMZ" Query/Set DMZ of Default QMAP Data Call 184
12.4 AT+QMAP="LANIP" Query/Modify DHCP Address Pool of Default LAN Interface 185
12.5 AT+QMAP="VLAN" Query/Set VLAN 186
12.6 AT+QMAP="MPDN_rule" Query/Modify QMAP Multiple Data Call Rule 188
12.7 AT+QMAP="IPPT_NAT" Query/Set IPPT NAT Working Mode of QMAP Data Call 192

12.8 AT+QMAP="connect" Initiate/Terminate QMAP Data Call 193
12.9 AT+QMAP="auto_connect" Query/Modify Automatic Connection of QMAP Data Call 194
12.10 AT+QMAP="MPDN_status" Query QMAP Multiple Data Call Status 196
12.11 AT+QMAP="NAT_timeout" Set NAT Timeout 197

13 Appendix References 199
13.1 Terms and Abbreviations 199
13.2 Factory Default Settings Restorable with AT&F 205
13.3 AT Command Settings Storable with AT&W 207
13.4 AT Command Settings Storable with ATZ 207
13.5 Summary of CME ERROR Codes 208
13.6 Summary of CMS ERROR Codes 210
13.7 Summary of URCs 212
13.8 SMS Character Sets Conversions 214

Table Index

Table 1: Type of AT Commands 11
Table 2: Verbose and Numeric Result Codes of ATV0&ATV1 23
Table 3: Terms and Abbreviations 199
Table 4: Factory Default Settings Restorable with AT&F 205
Table 5: AT Command Settings Storable with AT&W 207
Table 6: AT Command Settings Storable with ATZ 207
Table 7: Different Coding Schemes of +CME ERROR: <err> 208
Table 8: Different Coding Schemes of +CMS ERROR: <err> 210
Table 9: Summary of URCs 212
Table 10: SMS Text Input or Output Methods 214
Table 11: Input Conversions Table (DCS=GSM 7-bit and AT+CSCS="GSM") 215
Table 12: Output Conversions Table (DCS=GSM 7-bit and AT+CSCS="GSM") 215
Table 13: GSM Extended Characters (GSM Encode) 216
Table 14: Input Conversions Table (DCS = GSM 7-bit and AT+CSCS="IRA") 217
Table 15: IRA Extended Characters 218
Table 16: Output Conversions Table (DCS = GSM 7-bit and AT+CSCS="IRA") 218
Table 17: GSM Extended Characters (ISO-8859-1/Unicode) 219

1 Introduction

1.1 Scope of the Document

This document presents the AT command set supported by Quectel 5G RG255C series and RM255C-GL modules.

NOTE

1. Please refer to the software Release Note released together with the firmware before using the module with this document.
2. For conciseness purposes, RG255C series and RM255C-GL modules will hereinafter be referred to collectively as "the module/modules" in parts hereof applicable to both modules, and individually as "RG255C series " and "RM255C-GL" in parts hereof referring to the differences between them.

1.2 Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on the command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

1.3 AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately

omitted.

AT commands implemented by the module can be separated into three categories syntactically: “Basic”, “S Parameter” and “Extended”, as listed below:

1.3.1. Basic Syntax

Basic command format is **AT<x><n>**, or **AT&<x><n>**, where **<x>** is the command, and **<n>** is/are the argument(s) of the command. For example, **ATE<n>** tells the DCE (Data Circuit-terminating Equipment) whether received characters should be echoed back to the DTE (Data Terminal Equipment) according to the value of **<n>**. **<n>** is optional and a default will be used if it is omitted.

1.3.2. S Parameter Syntax

S Parameter command format is **ATS<n>=<m>**, where **<n>** is the index of the **S** register to be set, and **<m>** is the value to be assigned to it.

1.3.3. Extended Syntax

There are several types of extended commands as shown in the following table.

Table 1: Type of AT Commands

Command Type	Syntax	Description
Test Command	**AT+<cmd>=?**	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	**AT+<cmd>?**	Check the current parameter value of the corresponding command.
Write Command	**AT+<cmd>=<p1>[,<p2>[,<p3>[...]]]**	Set user-definable parameter value.
Execution Command	**AT+<cmd>**	Return a specific information parameter or perform a specific action.

1.3.4. Entering AT Commands

Multiple commands can be placed on a single line using a semi-colon (**;**) between commands. In such cases, only the first command should have **AT** prefix. Commands can be in upper or lower case.

Spaces should be ignored when you enter AT commands, except in the following cases:

- Within quoted strings, where they are preserved;
- Within an unquoted string or numeric parameter;
- Within an IP address;
- Within the AT command name up to and including a **=**, **?** or **=?**.

On input, at least a carriage return is required. A newline character is ignored so it is permissible to use carriage return/line feed pairs on the input.

If no command is entered after the **AT** token, **OK** will be returned. If an invalid command is entered, **ERROR** will be returned.

Optional parameters, unless explicitly stated, need to be provided up to the last entered parameter.

1.4 AT Command Responses

When the AT command processor has finished processing a line, it will output **OK**, **ERROR**, **+CME ERROR: <err>** or **+CMS ERROR: <err>** to indicate that it is ready to accept a new command. Solicited information responses are sent before the final **OK**, **ERROR** or **+CME ERROR: <err>** or **+CMS ERROR: <err>**.

Responses will be in the format of:

<CR><LF>+CMD1:<parameters><CR><LF>
<CR><LF>OK<CR><LF>

Or

<CR><LF><parameters><CR><LF>
<CR><LF>OK<CR><LF>

1.5 Supported Character Sets

The AT command interface of the module defaults to the GSM character set. The module supports the following character sets:

- GSM format
- UCS2
- IRA

The character set can be configured and queried via **AT+CSCS** (*3GPP TS 27.007*) and it is defined in

3GPP TS 27.005. The character set affects transmission and reception of SMS and SMS Cell Broadcast Messages, as well as the entry and display of phone book entries text field.

1.6 AT Command Interface

The AT command interface of the module includes the main UART port and the USB port, all of which support AT command communication and data transfer. The main UART port is only supported on RG2555C series standard modules.

1.7 URC (Unsolicited Result Code)

Unsolicited Result Code (URC) is a report message that is not issued in response to an executed AT command. URC is automatically issued by the modules in response to a certain event. Typical URC triggering events include incoming calls (**RING**), short message reception, high/low voltage alarm, high/low temperature alarm.

A summary of all URCs can be found in ***Chapter 13.7***.

1.8 Module Turn-off Procedure

The safest and best way to turn off the module is to execute **AT+QPOWD**. This procedure is performed by letting the module log off from the network and allowing the software to enter a secure and safe data state before disconnecting the power supply.

After sending **AT+QPOWD**, do not enter any other AT commands. When the command is executed successfully, the module will output **POWERED DOWN** and then enter the power down mode. To avoid data loss, it is suggested to wait for 1 s to disconnect the power supply after the URC **POWERED DOWN** is outputted. If **POWERED DOWN** is not received within 65 s, the power supply will be disconnected automatically.

1.9 Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean

that there is a correlation among these examples, or that they should be executed in a given sequence. The URLs, domain names, IP addresses, usernames/accounts, and passwords (if any) in the AT command examples are provided for illustrative and explanatory purposes only, and they should be modified to reflect your actual usage and specific needs.

2 General Commands

2.1 ATI Request MT Identification Information

This command returns MT identification information including the model information and the firmware revision..

ATI Request MT Identification Information	
Execution Command **ATI**	Response **Quectel** **<objectID>** **Revision: <revision>** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<objectID>	String type. Model information.
<revision>	String type. Firmware revision.

Example

```
ATI
Quectel
RG255C-GL
Revision: RG255CGLABR01A04M4G

OK
```

2.2 AT+GMI Request Manufacturer Identification

This command returns the manufacturer identification. It is identical with **AT+CGMI** in ***Chapter 2.5***.

AT+GMI Request Manufacturer Identification	
Test Command **AT+GMI=?**	Response **OK**
Execution Command **AT+GMI**	Response **Quectel** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

2.3 AT+GMM Request MT Model Identification

This command returns MT model identification. It is identical with **AT+CGMM** in ***Chapter 2.6***.

AT+GMM Request MT Model Identification	
Test Command **AT+GMM=?**	Response **OK**
Execution Command **AT+GMM**	Response **<objectID>** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<objectID>	String type. Model information.

2.4 AT+GMR Request MT Firmware Version Identification

This command returns MT firmware version identification. It is identical with **AT+CGMR** in ***Chapter 2.7***.

AT+GMR Request MT Firmware Version Identification	
Test Command **AT+GMR=?**	Response **OK**
Execution Command **AT+GMR**	Response **<revision>** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<revision>	String type. Identification of MT firmware version, including line terminators, which should not exceed 2048 characters.

Example

```
AT+GMR
RG255CGLABR01A04M4G

OK
```

2.5 AT+CGMI Request Manufacturer Identification

This command returns the manufacturer identification. It is identical with **AT+GMI** in ***Chapter 2.2***.

AT+CGMI Request Manufacturer Identification	
Test Command **AT+CGMI=?**	Response **OK**
Execution Command **AT+CGMI**	Response **Quectel** **OK**

Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

2.6 AT+CGMM Request MT Model Identification

This command returns MT model information. It is identical with **AT+GMM** in ***Chapter 2.3***.

AT+CGMM Request MT Model Identification	
Test Command **AT+CGMM=?**	Response **OK**
Execution Command **AT+CGMM**	Response **<objectID>** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<objectID>	String type. Model information.

2.7 AT+CGMR Request MT Firmware Version Identification

This command returns MT firmware version. It is identical with **AT+GMR** in ***Chapter 2.4***.

AT+CGMR Request MT Firmware Revision Identification	
Test Command **AT+CGMR=?**	Response **OK**
Execution Command **AT+CGMR**	Response **<revision>** **OK**
Maximum Response Time	300 ms

Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<revision>	String type. Identification of MT firmware version, including line terminators, which should not exceed 2048 characters.

2.8 AT&F Reset AT Command Settings to Factory Settings

This command resets AT command settings to factory settings specified by the manufacturer. See ***Chapter 13.2*** for the factory settings restorable with **AT&F**.

AT&F Reset AT Command Settings to Factory Settings	
Execution Command **AT&F[<value>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<value>	Integer type. 0 Reset all AT command settings to factory settings.

NOTE

Executing **AT&F** writes data to NVM (Non-Volatile Memory). Please proceed with caution.

2.9 AT&V Display Current AT Command Settings

This command displays the current configuration of some AT command parameters, including the single-letter AT command parameters that are not otherwise readable. See the example below for the default command response before any change.

AT&V Display Current AT Command Settings	
Execution Command **AT&V**	Response **<settings>** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<settings>	String type without double quotes. List of current AT command parameter settings. Format: **<command1>: <value1>** **<command2>: <value2>** **…** **<command*x*>: <value*x*>**
<command*x*>	String type without double quotes. AT command name, ignoring the "**AT**" or "**at**" prefix and termination characters.
<value>	Integer type. Current parameter value of the AT command.

Example

```
AT&V
&C: 1
&D: 2
&F: 0
&W: 0
E: 1
Q: 0
V: 1
X: 4
Z: 0
S0: 0
S3: 13
S4: 10
S5: 8
S6: 2
S7: 0
S8: 2
S10: 15
```

OK

2.10 ATZ Restore All AT Command Settings from User-defined Profile

This command first resets the AT command settings to their manufacturer defaults, which is similar to **AT&F**. Afterwards the AT command settings are restored from the user-defined profile in the non-volatile memory, if they have been stored with **AT&W** before. See ***Chapter 13.4*** for the factory settings restorable with **ATZ**.

Any additional AT command on the same command line may be ignored.

ATZ Restore All AT Command Settings From User-defined Profile	
Execution Command **ATZ[<value>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<value>	Integer type. 0 User profile number

2.11 ATQ Set Result Code Presentation Mode

This command controls whether the result code is transmitted to TE. Other information text transmitted as response is not affected.

ATQ Set Result Code Presentation Mode	
Execution Command **ATQ<n>**	Response If **<n>**=0: **OK** If **<n>**=1: (none)
Maximum Response Time	300 ms

Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Whether the result code is transmitted to TE.	
	0	Result code is transmitted
	1	Result code is suppressed and not transmitted

2.12 ATV MT Response Format

This command determines the contents of the header and trailer transmitted with result codes and information responses. It also determines whether result codes are transmitted in a numeric form or an alphabetic (or "verbose") form. The text portion of information responses is not affected by this command.

The verbose and numeric format results codes and their brief descriptions are provided in ***Table 2***.

ATV MT Response Format	
Execution Command **ATV<value>**	Response When **<value>**=0 **0** When **<value>**=1 **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<value>	Integer type.	
	0	Information response: **<text><CR><LF>** Result code in numeric format: **<numeric code><CR>**
	1	Information response: **<CR><LF><text><CR><LF>** Result code in verbose format: **<CR><LF><verbose code><CR><LF>**

Example

```
ATV1                                    //Set <value>=1.
OK
AT+QCSQ
+QCSQ: "LTE",-34,-83,1,-3

OK                                      //When <value>=1, the result code is OK.
ATV0                                    //Set <value>=0.
0
AT+QCSQ
+QCSQ: "LTE",-76,-140,-14,-20
0                                       //When <value>=0, the result code is 0.
```

Table 2: Verbose and Numeric Result Codes of ATV0&ATV1

ATV1	ATV0	Description
OK	0	Acknowledge of a command execution.
CONNECT	1	A connection has been established. DCE is switching from command mode to data mode.
RING	2	DCE has detected an incoming call signal from network.
NO CARRIER	3	A connection has been terminated or an attempt to establish a connection fails.
ERROR	4	Command not recognized due to exceeding command line maximum length, invalid parameter value, or other processing issues.
NO DIALTONE	6	No dial tone detected.
BUSY	7	Engaged (busy) signal detected.
NO ANSWER	8	@ (Wait for Quiet Answer) dialing modifier was used, but remote ringing followed by five seconds of silence was not detected before expiration of the connection timer (**ATS7**).

2.13 AT&W Store Current AT Command Settings to User-defined Profile

This command stores the current AT command settings to a user-defined profile in non-volatile memory. See ***Chapter 13.3*** for the factory settings restorable with **AT&W**. After this command is executed, the AT command settings are automatically restored from the user-defined profile during power-up or if **ATZ** is executed.

AT&W Store Current AT Command Settings to User-defined Profile	
Execution Command **AT&W[<n>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. 0 Profile number to store current AT command settings.

NOTE

Executing **AT&W[<n>]** writes data to NVM (Non-Volatile Memory). Please proceed with caution.

2.14 ATE Set Command Echo Mode

This command controls whether TA echoes characters received from TE in AT command mode.

ATE Set Command Echo Mode	
Execution Command **ATE<value>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<value>	Integer type. Whether to echo the characters received from TE. 0 Not Echo 1 Echo

2.15 A/ Repeat Previous Command Line

This command repeats the previous AT command line, and "**/**" acts as the line termination character.

A/ Repeat Previous Command Line	
Execution Command **A/**	Response Repeat the previous command
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Example

```
ATI                                    //Deliver the product identification information text.
Quectel
RG255-GL
Revision: RG255CGLABR01A04M4G

OK
A/                                     //Repeat the previous command.
Quectel
RG255C-GL
Revision: RG255CGLABR01A04M4G

OK
```

2.16 ATS3 Set Command Line Termination Character

This command determines the character that terminates an incoming command line, which is recognized by TA. It is also generated by the module for result codes and information text, along with character value set via **ATS4**.

ATS3 Set Command Line Termination Character	
Read Command **ATS3?**	Response **<n>** **OK**
Write Command **ATS3=<n>**	Response **OK**
Maximum Response Time	300 ms

Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Command line termination character. Range: 0–127. Default value: 13.

2.17 ATS4 Set Response Formatting Character

This command determines the character generated by TA for result code and information text, along with the command line termination character set via **ATS3**.

ATS4 Set Response Formatting Character	
Read Command **ATS4?**	Response **<n>** **OK**
Write Command **ATS4=<n>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Response formatting character. Range: 0–127. Default value: 10.

2.18 ATS5 Set Command Line Editing Character

This command determines the editing character used by TA to delete the immediately preceding character from the AT command line, i.e., the backspace key.

ATS5 Set Command Line Editing Character	
Read Command **ATS5?**	Response **<n>**

	OK
Write Command **ATS5=<n>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Command line editing character. Range: 0–127. Default value: 8.

2.19 ATX Set CONNECT Result Code Format and Monitor Call Progress

This command determines whether TA transmits particular result codes to TE. It also controls whether TA detects a dial tone when initiating a call and an engaged tone (i.e., busy signal).

ATX Set CONNECT Result Code Format and Monitor Call Progress	
Execution Command **ATX<value>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<value>	Integer type. 0 Only **CONNECT** is returned, with both dial tone and busy detection disabled. 1 Only **CONNECT<text>** is returned, with both dial tone and busy detection disabled. 2 **CONNECT<text>** is returned, with dial tone detection enabled, and busy detection disabled. 3 **CONNECT<text>** is returned, with dial tone detection disabled, and busy detection enabled. 4 **CONNECT<text>** is returned, with both dial tone and busy detection enabled.

2.20 AT+CFUN Set UE Functionality

This command controls the UE functionality level. It can also be used for resetting UE.

AT+CFUN Set UE Functionality	
Test Command **AT+CFUN=?**	Response **+CFUN: (**list of supported **<fun>**s**),(**list of supported **<rst>**s**)** **OK**
Read Command **AT+CFUN?**	Response **+CFUN: <fun>** **OK**
Write Command **AT+CFUN=<fun>[,<rst>]**	Response **OK** If there is any error: **+CME ERROR: <err>** Or **ERROR**
Maximum Response Time	15 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<fun>	Integer type. Functionality level. 0 Minimum functionality 1 Full functionality 4 Disable both transmitting and receiving RF signals
<rst>	Integer type. Whether to reset UE. 0 Do not reset the UE before setting it to **<fun>** power level. 1 Reset UE. The device is fully functional after the reset. This value is available only for **<fun>**=1.
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

When the module searches for or registers the network, it may write data to NVM if you execute **AT+CFUN=1**. Please proceed with caution.

Example

```
AT+CFUN=0                                  //Switch UE to minimum functionality.
OK
AT+COPS?                                   //Read command.
+COPS: 0                                   //No operator is registered.

OK
AT+CPIN?
+CME ERROR: 13                             //(U)SIM failure.
AT+CFUN=1                                  //Switch UE to full functionality.
OK

+CPIN: READY

+QUSIM: 1

+QIND: PB DONE

+QIND: SMS DONE
AT+CPIN?                                   //Read command.
+CPIN: READY

OK
AT+COPS?                                   //Read command.
+COPS: 0,0,"CHINA MOBILE CMCC",7           //Operator is registered.

OK
```

2.21 AT+CMEE Error Message Format

This command disables or enables the use of final result code **+CME ERROR: <err>** as an indication of an error relating to the functionality of the MT. When enabled, errors will trigger **+CME ERROR: <err>** instead of **ERROR**.

AT+CMEE Error Message Format	
Test Command **AT+CMEE=?**	Response **+CMEE: (**list of supported **<n>**s**)** **OK**
Read Command **AT+CMEE?**	Response **+CMEE: <n>**

	OK
Write Command **AT+CMEE=[<n>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Whether to enable **+CME ERROR: <err>**. 0 Disable **+CME ERROR: <err>** and use **ERROR** instead. 1 Enable **+CME ERROR: <err>** and use numeric **<err>** values. 2 Enable **+CME ERROR: <err>** and use verbose **<err>** values.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CMEE=0                          //Disable +CME ERROR: <err>.
OK
AT+CPIN?                           //Read command.
ERROR                              //Only ERROR is displayed.
AT+CMEE=1                          //Enable +CME ERROR: <err> with numeric values.
OK
AT+CPIN?                           //Read command.
+CME ERROR: 10
AT+CMEE=2                          //Enable +CME ERROR: <err> with verbose values.
OK
AT+CPIN?                           //Read command.
+CME ERROR: SIM not inserted
```

2.22 AT+CSCS Select TE Character Set

This command informs MT of the character set used by TE. This enables MT to convert character strings correctly between TE and MT character sets.

AT+CSCS Select TE Character Set	
Test Command **AT+CSCS=?**	Response **+CSCS: (**list of supported **<chset>**s**)**

	OK
Read Command **AT+CSCS?**	Response **+CSCS: <chset>** **OK**
Write Command **AT+CSCS=<chset>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<chset>	String type. Character set.	
	"GSM"	GSM default alphabet
	"IRA"	International reference alphabet
	"UCS2"	UCS2 alphabet

Example

```
AT+CSCS?                    //Query the current character set.
+CSCS: "GSM"                //The character set is GSM.

OK
AT+CSCS="UCS2"              //Set the character set to "UCS2".
OK
AT+CSCS?                    //Query the current character set.
+CSCS: "UCS2"               //The character set is UCS2 after the configuration.

OK
```

2.23 AT+QURCCFG Configure URC Output Port

This command configures URC output port.

AT+QURCCFG Configure URC Output Port	
Test Command **AT+QURCCFG=?**	Response **+QURCCFG: "urcport",(**list of supported **<URC_port_value>**s**)** **OK**
Write Command **AT+QURCCFG="urcport"[,<URC_port_value>]**	Response If the optional parameter is omitted, query the current setting. **+QURCCFG: "urcport",<URC_port_value>** **OK** If the optional parameter is specified, set URC output port. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<URC_port_value>	String type. URC output port.	
	"usbat"	USB AT port
	"uart1"	Main UART
	"all"	All ports

NOTE

Executing **AT+QURCCFG="urcport",<URC_port_value>** writes data to NVM (Non-Volatile Memory). Please proceed with caution.

Example

```
AT+QURCCFG=?                          //Test command.
+QURCCFG: "urcport",("usbat","uart1","all")

OK
```

```
AT+QURCCFG="urcport"                    //Query the current configuration of URC output port.
+QURCCFG: "urcport","usbat"

OK
AT+QURCCFG="urcport","uart1"            //Configure the URC output port to main UART port.
OK
AT+QURCCFG="urcport"
+QURCCFG: "urcport","uart1"

OK
```

3 Status Control Commands

3.1 AT+CPAS ME Activity Status

This command queries the activity status of ME.

AT+CPAS ME Activity Status	
Test Command **AT+CPAS=?**	Response **+CPAS: (**list of supported **<pas>**s**)** **OK**
Execution Command **AT+CPAS**	Response TA returns the activity status of ME: **+CPAS: <pas>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<pas>	Integer type. ME activity status. 0 Ready (MT allows commands from TA/TE) 3 Ringing (MT is ready for commands from TA/TE, but the ringer is active) 4 Call in progress or call on hold (MT is ready for commands from TA/TE, but a call is in progress or a call is on hold)
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CPAS                                  //Execution command.
+CPAS: 0                                 //ME is ready.

OK
RING
AT+CLCC                                  //Execution command.
+CLCC: 1,1,4,0,0,"15695519173",161

OK
AT+CPAS                                  //Execution command.
+CPAS: 3                                 //MT is ringing.

OK
AT+CLCC                                  //Execution command.
+CLCC: 1,0,0,0,0,"10010",129

OK
AT+CPAS                                  //Execution command.
+CPAS: 4                                 //Call in progress.

OK
```

3.2 AT+QCFG Extended Configuration Settings

This command queries and configures various settings of UE.

AT+QCFG Extended Configuration Settings	
Test Command **AT+QCFG=?**	Response **+QCFG: "pdp/duplicatechk",(**list of supported **<enable>**s**)** **+QCFG: "risignaltype",(**list of supported **<risignatype>**s**)** **+QCFG: "data_interface",(**list of supported **<network>**s**),(**list of supported **<diag>**s**)** **+QCFG: "pcie/mode",(**list of supported **<mode>**s**)** **+QCFG: "usbnet",(**list of supported **<net>**s**)** **+QCFG: "sms_control",(**list of supported **<submit>**s**),(**list of supported **<deliver>**s**)** **+QCFG: "call_control",(**list of supported **<disableMO>**s**),(**list of supported **<disableMT>**s**)** **…**

	OK
Maximum Response Time	300 ms

3.2.1. AT+QCFG="pdp/duplicatechk" Establish Multi PDNs With a Single APN

This command allows or refuses establishing multi PDNs with a single APN profile.

AT+QCFG="pdp/duplicatechk" Establish Multi PDNs With a Single APN	
Write Command **AT+QCFG="pdp/duplicatechk"[,<enable>]**	Response If the optional parameter is omitted, query the current setting. **+QCFG: "pdp/duplicatechk",<enable>** **OK** If the optional parameter is specified, allow or refuse establishing multiple PDNs with a single APN profile. **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type.	
	0	Refuse to establish multi PDNs with a single APN profile
	1	Allowed to establish multi PDNs with a single APN profile
<err>	Error codes. For more details, see ***Chapter 13.5***.	

NOTE

Executing **AT+QCFG="pdp/duplicatechk",<enable>** writes data to NVM. Please proceed with caution.

3.2.2. AT+QCFG="risignaltype" RI Signal Output Carrier

This command specifies the RI (ring indicator) signal output carrier.

AT+QCFG="risignaltype"	RI Signal Output Carrier
Write Command **AT+QCFG="risignaltype"[,<risignatype>]**	Response If the optional parameter is omitted, query the current setting: **+QCFG: "risignaltype",<risignatype>** **OK** If the optional parameter is specified, set the RI signal output carrier: **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<risignaltype>	String type. RI signal output carrier.	
	"respective"	The ring indicator behaves according to the port where URC is presented. If URC is presented on UART port, it acts as a physical ring indicator. If on USB port, it acts as a virtual ring indicator. If on USB AT port which does not support a ring indicator, then there is no ring indicator. Use **AT+QURCCFG="urcport"** to determine the port on which URC is presented, see ***Chapter 2.23***.
	"physical"	Regardless of the port where URC is presented, it only affects the behavior of physical ring indicator.
<err>	Error codes. For more details, see ***Chapter 13.5***.	

NOTE

Executing **AT+QCFG="risignaltype",<risignatype>** writes data to NVM. Please proceed with caution.

3.2.3. AT+QCFG="data_interface" Set Network Port/Diagnostic Port Communication via PCIe/USB Interface

This command sets the network port/diagnostic port communication via USB/PCIe interface.

AT+QCFG="data_interface"	Set Network Port/Diagnostic Port Communication via PCIe/USB Interface
Write Command **AT+QCFG="data_interface"[,<network>,<diag>]**	Response If the optional parameters are omitted, query the current setting. **+QCFG: "data_interface",<network>,<diag>** **OK** If the optional parameters are specified, set the network port/diagnostic port communication via USB/PCIe interface. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<network>	Integer type. 0 Set the network port communication via USB interface. 1 Set the network port communication via PCIe interface. See note 3.
<diag>	Integer type. 0 Set the diagnostic port communication via USB interface.

NOTE

1. If the network port and diagnostic port communication is switched to the PCIe interface through eFuse, this command is invalid, and the communication cannot be switched back to the USB interface.
2. If the network port is set to communicate via the USB interface, the PCIe interface is disabled, i.e., no AT port or diagnostic port communicates via the PCIe interface.
3. PCIe switching with **AT+QCFG="data_interface"** is only possible when the host has an ARM system and the USB interface of the module is connected to the host.
4. PCIe switching through eFuse supports firmware upgrading when the host is connected via the

PCIe interface. However, PCIe switching via **AT+QCFG="data_interface"** does not support PCIe-based upgrading. Ensure to use the USB interface for firmware upgrading.

5. When rebooting the module (For example: 5 seconds after upgrading firmware via FOTA or host connection), ensure to synchronously reboot both the host and module while maintaining the same power-on time sequence as during the first initialization.
6. It is not recommended to execute **AT+CFUN=1,1** to restart the module with the PCIe interface, as it may cause the PCIe initialization time sequence errors, resulting in PCIe interface initialization failure. It is recommended to restart the module by hardware method instead.
7. If the module or the host restarts, ensure that the PCIe interface initializes correctly in the proper time sequence.

Example

```
AT+QCFG="data_interface"                //Query the current configuration.
+QCFG: "data_interface",0,0

OK
AT+QCFG="data_interface",1,0            //Set the network port communication via PCIe interface, and
                                        diagnostic port communication via USB interface, enabling AT
                                        commands to communicate via both interfaces.
OK
```

3.2.4. AT+QCFG="pcie/mode" Set PCIe RC/EP Mode

This command sets PCIe RC/EP mode.

AT+QCFG="pcie/mode" Set PCIe RC/EP Mode	
Write Command **AT+QCFG="pcie/mode"[,<mode>]**	Response If the optional parameter is omitted, query the current setting. **+QCFG: "pcie/mode",<mode>** **OK** If the optional parameter is specified, set PCIe RC/EP mode. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<mode>	Integer type. PCIe RC or EP mode. 0 PCIe EP mode. 1 PCIe RC mode.

Example

```
AT+QCFG="pcie/mode"          //Query the current configuration.
+QCFG: "pcie/mode",0

OK
AT+QCFG="pcie/mode",1        //Set PCIe RC/EP mode to PCIe RC mode.
OK
```

3.2.5. AT+QCFG="usbnet" Configure NIC Data Call Method

This command configures NIC data call method in USB NIC mode.

AT+QCFG="usbnet" Configure NIC Data Call Method	
Write Command **AT+QCFG="usbnet"[,<net>]**	Response If the optional parameter is omitted, query the current setting. **+QCFG: "usbnet",<net>** **OK** If the optional parameter is specified, configure the NIC data call method in USB NIC mode. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	This command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<net>	Integer type. NIC data call method in USB NIC mode. 0 RmNET 1 ECM 2 MBIM

	3 RNDIS

Example

```
AT+QCFG="usbnet"          //Query the current configuration.
+QCFG: "usbnet",0

OK
AT+QCFG="usbnet",1        //Set the NIC data call method to ECM.
OK
```

3.2.6. AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS

This command enables or disables delivering or submitting SMS.

AT+QCFG="sms_control" Enable/Disable Delivering or Submitting SMS	
Write Command **AT+QCFG="sms_control"[,<submit>,<deliver>]**	Response If the optional parameters are omitted, query the current setting. **+QCFG: "sms_control",<submit>,<deliver>** **OK** If the optional parameters are specified, enable or disable delivering or submitting SMS. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately; The configurations are saved automatically.

Parameter

<submit>	Integer Type. Enable or disable submitting SMS. 0 Disable 1 Enable
<deliver>	Integer Type. Enable or disable delivering SMS. 0 Disable 1 Enable

NOTE

1. After submitting SMS is disabled, executing **AT+CMGS/AT+CMSS** will return an error.
2. This command takes effect in both 3GPP and 3GPP2 messages.

Example

```
AT+QCFG="sms_control"                    //Query SMS control configuration.
+QCFG: "sms_control",1,1

OK
AT+QCFG="sms_control",0,1                //Disable submitting SMS.
OK
AT+CMGS="17301836745"
+CMS ERROR: 302                          //The operation is not allowed.
AT+QCFG="sms_control",0,0                //Disable submitting and delivering SMS.
OK
```

3.2.7. AT+QCFG="call_control" Enable/Disable Voice Call Features

This command enables or disables MO and MT voice call features of the module.

AT+QCFG="call_control" Enable/Disable Voice Call Features	
Write Command **AT+QCFG="call_control"[,<disableMO>,<disableMT>]**	Response If the optional parameters are omitted, query the current setting. **+QCFG: "call_control",<disableMO>,<disableMT>** **OK** If the optional parameter is specified, enable or disable MO and MT voice call feature of the module. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately; the configurations are saved automatically.

Parameter

<disableMO>	Integer type. Whether to disable MO voice call feature. 0 Not disable 1 Disable
<disableMT>	Integer type. Whether to disable MT voice call feature. 0 Not disable 1 Disable

Example

```
AT+QCFG=?
…
+QCFG: "call_control",(0,1),(0,1)
…

OK
AT+QCFG="call_control"
+QCFG: "call_control",0,0

OK
ATD10086;       //Make a MO voice call.
OK
ATH
OK
AT+QCFG="call_control",1,0
OK
ATD10086;       //Failed to make a MO voice call.
ERROR
```

3.2.8. AT+QCFG="ResetFactory" Restore to Factory Settings

This command restores the module configuration to Quectel factory settings. It restores the efs2 partition to factory settings and format the usrdata partition.

AT+QCFG="ResetFactory"	Restore to Factory Settings
Write Command **AT+QCFG="ResetFactory"**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted.

NOTE

1. This command may discard some customer's files and data in efs2 and usrdata. Please proceed with caution.
2. After the command is executed, the module will be rebooted automatically after about 2 seconds.
3. It is not recommended to power down the module while executing this command, otherwise it may cause incomplete data restoration.
4. If the module powers down abnormally during the execution of this command, it is recommended to execute the command again after the module powers up.

Example

```
AT+QCFG="ResetFactory"
OK
```

3.2.9. AT+QCFG="usbcfg" Configure USB Composite Features

This command configures USB composite features.

AT+QCFG="usbcfg"	Configure USB Composite Features
Write Command **AT+QCFG="usbcfg"[,<VID>,<PID>,<Diag>,<NMEA>,<AT_Port>,<NET>,<ADB>]**	Response If the optional parameters are omitted, query the current configuration: **+QCFG:"usbcfg",<VID>,<PID>,<Diag>,<NMEA>,<AT_Port>,<NET>,<ADB>** **OK** If the optional parameters are specified, configure USB composite features: **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations will be saved automatically.

Parameter

<VID>	Integer type in hexadecimal format. Vendor ID of USB device. Maximum value: 0xFFFF.
<PID>	Integer type in hexadecimal format. Product ID of USB device. Maximum value: 0xFFFF.
<Diag>	Integer type. USB diagnostic port state.

	0	Disable
	1	Enable
<NMEA>	Integer type. USB NMEA port state.	
	0	Disable
	1	Enable
<AT_Port>	Integer type. USB AT port state.	
	0	Disable
	1	Enable
<NET>	Integer type. USB network device state.	
	0	Disable
	1	Enable
<ADB>	Integer type. USB ADB device state.	
	0	Disable
	1	Enable

Example

```
AT+QCFG="usbcfg"
+QCFG: "usbcfg",0x2C7C,0x0316,1,1,1,1,0

OK
AT+QCFG="usbcfg",0x2C7C,0x0316,1,1,1,1,1 //Enable ADB. Please decrypt first, otherwise it will
                                          return ERROR.
OK
```

NOTE

1. ADB is disabled and encrypted by default for security. If you want to enable it, please contact Quectel Technical Support.
2. Please do not modify the **<VID>** and **<PID>** arbitrarily.

3.2.10. AT+QCFG="ntp" Specify Re-transmission Count and Interval for NTP Client

The command specifies the re-transmission count and the interval for NTP client.

AT+QCFG="ntp"	Specify Re-transmission Count and Interval for NTP Client
Write Command **AT+QCFG="ntp"[,<cnt>,<interval>]**	Response If the optional parameters are omitted, query the current setting: **+QCFG: "ntp",<cnt>,<interval>** **OK**

	If the optional parameters are not omitted, specify the re-transmission count and the interval for NTP client: **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations will be saved automatically.

Parameter

<cnt>	Integer type. NTP client re-transmission count. Range: 1–10. Default value: 3.
<interval>	Integer type. NTP client re-transmissions interval. Range: 5–60. Default value: 15.

Example

```
AT+QCFG="ntp"          //Query the current setting.
+QCFG: "ntp",3,15

OK

AT+QCFG="ntp",5,20     //Set NTP client re-transmission count and interval.

OK
AT+QCFG="ntp"          //Query the current setting.
+QCFG: "ntp",5,20

OK
```

3.3 AT+QPLATCFG Configure and Query Platform Function Settings

This command queries and configures platform function settings, and it's only supported on RG255C series modules.

AT+QCFG Configure and Query Platform Function Settings	
Test Command **AT+QPLATCFG=?**	Response **+QPLATCFG: "board_type",(**list of supported **<enable>**s**)** **+QPLATCFG: "periph_cfg",<periph>,(**list of supported **<enable>**s**)** **OK**

Maximum Response Time	300 ms

3.3.1. AT+QPLATCFG="board_type" Query/Set Board Type

This command queries or sets the board type.

AT+QPLATCFG="board_type" Query/Set Board Type	
Write Command **AT+QPLATCFG="board_type"[,<type>]**	Response If the optional parameter is omitted, query the current setting. **+QPLATCFG: "board_type",<type>** **OK** If the optional parameter is specified, set the board type. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<type>	Integer type. Board type. 0 Support CNSS2 and Ethernet 1 Support CNSS and Ethernet 2 Support PCIe EP

Example

```
AT+QPLATCFG="board_type"      //Query the current setting.
+QPLATCFG: "board_type",0

OK
AT+QPLATCFG="board_type",1    //Set board type to 1.
OK
```

NOTE

The Wi-Fi driver relies on CNSS. CNSS2 (ConNectivity SubSystem 2.0) supports Quectel Wi-Fi modules FC60E, FC08E and so on, while CNSS (ConNectivity SubSystem) supports QCA6174. For more

supported Wi-Fi modules, see *Quectel_RG255C_Series_Wi-Fi_User_Guide*.

3.3.2. AT+QPLATCFG="periph_cfg" Enable/Disable Peripheral

This command enables or disables peripheral.

AT+QPLATCFG="periph_cfg" Enable/Disable Peripheral	
Write Command **AT+QPLATCFG="periph_cfg"[,<peripheral>,<enable>]**	Response If the optional parameter is omitted, query the current setting. **+QPLATCFG: "periph_cfg","ethernet",<enable>** **+QPLATCFG: "periph_cfg","cnss",<enable>** **OK** If the optional parameter is specified, enable or disable peripheral. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<peripheral>	String type. Name of the peripheral. "ethernet" Ethernet network. "cnss" ConNectivity SubSystem. The Wi-Fi driver relies on CNSS.
<enable>	Integer type. Enable or disable the peripheral. 0 Disable 1 Enable

Example

```
AT+QPLATCFG="periph_cfg"                    //Query the current setting.
+QPLATCFG: "periph_cfg","ethernet",0
+QPLATCFG: "periph_cfg","cnss",0

OK
AT+QPLATCFG="periph_cfg","ethernet",1       //Enable ethernet peripheral.
OK
```

NOTE

Ethernet and WLAN functions are only supported on RG255C series modules and are disabled by default on standard firmware for power consumption saving.

4 (U)SIM Related Commands

4.1 AT+CIMI Request IMSI

This command requests the IMSI (International Mobile Subscriber Identity), which is intended to permit TE to identify the individual (U)SIM card or active application in the UICC (GSM or (U)SIM) that is attached to MT.

AT+CIMI Request IMSI	
Test Command **AT+CIMI=?**	Response **OK**
Execution Command **AT+CIMI**	Response TA returns **<IMSI>** for identifying the individual (U)SIM which is attached to the module. **<IMSI>** **OK** If there is any error: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<IMSI>	String without double quotes. International mobile subscriber identity.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CIMI                 //Query IMSI number of (U)SIM attached to MT.
460023210226023

OK
```

4.2 AT+ICCID Get ICCID

This command returns ICCID (Integrated Circuit Card ID) if a (U)SIM card is inserted.

AT+ICCID Get ICCID	
Test Command **AT+ICCID=?**	Response **OK**
Execution Command **AT+ICCID**	Response **+ICCID: <ICCID>** **OK** If there is any error: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<ICCID>	String without double quotes. ICCID of (U)SIM card.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+ICCID                          //Query ICCID of the (U)SIM card.
+ICCID: 89148000000000000002

OK
```

4.3 AT+CLCK Facility Lock

This command locks/unlocks or interrogates an MT or a network facility **<fac>**. Normally such actions require a password. When querying the status of network service (**<mode>**=2), the response line for 'not active' case (**<status>**=0) should be returned only if service is not active for any **<class>**.

AT+CLCK Facility Lock	
Test Command **AT+CLCK=?**	Response **+CLCK: (**list of supported **<fac>**s**)**

	OK
Write Command **AT+CLCK=<fac>,<mode>[,<password>[,<class>]]**	Response If **<mode>** is not 2 and the command is set successfully: **OK** If **<mode>**=2 and the command is set successfully: **+CLCK: <status>[,<class>]** **[+CLCK: <status>[,<class>]]** **[…]** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<fac>	String type.	
	"SC"	(U)SIM (lock (U)SIM/UICC card inserted in the currently selected card slot) (U)SIM/UICC requests the password at MT power-up and when this lock command is issued).
	"AO"	BAOC (Barr All Outgoing Calls, see *3GPP TS 22.088*).
	"OI"	BOIC (Barr Outgoing International Calls, see *3GPP TS 22.088*).
	"OX"	BOIC-exHC (Barr Outgoing International Calls except to Home Country, see *3GPP TS 22.088*).
	"AI"	BAIC (Barr All Incoming Calls, see *3GPP TS 22.088*).
	"IR"	BIC-Roam (Barr Incoming Calls when Roaming outside the home country, see *3GPP TS 22.088*).
	"AB"	All barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0).
	"AG"	All outgoing barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0).
	"AC"	All incoming barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0).
	"FD"	(U)SIM card or active application in the UICC (GSM or (U)SIM) fixed dialing memory feature (if SIM PIN2 authentication has not been performed during the current session, SIM PIN2 is required as **<password>**. See ***Chapter 4.4*** for

		details about SIM PIN2).
	"PF"	Lock Phone to the very first inserted (U)SIM/UICC card (also referred in the present document as PH-FSIM) (MT requests a password when other (U)SIM/UICC cards are inserted).
	"PN"	Network Personalization (see *3GPP TS 22.022*)
	"PU"	Network Subset Personalization (see *3GPP TS 22.022*)
	"PP"	Service Provider Personalization (see *3GPP TS 22.022*)
	"PC"	Corporate Personalization (see *3GPP TS 22.022*)
<mode>	Integer type. Operation mode.	
	0	Unlock
	1	Lock
	2	Query status
<password>	String type. Password.	
<class>	Integer type.	
	1	Voice
	2	Data
	4	FAX
	7	All telephony except SMS
	8	Short message service
	16	Data circuit synchronization
	32	Data circuit asynchronization
<status>	Integer type. Lock status.	
	0	Not active (Unlocked)
	1	Active (Locked)
<err>	Error codes. For more details, see ***Chapter 13.5***.	

NOTE

When **<mode>** is not 2, executing **AT+CLCK=<fac>,<mode>[,<password>[,<class>]]** writes data to NVM. Please proceed with caution.

Example

```
AT+CLCK="SC",2                  //Query (U)SIM card status.
+CLCK: 0                        //(U)SIM card is unlocked (Not active).

OK
AT+CLCK="SC",1,"1234"           //Lock (U)SIM card. Password: 1234.
OK
AT+CLCK="SC",2                  //Query (U)SIM card status.
+CLCK: 1                        //(U)SIM card is locked Active).

OK
AT+CLCK="SC",0,"1234"           //Unlock (U)SIM card.
```

OK

4.4 AT+CPIN Enter PIN

This command sends to the MT a password that is necessary before it can be operated, or queries whether MT requires a password before it can be operated. The password may be (U)SIM PIN, (U)SIM PUK (PIN Unlocking Key), PH-SIM PIN, etc.

AT+CPIN Enter PIN	
Test Command **AT+CPIN=?**	Response **OK**
Read Command **AT+CPIN?**	Response MT returns an alphanumeric string indicating if a password is required. **+CPIN: <code>** **OK** If there is any error related to MT functionality: **+CME ERROR: <err>**
Write Command **AT+CPIN=<pin>[,<new_pin>]**	Response MT stores a password, such as (U)SIM PIN, (U)SIM PUK, required to operate it. If the PIN is to be entered twice, MT automatically repeats the PIN. If no PIN request is pending, no action will be taken and an error message **+CME ERROR** is returned to TE. If the PIN required is (U)SIM PUK or (U)SIM PUK2, the second pin is required. The second PIN **<new_pin>** replaces the old pin in the (U)SIM. **OK** If there is any error: **+CME ERROR: <err>**
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<code>	String without double quotes.	
	READY	MT is not pending for any password
	SIM PIN	MT is waiting for (U)SIM PIN
	SIM PUK	MT is waiting for (U)SIM PUK
	SIM PIN2	MT is waiting for(U)SIM PIN2
	SIM PUK2	MT is waiting for (U)SIM PUK2
	PH-NET PIN	MT is waiting for network personalization password
	PH-NET PUK	MT is waiting for network personalization unlocking password
	PH-NETSUB PIN	MT is waiting for network subset personalization password
	PH-NETSUB PUK	MT is waiting for network subset personalization unlocking password
	PH-SP PIN	MT is waiting for service provider personalization password
	PH-SP PUK	MT is waiting for service provider personalization unlocking password
	PH-CORP PIN	MT is waiting for corporate personalization password
	PH-CORP PUK	MT is waiting for corporate personalization unlocking password
<pin>	String type. Password. If the requested password is a PUK, such as (U)SIM PUK, (U)SIM PUK2, etc., **<pin>** must be followed by **<new_pin>**.	
<new_pin>	String type. A second PIN to replace the old PIN in (U)SIM.	
<err>	Error codes. For more details, see ***Chapter 13.5***.	

Example

```
//Enter PIN
AT+CPIN?                          //Whether or not a password is required.
+CPIN: SIM PIN                    //Waiting for (U)SIM PIN to be given.

OK
AT+CPIN="1234"                    //Enter PIN.
OK

+CPIN: READY
AT+CPIN?                          //PIN has already been entered.
+CPIN: READY

OK
//Enter PUK and PIN
AT+CPIN?                          //Whether or not a password is required.
+CPIN: SIM PUK                    //Waiting for (U)SIM PUK to be given

OK
AT+CPIN="26601934","1234"         //Enter PUK and the new password.
```

```
OK

+CPIN: READY
AT+CPIN?                    //Whether or not a password is required.
+CPIN: READY                //PUK has already been entered.

OK
```

4.5 AT+CPWD Change Password

This command sets a new password for the facility lock function defined by **AT+CLCK**.

AT+CPWD Change Password	
Test Command **AT+CPWD=?**	Response MT returns a list of pairs that present the available facilities and the maximum length of their password. **+CPWD:** list of supported **(<fac>,<pwdlength>)**s **OK**
Write Command **AT+CPWD=<fac>,<oldpwd>,<newpwd>**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<fac>	String type. Facility lock type. "SC" (U)SIM (lock (U)SIM/UICC card inserted in the currently selected card slot) (U)SIM/UICC requests the password at MT power-up and when this lock command is issued). "AO" BAOC (Barr All Outgoing Calls, see *3GPP TS 22.088*) "OI" BOIC (Barr Outgoing International Calls, see *3GPP TS 22.088*) "OX" BOIC-exHC (Barr Outgoing International Calls except to Home Country, see

		3GPP TS 22.088)
	"AI"	BAIC (Barr All Incoming Calls, see *3GPP TS 22.088*)
	"IR"	BIC-Roam (Barr Incoming Calls when Roaming outside the home country, see *3GPP TS 22.088*)
	"AB"	All barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0)
	"AG"	All outgoing barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0)
	"AC"	All incoming barring services (see *3GPP TS 22.030*, applicable only for **<mode>**=0)
	"P2"	(U)SIM PIN2
<pwdlength>	Integer type. Maximum password length.	
<oldpwd>	String type. Password specified for the facility from the user interface or with command.	
<newpwd>	String type. New password.	
<err>	Error codes. For more details, see ***Chapter 13.5***.	

Example

```
AT+CPIN?                                  //Whether or not a password is required.
+CPIN: READY

OK
AT+CPWD="SC","1234","4321"                //Change (U)SIM card password to "4321".
OK
//Restart MT or re-activate the (U)SIM card
AT+CPIN?                                  //Waiting for (U)SIM PIN to be given.
+CPIN: SIM PIN

OK
AT+CPIN="4321"                            //PIN must be entered to define a new password "4321".
OK

+CPIN: READY
```

4.6 AT+CSIM Generic (U)SIM Access

This command allows a direct control of the (U)SIM inserted in the selected card slot by a remote application on TE. TE should then keep the processing of (U)SIM information within the frame specified by GSM/UMTS.

AT+CSIM Generic (U)SIM Access	
Test Command	Response
AT+CSIM=?	**OK**

Write Command **AT+CSIM=<length>,<command>**	Response **+CSIM: <length>,<response>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are not saved.
Reference	*3GPP TS 27.007*

Parameter

<length>	Integer type. Length of **<command>** or **<response>** (two times the actual length of the command or response). Unit: byte.
<command>	String type in hexadecimal format. Command transferred by the MT to the (U)SIM in the format described in *3GPP TS 51.011*.
<response>	String type in hexadecimal format. Response to the command transferred by the (U)SIM to the MT in the format described in *3GPP TS 51.011*.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CSIM=?
OK
AT+CSIM=10,"80F2010112"
+CSIM: 40,"8410A0000000871002FF86FF0389FFFFFFFF9000"

OK
```

4.7 AT+CRSM Restricted (U)SIM Access

This command offers easy and limited access to the (U)SIM database. It transmits the (U)SIM command number **<command>** and its required parameters to MT.

AT+CRSM Restricted (U)SIM Access	
Test Command	Response

AT+CRSM=?	**OK**
Write Command **AT+CRSM=<command>[,<fileId>[,<P1>,<P2>,<P3>[,<data>][,<pathId>]]]**	Response **+CRSM: <sw1>,<sw2>[,<response>]** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are not saved.
Reference	*3GPP TS 27.007*

Parameter

<command>	Integer type. (U)SIM command number. 176 READ BINARY 178 READ RECORD 192 GET RESPONSE 214 UPDATE BINARY 220 UPDATE RECORD 242 STATUS 203 RETRIEVE DATA 219 SET DATA
<fileId>	Integer type. Identifier for an elementary data file on (U)SIM, if used by **<command>**.
<P1>, <P2>, <P3>	Parameters passed on by the MT to the (U)SIM. These parameters are mandatory for every command, except GET RESPONSE and STATUS. Their values are described in *3GPP TS 51.011*.
<data>	String type in hexadecimal format. Information to be written to the (U)SIM.
<pathId>	String type in hexadecimal format. Directory path of an elementary file on a (U)SIM/UICC.
<sw1>, **<sw2>**	Integer type. Information from the (U)SIM about the execution of the actual command. These parameters are delivered to the TE in both cases, on successful or failed execution of the command.
<response>	String type in hexadecimal format. Response of a successful completion of the previously issued command. STATUS and GET RESPONSE return data, which gives information about the current elementary data field. The information includes the type and size of the file (see *3GPP TS 51.011*). After READ BINARY, READ

	RECORD or RETRIEVE DATA command, the requested data will be returned. **<response>** is not returned after a successful UPDATE BINARY, UPDATE RECORD or SET DATA command.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CRSM=?
OK
AT+CRSM=242
+CRSM:  144,0,"623A8202782183027FF08410A0000000871002FF86FFFF89FFFFFFFF8A01058B03
2F0601C6129001788301018301818301 0A83010B83010C81026DA7"

OK
AT+CRSM=242,80,01,01,12
+CRSM: 144,0,"8410A0000000871002FF86FF"

OK
```

4.8 AT+CCHO Open Logical Channel

This command opens a logical channel. **<sessionid>** is to be used when you send the command with generic UICC logical channel access **AT+CGLA** (see ***Chapter 4.10***).

AT+CCHO Open Logical Channel	
Test Command **AT+CCHO=?**	Response **OK**
Write Command **AT+CCHO=<dfname>**	Response **+CCHO: <sessionid>** **OK** If there is any error: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	*3GPP TS 27.007*

Parameter

<sessionid>	Integer type. A session ID to be used to target a specific application on the smart card, e.g. (U)SIM, WIM, ISIM, using the logical channel mechanism.
<dfname>	String type. All selectable applications in the UICC referenced by a DF name coded on 1 to 16 bytes.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CCHO=?
OK
AT+CCHO="A0000000871002FF86FFFF89FFFFFFFF"          //Open logical channels.
+CCHO: 1

OK
```

4.9 AT+CCHC Close Logical Channel

This command asks ME to close a communication session with the active UICC, then ME will close the previously opened logical channel, and TE will no longer be able to send commands on this logical channel. UICC closes the logical channel when receiving this command.

AT+CCHC Close Logical Channel	
Test Command **AT+CCHC=?**	Response **OK**
Write Command **AT+CCHC=<sessionid>**	Response **OK** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is not saved.
Reference	*3GPP TS 27.007*

Parameter

<sessionid>	Integer type. A session ID to be used to target a specific application on the smart card, e.g. (U)SIM, WIM, ISIM, using the logical channel mechanism.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CCHC=?
OK
AT+CCHC=1                    //Close logical channels.
OK
```

4.10 AT+CGLA Generic UICC Logical Channel Access

This command allows a direct control of the currently selected UICC by a remote application on TE. TE will process UICC information within the frame specified by GSM/UMTS.

AT+CGLA Generic UICC Logical Channel Access	
Test Command **AT+CGLA=?**	Response **OK**
Write Command **AT+CGLA=<sessionid>,<length>,<command>**	Response **+CGLA: <length>,<response>** **OK** If there is any error: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are not saved.
Reference	*3GPP TS 27.007*

Parameter

<sessionid>	Integer type. Identifier of the session used to send the APDU commands to the UICC. It is mandatory to send commands to the UICC when targeting applications on the smart card using a logical channel other than the default channel (channel "0").
<length>	Integer type. Length of the characters that are sent to TE in **<command>** or **<response>** (two times the actual length of the command or response).
<command>	String type in hexadecimal character format. Command passed on by the MT to the UICC as described in *3GPP TS 31.101*.
<response>	String type in hexadecimal character format. Response to the command passed on by the UICC to the MT in the format as described in *3GPP TS 31.101*.
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

Before using this command, the logical channel must be opened via **AT+CCHO=<dfname>**.

Example

```
AT+CGLA=?
OK
AT+CGLA=1,10,"80F2010112"
+CGLA: 40,"8410A0000000871002FF86FFFF89FFFFFFFF9000"

OK
```

4.11 AT+QPINC Remaining PIN/PUK Retries

This command queries the number of remaining PIN/PUK retries.

AT+QPINC Remaining PIN/PUK Retries	
Test Command **AT+QPINC=?**	Response **+QPINC: (**list of supported **<facility>**s**)** **OK**
Read Command **AT+QPINC?**	Response **+QPINC: "SC",<PIN_retries>,<PUK_retries>** **+QPINC: "P2",<PIN_retries>,<PUK_retries>** **OK**
Write Command **AT+QPINC=<facility>**	Response **+QPINC: <facility>,<PIN_retries>,<PUK_retries>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<facility>	String type. "SC" (U)SIM PIN "P2" (U)SIM PIN2
<pincounter>	Integer type. Number of remaining PIN retries.
<pukcounter>	Integer type. Number of remaining PUK retries.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+QPINC?
+QPINC: "SC",3,10
+QPINC: "P2",3,10

OK
```

4.12 AT+QSIMDET (U)SIM Card Detection

This command enables or disables (U)SIM card detection. (U)SIM card is detected by GPIO interrupt. The level of (U)SIM card detection pin should also be set when the (U)SIM card is inserted.

AT+QSIMDET (U)SIM Card Detection	
Test Command **AT+QSIMDET=?**	Response **+QSIMDET: (**list of supported **<enable>**s**),(**list of supported **<insert_level>**s**)** **OK**
Read Command **AT+QSIMDET?**	Response **+QSIMDET: <enable>,<insert_level>** **OK**
Write Command **AT+QSIMDET=<enable>,<insert_level>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable or disable (U)SIM card detection. 0 Disable 1 Enable
<insert_level>	Integer type. Level of (U)SIM detection pin when a (U)SIM card is inserted. 0 Low level 1 High level

NOTE

1. (U)SIM card detection is invalid if the configured value of **<insert_level>** is inconsistent with hardware design.
2. The configuration of **<insert_level>** is valid only when (U)SIM card detection is enabled.
3. Executing **AT+QSIMDET=<enable>,<insert_level>** writes data to NVM. Please proceed with caution.

Example

```
AT+QSIMDET=1,0      //Set (U)SIM card detection pin level as low when a (U)SIM card is inserted.
OK

<Remove (U)SIM card>
+CPIN: NOT READY

<Insert (U)SIM card>
+CPIN: READY
```

4.13 AT+QSIMSTAT (U)SIM Card Insertion Status Report

This command queries (U)SIM card insertion status or determines whether (U)SIM card insertion status report is enabled.

AT+QSIMSTAT (U)SIM Card Insertion Status Report	
Test Command **AT+QSIMSTAT=?**	Response **+QSIMSTAT: (**list of supported **<enable>**s**)** **OK**
Read Command **AT+QSIMSTAT?**	Response **+QSIMSTAT: <enable>,<inserted_status>** **OK**

Write Command **AT+QSIMSTAT=<enable>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<enable>	Integer type. Enable or disable (U)SIM insertion status report. If it is enabled, the URC **+QSIMSTAT: <enable>,<inserted_status>** is reported when (U)SIM card is inserted or removed. 0 Disable 1 Enable
<inserted_status>	Integer type. (U)SIM card insertion status. 0 Removed 1 Inserted 2 Unknown (before (U)SIM initialization)

NOTE

Executing **AT+QSIMSTAT=<enable>** writes data to NVM. Please proceed with caution.

Example

```
AT+QSIMSTAT?                    //Query (U)SIM card insertion status.
+QSIMSTAT: 0,1

OK
AT+QSIMDET=1,0
OK
AT+QSIMSTAT=1                   //Enable reporting of (U)SIM card insertion status.
OK
AT+QSIMSTAT?                    //Query (U)SIM card insertion status.
+QSIMSTAT: 1,1

OK
//Remove the (U)SIM card
+QSIMSTAT: 1,0                  //Report of (U)SIM card insertion status: removed.

+CPIN: NOT READY
```

```
AT+QSIMSTAT?                    //Query (U)SIM card insertion status.
+QSIMSTAT: 1,0

OK
//Insert a (U)SIM card
+QSIMSTAT: 1,1                  //Report of (U)SIM card insertion status: inserted.

+CPIN: READY
```

4.14 AT+QUIMSLOT Set Card Slot

This command queries the currently selected card slot, and sets the card slot to be used by the (U)SIM card.

AT+QUIMSLOT Set Card Slot	
Test Command **AT+QUIMSLOT=?**	Response **+QUIMSLOT: (**list of supported **<slot>**s**)** **OK**
Read Command **AT+QUIMSLOT?**	Response **+QUIMSLOT: <slot>** **OK**
Write Command **AT+QUIMSLOT=<slot>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<slot>	Integer type. (U)SIM card slot. 1 Card slot 1 2 Card slot 2

NOTE

Executing **AT+QUIMSLOT=<slot>** writes data to NVM. Please proceed with caution.

Example

```
AT+QUIMSLOT?                    //Query the currently selected (U)SIM card slot.
+QUSIMSLOT: 1

OK
AT+QUIMSLOT=2                   //Set (U)SIM card slot 2 to be active .
OK
```

5 Network Service Commands

5.1 AT+COPS Operator Selection

This command returns information about the current operators and their status, and allows automatic or manual network selection.

The Test Command returns a set or sets of five parameters, each set representing an operator present in the network. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in the order of: home network, networks referenced in (U)SIM and other networks.

The Read Command returns the current network registration/deregistration mode and the currently selected operator. If no operator is selected, **<format>**, **<oper>** and **<AcT>** are omitted.

The Write Command forces an attempt to select and register the EPS/5G network operator. If the selected operator is not available, no other operator shall be selected (except **<mode>**=4). The format of selected operator name shall apply to further Read Command (**AT+COPS?**).

AT+COPS Operator Selection	
Test Command **AT+COPS=?**	Response **+COPS: [**list of supported **(<stat>,**long alphanumeric **<oper>,**short alphanumeric **<oper>,**numeric **<oper>**s**[,<AcT>])**s**][,,(**list of supported **<mode>**s**),(**list of supported **<format>**s**)]** **OK** If there is any error: **+CME ERROR: <err>**
Read Command **AT+COPS?**	Response **+COPS: <mode>[,<format>[,<oper>][,<AcT>]]** **OK** If there is any error related to MT functionality: **+CME ERROR: <err>**
Write Command	Response

AT+COPS=<mode>[,<format>[,<oper>[,<AcT>]]]	**OK** Or **+CME ERROR: <err>**
Maximum Response Time	180 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<stat>	Integer type. Availability of operators. 0 Unknown 1 Operator available 2 Current operator 3 Operator forbidden
<oper>	String type. Operator in format as per **<format>**.
<mode>	Integer type. 0 Automatic operator selection (**<oper>** field is ignored). 1 Manual operator selection (**<oper>** field shall be present and **<AcT>** is optional) 2 Deregistration from network 3 Set only **<format>** (for **AT+COPS?** Read Command), and do not attempt registration/deregistration (**<oper>** and **<AcT>** fields are ignored). This value is invalid in the response of the Read Command. 4 Manual/automatic selection (**<oper>** field shall be presented). If manual selection fails, automatic mode (**<mode>**=0) is entered.
<format>	Integer type. Format of **<oper>**. 0 Long format alphanumeric **<oper>** up to 16 characters 1 Short format alphanumeric **<oper>** 2 Numeric **<oper>**. GSM location area identification number
<AcT>	Integer type. Access technology selected. 7 E-UTRAN 11 NR connected to a 5GCN 12 NG-RAN
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

1. When selecting NR5G SA network, **<AcT>** should be set to 12, and when registering NR5G SA network, **<AcT>** returned by **AT+COPS?** is 11.
2. Executing **AT+COPS=<mode>[,<format>[,<oper>[,<AcT>]]]** writes data to NVM (Non-Volatile Memory). Please proceed with caution.

Example

```
AT+COPS=?                                   //List all network operators present in the network.
+COPS: (1,"CHN-UNICOM","UNICOM","46001",12),(3,"CHINA MOBILE","CMCC","46000",7),(3,"CHN-CT","CT","46011",12),(3,"CHN-CT","CT","46011",7),(3,"CHINA MOBILE","CMCC","46000",12),,(0-4),(0-2)

OK
AT+COPS?                                    //Query the currently selected network operator.
+COPS: 0,0,"CHINA MOBILE",11

OK
```

5.2 AT+CEREG EPS Network Registration Status

This command queries the network registration status and controls the presentation of URC **+CEREG: <stat>** when **<n>**=1 and there is a change in the MT's EPS network registration status in E-UTRAN, or URC **+CEREG: <stat>[,[<tac>],[<ci>],[<AcT>]]** when **<n>**=2 and there is a change of the network cell in E-UTRAN.

AT+CEREG EPS Network Registration Status	
Test Command **AT+CEREG=?**	Response **+CEREG: (**list of supported **<n>**s**)** **OK**
Read Command **AT+CEREG?**	Response **+CEREG: <n>,<stat>[,<tac>,<ci>[,<AcT>]]** **OK**
Write Command **AT+CEREG=[<n>]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type.	
	0	Disable network registration URC
	1	Enable network registration URC **+CEREG:<stat>**
	2	Enable network registration and location information URC **+CEREG: <stat>[,[<tac>],[<ci>],[<AcT>]]**
<stat>	Integer type. EPS registration status.	
	0	Not registered, MT is not currently searching an operator to register to.
	1	Registered. Home network.
	2	Not registered, but MT is currently trying to attach or searching an operator to register to.
	3	Registration denied.
	4	Unknown
	5	Registered. Roaming.
<tac>	String type. Two-byte tracking area code in hexadecimal format.	
<ci>	String type. Four-byte (E-UTRAN) cell ID in hexadecimal format.	
<AcT>	Access technology selected.	
	7	E-UTRAN

Example

```
AT+CEREG=?
+CEREG: (0-2)

OK
AT+CEREG=2
OK
AT+CEREG?
+CEREG: 2,1,"DE10","5A29C0B",7

OK

+CEREG: 1,"DE10","5A29C0B",7
```

5.3 AT+C5GREG 5GS Network Registration Status

This command queries the network registration status and controls the presentation of URC **+C5GREG: <stat>** when **<n>**=1 and there is a change in the MT's network registration status in 5GS.

It also controls the presentation of URC **+C5GREG: <stat>[,[<tac>],[<ci>],[<AcT>],[<Allowed_NSSAI_length>],[<Allowed_NSSAI>]]** when **<n>**=2 and

there is a change of the network cell in 5GS or when the network provides an allowed NSSAI. The parameters **<AcT>**, **<tac>**, **<ci>**, **<Allowed_NSSAI_length>** and **<Allowed_NSSAI>** are included only if available.

AT+C5GREG 5GS Network Registration Status	
Test Command **AT+C5GREG=?**	Response **+C5GREG: (**list of supported **<n>**s**)** **OK**
Read Command **AT+C5GREG?**	Response **+C5GREG: <n>,<stat>[,[<tac>],[<ci>],[<AcT>],[<Allowed_NSSAI_length>],[<Allowed_NSSAI>]]** **OK**
Write Command **AT+C5GREG=[<n>]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. 0 Disable network registration URC 1 Enable network registration URC **+C5GREG:<stat>** 2 Enable network registration and location information URC **+C5GREG: <stat>[,[<tac>],[<ci>],[<AcT>],[<Allowed_NSSAI_length>],[<Allowed_NSSAI>]]**
<stat>	Integer type. Indicate the NR registration status. 0 Not registered. MT is currently not searching an operator to register to 1 Registered. Home network. 2 Not registered. but MT is currently trying to attach or searching an operator to register to 3 Registration denied 4 Unknown 5 Registered. Roaming 8 Registered for emergency services only
<tac>	String type. Three-byte tracking area code in hexadecimal format.
<ci>	String type. Five-byte (NR) cell ID in hexadecimal format.

<AcT>	Integer type. Access technology selected. 10 E-UTRAN connected to a 5GCN 11 NR connected to a 5GCN
<Allowed_NSSAI_length>	Integer type. Number of octets of the **<Allowed_NSSAI>** information element.
<Allowed_NSSAI>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s). This parameter indicates the list of allowed S-NSSAIs received from the network. **<Allowed_NSSAI>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *3GPP 27.007 subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<S-NSSAI>	String type in hexadecimal character format. Depending on the form, the string can be separated by dot(s) and semicolon(s). This parameter is associated with the PDU session for identifying a network slice in 5GS, see *3GPP TS 23.501 and 3GPP TS 24.501*. For the format and the encoding of S-NSSAI, see also *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**. The parameter takes one of the following forms: sst only slice/service type (SST) is present sst;mapped_sst SST and mapped configured SST are present sst.sd SST and slice differentiator (SD) are present sst.sd;mapped_sst SST, SD and mapped configured SST are present sst.sd;mapped_sst.mapped_sd SST, SD, mapped configured SST and mapped configured SD are present.

Example

```
AT+C5GREG=?
+C5GREG: (0-2)

OK
AT+C5GREG=2
OK
AT+C5GREG?
+C5GREG: 2,1,"690E0F","9013B004",11,4,"01.000000"

OK
+C5GREG: 1,"690E0F","9013B004",11,4,"01.000000"
```

5.4 AT+C5GNSSAI 5GS NSSAI Setting

This command enables updating the default NSSAI configuration stored at MT.

AT+C5GNSSAI 5GS NSSAI Setting	
Test Command **AT+C5GNSSAI=?**	Response **+C5GNSSAI: (**list of supported **<default_configured_nssai_length>**s**),(**list of supported **<default_configured_nssai>**s**)** **OK**
Read Command **AT+C5GNSSAI?**	Response **+C5GNSSAI: [<default_configured_nssai_length>,<default_configured_nssai>]** **OK**
Write Command **AT+C5GNSSAI=<default_configured_nssai_length>,<default_configured_nssai>**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<default_configured_nssai_length>	Integer type. Default configured NSSAI length in octets to be stored in MT.
<default_configured_nssai>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s). This parameter indicates the list of S-NSSAIs included in the default configured NSSAI to be stored by the MT. **<default_configured_nssai>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

1. If the value is an empty string (""), no default configured NSSAI is stored in MT.
2. Executing **AT+C5GNSSAI=<default_configured_nssai_length>,<default_configured_nssai>** writes data to NVM. Please proceed with caution.

5.5 AT+C5GNSSAIRDP Read 5GS NSSAI Dynamic Parameters

This command returns the default configured NSSAI, rejected NSSAI for 3GPP access and rejected NSSAI for non-3GPP access stored at the MT.

AT+C5GNSSAIRDP Read 5GS NSSAI Dynamic Parameters	
Test Command **AT+C5GNSSAIRDP=?**	Response **+C5GNSSAIRDP: (**range of supported **<nssai_type>**s**),(**list of supported **<plmn_id>**s**)** **OK**
Write Command **AT+C5GNSSAIRDP[=<nssai_type>[,<plmn_id>]]** If **<plmn_id>** is omitted, the NSSAIs for all PLMNs for which the MT has stored NSSAI information are returned.	Response **[+C5GNSSAIRDP: [<default_configured_nssai_length>,<default_configured_nssai>[,<rejected_nssai_3gpp_length>,<rejected_nssai_3gpp>[,<rejected_nssai_non3gpp_length>,<rejected_nssai_non3gpp>]]]** **[+C5GNSSAIRDP: <plmn_id>[,<configured_nssai_length>,<configured_nssai>[,<allowed_nssai_3gpp_length>,<allowed_nssai_3gpp>,<allowed_nssai_non3gpp_length>,<allowed_nssai_non3gpp>]]** **[+C5GNSSAIRDP: <plmn_id>[,<configured_nssai_length>,<configured_nssai>[,<allowed_nssai_3gpp_length>,<allowed_nssai_3gpp>,<allowed_nssai_non3gpp_length>,<allowed_nssai_non3gpp>]]** **[...]]]]** **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<nssai_type>	Integer type. Type of NSSAI to be returned. 0 Return stored default configured NSSAI only 1 Return stored default configured NSSAI and rejected NSSAI(s) 2 Return stored default configured NSSAI, rejected NSSAI(s) and configured NSSAI(s) 3 Return stored default configured NSSAI, rejected NSSAI(s), configured NSSAI(s) and allowed NSSAI(s)
<plmn_id>	String type. MCC and MNC of the PLMN to which the NSSAI information applies. For the format and the encoding of the MCC and MNC, see *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<default_configured_nssai_length>	Integer type. Length in octets of the default configured NSSAI stored in MT.
<default_configured_nssai>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s). This parameter indicates the list of S-NSSAIs included in the default configured NSSAI stored in MT for the PLMN. The **<default_configured_nssai>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *3GPP 27.007 subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS.**
<rejected_nssai_3gpp_length>	Integer type. Length in octets of the rejected NSSAI associated with 3GPP access stored in MT for the serving PLMN.
<rejected_nssai_3gpp>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), colon(s) and hash(es). This parameter indicates the list of rejected S-NSSAIs associated with 3GPP access stored in MT for the serving PLMN. **<rejected_nssai_3gpp>** is coded as a list of rejected **<S-NSSAI>**s separated by colon. For the format and the encoding of **<S-NSSAI>**, see also *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**. The rejected S-NSSAI takes one of the following forms: sst#cause only slice/service type (SST) and reject cause are present sst.sd#cause SST and slice differentiator (SD) and reject cause are present where cause is a cause value according to *3GPP TS 24.501 table 9.11.3.46.1*.
<rejected_nssai_non3gpp_length>	Integer type. Length in octets of the rejected NSSAI associated

	with non-3GPP access stored at the MT for the serving PLMN.
<rejected_nssai_non3gpp>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), colon(s) and hash(es). This parameter indicates the list of rejected S-NSSAIs associated with non-3GPP access stored in MT for the serving PLMN. **<rejected_nssai_non3gpp>** is coded as a list of rejected **<S-NSSAI>**s separated by colon. For the format and the encoding of **<S-NSSAI>**, see also *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**. The rejected S-NSSAI takes one of the following forms: sst#cause — only slice/service type (SST) and reject cause are present sst.sd#cause — SST and slice differentiator (SD) and reject cause are present where cause is a cause value is according to *3GPP TS 24.501 table 9.11.3.46.1*.
<configured_nssai_length>	Integer type. Length in octets of the configured NSSAI stored in MT for the PLMN identified by **<plmn_id>**.
<configured_nssai>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s). This parameter indicates the list of configured S-NSSAIs stored in MT for the PLMN identified by **<plmn_id>**. The **<configured_nssai>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *3GPP 27.007 subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<allowed_nssai_3gpp_length>	Integer type. Length in octets of the allowed NSSAI associated with 3GPP access stored in MT for the PLMN identified by **<plmn_id>**.
<allowed_nssai_3gpp>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s). This parameter indicates the list of allowed S-NSSAIs associated with 3GPP access stored in MT for the PLMN identified by **<plmn_id>**. The **<allowed_nssai_3gpp>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *3GPP 27.007 subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<allowed_nssai_non3gpp_length>	Integer type. Length in octets of the allowed NSSAI associated with non-3GPP access stored in MT for the PLMN identified by **<plmn_id>**.
<allowed_nssai_non3gpp>	String type in hexadecimal format. Depending on the form, the string can be separated by dot(s), semicolon(s) and colon(s).

	This parameter indicates the list of allowed S-NSSAIs associated with non-3GPP access stored in MT for the PLMN identified by **<plmn_id>**. The **<allowed_nssai_non3gpp>** is coded as a list of **<S-NSSAI>**s separated by colons. See **<S-NSSAI>** in *3GPP 27.007 subclause 10.1.1*. This parameter is not subject to conventional character conversion as per **AT+CSCS**.
<S-NSSAI>	String type in hexadecimal character format. Depending on the form, the string can be separated by dot(s) and semicolon(s). This parameter is associated with the PDU session for identifying a network slice in 5GS, see *3GPP TS 23.501 and 3GPP TS 24.501*. For the format and the encoding of S-NSSAI, see also *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**. The parameter takes one of the following forms: sst only slice/service type (SST) is present sst;mapped_sst SST and mapped configured SST are present sst.sd SST and slice differentiator (SD) are present sst.sd;mapped_sst SST, SD and mapped configured SST are present sst.sd;mapped_sst.mapped_sd SST, SD, mapped configured SST and mapped configured SD are present.

5.6 AT+CGDCONT Define PDP Contexts

This command specifies PDP context parameters for a specific context **<cid>**. A special form of the Write Command (**AT+CGDCONT=<cid>**) causes the values for **<cid>** to become undefined. It is not allowed to change the definition of an already activated context.

This Read Command returns the current configurations for each defined PDP context.

AT+CGDCONT Define PDP Contexts	
Test Command **AT+CGDCONT=?**	Response **+CGDCONT: (**list of supported **<cid>**s**),<PDP_type>,<APN>,<PDP_addr>,(**list of supported **<d_comp>**s**),(**list of supported **<h_comp>**s**)[,(**list of supported **<IPv4AddrAlloc>**s**)[,(**list of supported

	<request_type>s**)[,(**list of supported **<SSC_mode>**s**)[,(**list of supported **<S-NSSAI>**s**)[,(**list of supported **<Pref_access_type>**s**)[,(**list of supported **<Always-on_req>**s**)]]]]]]** **OK**
Read Command **AT+CGDCONT?**	Response **+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<IPv4AddrAlloc>[,<request_type>,,,,,,,,[,<SSC_mode>[,<S-NSSAI>[,<Pref_access_type>,,[,<Always-on_req>]]]]]]** **[…]** **OK**
Write Command **AT+CGDCONT=[<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<IPv4AddrAlloc>[,<request_type>,,,,,,,,[,<SSC_mode>[,<S-NSSAI>[,<Pref_access_type>,,[,<Always-on_req>]]]]]]]]]]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<cid>	Integer type. PDP context identifier, which specifies a particular PDP context definition. Range: 1–16. The parameter is local to the TE-MT interface and is used in other PDP context-related commands.
<PDP_type>	String type. Packet data protocol type. "IP" IPv4. Internet protocol (see IETF STD 5) "IPV6" Internet Protocol, version 6 (see RFC 2460) "IPV4V6" Virtual **<PDP_type>** introduced to handle dual IP stack UE capability. (See *3GPP TS 24.301*)
<APN>	String type. Access point name, which is a logical name used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<PDP_addr>	String type. It identifies the MT in the address space applicable to the PDP. If the value is null or omitted, a value may be provided by the TE during the PDP startup procedure or, failing that, a dynamic address will be requested. The allocated address may be read using the **AT+CGPADDR** (see ***Chapter 9.3***).

<d_comp> Integer type. It controls PDP data compression (applicable for SNDCP only) (see *3GPP TS 44.065*).
0 Off
2 V.42bis

<h_comp> Integer type. It controls PDP header compression (see *3GPP TS 44.065 and 3GPP TS 25.323*).
0 Off
4 RFC3095

<IPv4AddrAlloc> Integer type. It controls how the MT/TA requests to get the IPv4 address information.
0 IPv4 address allocation through NAS signaling
1 IPv4 address allocated through DHCP

<request_type> Integer type. Type of PDP context activation request.
0 PDP context is for new PDP context establishment or for a handover from a non-3GPP access network (how the MT decides whether the PDP context is for new PDP context establishment or for a handover is implementation specific).
1 PDP context is for emergency bearer services.

<SSC_mode> Integer type. It indicates the session and service continuity (SSC) mode for the PDU session in 5GS, see *3GPP TS 23.501*.
0 The PDU session is associated with SSC mode 1
1 The PDU session is associated with SSC mode 2
2 The PDU session is associated with SSC mode 3

<S-NSSAI> String type in hexadecimal character format. Depending on the form, the string can be separated by dot(s) and semicolon(s). This parameter is associated with the PDU session for identifying a network slice in 5GS, see *3GPP TS 23.501 and 3GPP TS 24.501*. For the format and the encoding of S-NSSAI, see also *3GPP TS 23.003*. This parameter is not subject to conventional character conversion as per **AT+CSCS**. The parameter takes one of the following forms:

sst	only slice/service type (SST) is present
sst;mapped_sst	SST and mapped configured SST are present
sst.sd	SST and slice differentiator (SD) are present
sst.sd;mapped_sst	SST, SD and mapped configured SST are present
sst.sd;mapped_sst.mapped_sd	SST, SD, mapped configured SST and mapped configured SD are present

<Pref_access_type> Integer type. Preferred access type for the PDU session in 5GS, see *3GPP TS 23.501* and *3GPP TS 24.501*.
0 The preferred access type is 3GPP access
1 The preferred access type is non-3GPP access

<Always-on_req> Integer type. It indicates whether the UE requested to establish the PDU session as an always-on PDU session, see *3GPP TS 24.501*.
0 always-on PDU session was not requested
1 always-on PDU session was requested

NOTE

Executing **AT+CGDCONT=[<cid>[,<PDP_type>[,<APN>[,<PDP_addr>[,<d_comp>[,<h_comp>[,<IPv4AddrAlloc>[,<request_type>,,,,,,,,[,<SSC_mode>[,<S-NSSAI>[,<Pref_access_type>,,,[,<Always-on_req>]]]]]]]]]]** writes data to NVM. Please proceed with caution.

5.7 AT+QRSRP Report RSRP

The command queries and reports the RSRP of the current service network.

AT+QRSRP Report RSRP	
Test Command **AT+QRSRP=?**	Response **OK**
Execution Command **AT+QRSRP**	Response **+QRSRP: <PRX>,<DRX>,<sysmode>** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<PRX>	Integer type. PRX path RSRP value. Range: -140 to -44 dBm.
<DRX>	Integer type. DRX path RSRP value. Range: -140 to -44 dBm.
<sysmode>	String type. It indicates the service mode in which the MT will report the RSRP. LTE LTE mode NR5G NR5G mode

NOTE

1. If the queried **<PRX>** or **<DRX>** is -32768, it indicates that the RSRP value is invalid.
2. This command is strongly related to the RF link and is generally only used for customer reference and cannot be used as a sensitivity test. In addition, it is best to use it when measuring the speed. The results are more accurate.

Example

```
AT+QRSRP                    //Query RSRP.
+QRSRP: -101,-105,LTE
```

```
OK
```

5.8 AT+QRSRQ Report RSRQ

The command queries and reports the RSRQ of the current service network.

AT+QRSRQ Report RSRQ	
Test Command **AT+QRSRQ=?**	Response **OK**
Execution Command **AT+QRSRQ**	Response **+QRSRQ: <PRX>,<DRX>,<sysmode>** **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<PRX>	Integer type. PRX path RSRQ value. Range: -20 to -3 dB.	
<DRX>	Integer type. DRX path RSRQ value. Range: -20 to -3 dB.	
<sysmode>	String type. It indicates the service mode in which the MT will report the RSRQ.	
	LTE	LTE mode
	NR5G	NR5G mode

NOTE

1. If the queried **<PRX>** or **<DRX>** is -32768, it indicates that the RSRQ value is invalid.
2. This command is strongly related to the RF link and is generally only used for customer reference and cannot be used as a sensitivity test. In addition, it is best to use it when measuring the speed. The results are more accurate.

Example

```
AT+QRSRQ                    //Query RSRQ.
+QRSRQ: -16,-19,LTE

OK
```

5.9 AT+QSINR Report SINR

The command queries and reports the SINR of the current service network.

AT+QSINR Report SINR	
Test Command **AT+QSINR=?**	Response **OK**
Read Command **AT+QSINR?**	Response **+QSINR: <PRX>,<DRX>,<sysmode>** **OK**
Execution Command **AT+QSINR**	Response **+QSINR: <PRX>,<DRX>,<sysmode>** **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<PRX>	Integer type. PRX path SINR value. Range: -20 to 30 dB in LTE, -23 to 40 dB in NR5G.	
<DRX>	Integer type. DRX path SINR value. Range: -20 to 30 dB in LTE, -23 to 40 dB in NR5G.	
<sysmode>	String type. It indicates the service mode in which the MT will report the SINR.	
	LTE	LTE mode
	NR5G	NR5G mode

NOTE

1. If the queried **<PRX>** or **<DRX>** is -32768, it indicates that the SINR value is invalid.
2. This command is strongly related to the RF link and is generally only used for customer reference and cannot be used as a sensitivity test. In addition, it is best to use it when measuring the speed. The results are more accurate.

Example

```
AT+QSINR                    //Query SINR.
+QSINR: -3,-7,LTE

OK
```

5.10 AT+QRSSI Report RSSI

The command queries and reports the RSSI of the current service network.

AT+QRSSI Report RSSI	
Test Command **AT+QRSSI=?**	Response **OK**
Execution Command **AT+QRSSI**	Response **+QRSSI: <PRX>,<DRX>,<sysmode>** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<PRX>	Integer type. PRX path RSSI value. Unit: dBm.
<DRX>	Integer type. DRX path RSSI value. Unit: dBm.
<sysmode>	String type without double quotes. Service mode in which the MT reports the RSSI. LTE LTE mode NR5G NR5G mode

NOTE

1. If the queried **<PRX>** or **<DRX>** is -32768, it indicates that the RSSI value is invalid.
2. This command is strongly related to the RF link and is generally only used for customer reference and cannot be used as a sensitivity test. In addition, it is best to use it when measuring the speed. The results are more accurate.

Example

```
AT+QRSSI                    //Query RSSI.
+QRSSI: -42,-56,NR5G

OK
```

5.11 AT+CPOL Preferred Operator List

This command edits and queries the list of preferred operators.

AT+CPOL Preferred Operator List	
Test Command **AT+CPOL=?**	Response **+CPOL: (**list of supported **<index>**s**),(**list of supported **<format>**s**)** **OK**
Read Command Query the list of preferred operators: **AT+CPOL?**	Response **+CPOL: <index>,<format>,<oper>[,<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>,<NG-RAN>]** **[…]** **OK**
Write Command Edit the list of preferred operators: **AT+CPOL=<index>[,<format>[,<oper>[<GSM>,<GSM_compact>,<UTRAN>,<E-UTRAN>,<NG-RAN>]]]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>** If **<index>** is given but **<oper>** is omitted, the entry is deleted.
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<index>	Integer type. Order number of the operators in the (U)SIM preferred operator list.
<format>	Integer type. Format of operator name. 0 Long format alphanumeric **<oper>** 1 Short format alphanumeric **<oper>** 2 Numeric **<oper>**
<oper>	String type. Operator name. **<format>** indicates the format is alphanumeric or numeric (see **AT+COPS**).
<GSM>	Integer type. GSM access technology selection. 0 Not selected 1 Selected

<GSM_compact>	Integer type. GSM compact access technology selection. 0 Not selected 1 Selected
<UTRAN>	Integer type. UTRAN access technology selection. 0 Not selected 1 Selected
<E-UTRAN>	Integer type. E-UTRAN access technology selection. 0 Not selected 1 Selected
<NG-RAN>	Integer type. NG-RAN access technology selection. 0 Not selected 1 Selected
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

The access technology selection parameters **<GSM>**, **<GSM_compact>**, **<UTRAN>** and **<E-UTRAN>** are required for (U)SIM cards or UICC's containing PLMN selector with access technology.

5.12 AT+CTZU Automatic Time Zone Update

This command enables or disables automatic time zone update via NITZ.

AT+CTZU Automatic Time Zone Update	
Test Command **AT+CTZU=?**	Response **+CTZU: (**list of supported **<onoff>**s**)** **OK**
Write Command **AT+CTZU=<onoff>**	Response **OK** Or **ERROR**
Read Command **AT+CTZU?**	Response **+CTZU: <onoff>** **OK**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<onoff>	Integer type. Enable or disable automatic time zone update. 0 Disable 1 Enable

NOTE

Executing **AT+CTZU=<onoff>** writes data to NVM. Please proceed with caution.

Example

```
AT+CTZU?                //Read command.
+CTZU: 0

OK
AT+CTZU=?               //Test command.
+CTZU: (0,1)

OK
AT+CTZU=1               //Enable automatic time zone update.
OK
AT+CTZU?
+CTZU: 1

OK
```

5.13 AT+CTZR Time Zone Reporting

This command controls time zone change event reporting. If reporting is enabled, MT returns URC **+CTZV: <tz>** or **+CTZE: <tz>,<dst>,[<time>]** whenever the time zone is changed.

AT+CTZR Time Zone Reporting	
Test Command **AT+CTZR=?**	Response **+CTZR: (**list of supported **<reporting>**s**)** **OK**
Read Command **AT+CTZR?**	Response **+CTZR: <reporting>** **OK**

Write Command **AT+CTZR=<reporting>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.
Reference	*3GPP TS 27.007*

Parameter

<reporting>	Integer type. Disable or enable time zone reporting. 0 Disable 1 Enable time zone change event reporting by URC **+CTZV: <tz>** 2 Enable extended time zone change event reporting by URC **+CTZE: <tz>,<dst>,[<time>]**
<tz>	String type. Sum of local time zone and daylight saving time (difference between local time and GMT is expressed in quarter(s) of an hour). Format: "±zz", where "zz" is a fixed width, two-digit integer with the range -48 to +56. To maintain a fixed width, numbers in range -9 to +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09".
<dst>	Integer type. It indicates whether **<tz>** includes daylight saving time adjustment. 0 **<tz>** does not include adjustment for daylight saving time 1 **<tz>** includes +1 hour adjustment (equivalent to 4 quarters in **<tz>**) for daylight saving time 2 **<tz>** includes +2 hours adjustment (equivalent to 8 quarters in **<tz>**) for daylight saving time
<time>	String type. Local time. Format: "YYYY/MM/DD,hh:mm:ss", expressed as integers representing year (YYYY), month (MM), date (DD), hour (hh), minute (mm) and second (ss). This parameter can be provided by the network when delivering time zone information and will be presented in URC of extended time zone change event reporting if provided by the network.

NOTE

Executing **AT+CTZR=<reportging>** writes data to NVM. Please proceed with caution.

Example

```
AT+CTZR=2
OK
AT+CTZR?
+CTZR: 2
```

OK

+CTZE: "+32",0,"2018/03/23,06:51:13" //Extended time zone and local time reporting by URC.

5.14 AT+QLTS Query Latest Time Synchronized Through Network

The Execution Command returns the latest time synchronized through the network.

AT+QLTS Query Latest Time Synchronized Through Network	
Test Command **AT+QLTS=?**	Response **+QLTS: (**list of supported **<mode>**s**)** **OK**
Write Command **AT+QLTS=<mode>**	Response **+QLTS: <time>,<ds>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Execution Command **AT+QLTS**	Response **+QLTS: <time>,<ds>** **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<mode>	Integer type. Query network time mode.	
	0	Query the latest time that has been synchronized through network
	1	Query the current GMT time calculated from the latest time that has been synchronized through network
	2	Query the current local time calculated from the latest time that has been

	synchronized through network
<time>	String type. Format is "YYYY/MM/DD,hh:mm:ss±zz", where characters represent year (two last digits), month, day, hour, minutes, seconds and time zone (indicates the difference, expressed in quarter(s) of an hour, between the local time and GMT; range: -48 to +48). E.g. 6th of May 2004, 22:10:00 GMT+2 hours equals "04/05/06,22:10:00+08".
<ds>	Integer type. Daylight saving time. 0 No adjustment 1 Plus one hour 2 Plus two hours
<err>	Error codes.. For more details, see ***Chapter 13.5***.

NOTE

If the time has not been synchronized through network, the command returns **+QLTS: ""**.

Example

```
AT+QLTS=?                   //Query supported network time modes.
+QLTS: (0-2)

OK
AT+QLTS                     //Query the latest time synchronized through network.
+QLTS: "2017/01/13,03:40:48+32,0"

OK
AT+QLTS=0                   //Query the latest time synchronized through network. It offers the same
                              function as Execution Command AT+QLTS.
+QLTS: "2017/01/13,03:40:48+32,0"

OK
AT+QLTS=1                   //Query the current GMT time calculated from the latest time that has been
                              synchronized through network.
+QLTS: "2017/01/13,03:41:22+32,0"

OK
AT+QLTS=2                   //Query the current LOCAL time calculated from the latest time that has been
                              synchronized through network.
+QLTS: "2017/01/13,11:41:23+32,0"

OK
```

5.15 AT+QENG Query Primary Serving Cell and Neighbour Cell Information

This command obtains the network information, such as serving cell and neighbour cells.

AT+QENG Query Primary Serving Cell and Neighbour Cell Information	
Test Command **AT+QENG=?**	Response **+QENG: (**list of supported **<cell_type>**s**)** **OK**
Write Command Query the serving cell information **AT+QENG="servingcell"**	Response In SA mode: **+QENG: "servingcell",<state>,"NR5G-SA",<duplex_mode>,<MCC>,<MNC>,<cellID>,<PCID>,<TAC>,<ARFCN>,<band>,<NR_DL_bandwidth>,<RSRP>,<RSRQ>,<SINR>,<scs>,<srxlev>** **OK** In LTE mode: **+QENG: "servingcell",<state>,"LTE",<is_tdd>,<MCC>,<MNC>,<cellID>,<PCID>,<earfcn>,<freq_band_ind>,<UL_bandwidth>,<DL_bandwidth>,<TAC>,<RSRP>,<RSRQ>,<RSSI>,<SINR>,<CQI>,<tx_power>,<srxlev>** **OK**
Write Command Query the information of neighbour cells **AT+QENG="neighbourcell"**	Response In LTE mode: **[+QENG: "neighbourcell intra","LTE",<earfcn>,<PCID>,<RSRQ>,<RSRP>,<RSSI>,<SINR>,<srxlev>,<cell_resel_priority>,<s_non_intra_search>,<thresh_serving_low>,<s_intra_search>]** **[…]** **[+QENG: "neighbourcell inter","LTE",<earfcn>,<PCID>,<RSRQ>,<RSRP>,<RSSI>,<SINR>,<srxlev>,<cell_resel_priority>,<threshX_low>,<threshX_high>]** **[…]** **OK** If there is any error: **ERROR**

Maximum Response Time	300 ms
Characteristics	-

Parameter

<cell_type>	String type. Information of different cells. "servingcell" Information of 4G/5G serving cells "neighbourcell" Information of 4G neighbor cells
<state>	String type. UE state. "SEARCH" UE is searching but cannot (yet) find a suitable 4G/5G cell. "LIMSRV" UE is camping on a cell but has not registered on the network. "NOCONN" UE is camping on a cell and has registered on the network, and it is in idle mode. "CONNECT" UE is camping on a cell and has registered on the network, and a call is in progress.
<duplex_mode>	String type. NR5G SA network mode. "TDD" "FDD"
<MCC>	16-bit unsigned integer. Mobile Country Code (first part of the PLMN code).
<MNC>	16-bit unsigned integer. Mobile Network Code (second part of the PLMN code).
<cellID>	Integer type. Cell ID. 28-bit (UMTS, LTE) or 36-bit (NR5G) cell ID. Range: 0–0xFFFFFFFFF.
<PCID>	Integer type. Physical cell ID.
<TAC>	String type. Two-byte tracking area code for LTE or three-byte tracking area code for 5G SA in hexadecimal format without double quotes (see *3GPP 23.003 Section 19.4.2.3*).
<ARFCN>	Integer type. SA-ARFCN of the scanned cell.
<band>	32-bit unsigned integer. Frequency band in NR5G SA network mode.
<NR_DL_bandwidth>	Integer type. DL bandwidth. It is only valid in RRC connected state. 0 5 MHz 1 10 MHz 2 15 MHz 3 20 MHz
<RSRP>	16-bit signed integer. In LTE mode: It indicates the signal of LTE Reference Signal Received Power (see *3GPP 36.214*). Range: -140 to -44 dBm. A value closer to -44 indicates a stronger signal, whereas the value closer to -140 indicates a weaker signal. In NR5G mode: It indicates the signal of NR5G Reference Signal Received Power. Range: -140 to -44 dBm. A value closer to -44 indicates a stronger signal, whereas the value closer to -140 indicates a weaker signal.

<RSRQ>	16-bit signed integer. In LTE mode: It indicates the signal of current LTE Reference Signal Received Quality (see *3GPP 36.214*). Range: -20 to -3 dB. A value closer to -3 indicates a stronger signal, whereas the value closer to -20 indicates a weaker signal. In NR5G mode: It indicates the signal of current NR5G Reference Signal Received Quality. Range: -20 to -3 dB. A value closer to -3 indicates a stronger signal, whereas the value closer to -20 indicates a weaker signal.
<SINR>	16-bit signed integer. In LTE mode: It indicates LTE Signal-to-Interface plus Noise Ratio. The conversion formula for actual SINR is **Y** = (**1/5**) × **X** × **10** - **20** (**X** is the **<SINR>** value queried by **AT+QENG** and **Y** is the actual value of LTE SINR after calculating with the formula). Range: -20 to 30 dB. In NR5G mode: It indicates the signal of NR5G Signal-to-Interface plus Noise Ratio. Range: -23 to 40 dB.
<scs>	Integer type. NR sub-carrier space. 0 15 kHz 1 30 kHz
<srxlev>	Integer type. Select reception level value for base station in dB.
<is_tdd>	String type. LTE network mode. "TDD" "FDD"
<earfcn>	Integer type. E-UTRA-ARFCN of the scanned cell.
<freq_band_ind>	Integer type. E-UTRA frequency band (see *3GPP 36.101*).
<UL_bandwidth>	Integer type. UL bandwidth. 0 1.4 MHz 1 3 MHz 2 5 MHz 3 10 MHz 4 15 MHz 5 20 MHz
<DL_bandwidth>	Integer type. DL bandwidth. 0 1.4 MHz 1 3 MHz 2 5 MHz 3 10 MHz 4 15 MHz 5 20 MHz
<RSSI>	Integer type. LTE Received Signal Strength Indication.
<CQI>	Integer type. Channel Quality Indication. Range: 1–30.
<tx_power>	Integer type. TX power value in 1/10 dBm. It is the maximum of all UL

	channel TX power. **<tx_power>** is only meaningful when the device is in traffic.
<cell_resel_priority>	Integer type. Cell reselection priority. Range: 0–7.
<s_non_intra_search>	Integer type. Threshold to control non-intra frequency searches.
<thresh_serving_low>	Integer type. It specifies the suitable reception level threshold (in dB) used by the UE on the serving cell when reselecting towards a lower priority RAT/frequency.
<s_intra_search>	Integer type. Cell selection parameter for the intra frequency cell.
<threshX_low>	Integer type. To be considered for re-selection. Suitable receive level value of an evaluated lower priority cell must be greater than this value.
<threshX_high>	Integer type. To be considered for re-selection. Suitable receive level value of an evaluated higher priority cell must be greater than this value.

NOTE

"-" or - indicates the parameter is invalid under current condition.

Example

```
//Query the serving cell information when the module is in LTE mode.
AT+QENG="servingcell"
+QENG:  "servingcell","NOCONN","LTE","FDD",460,01,5F1EA15,12,1650,3,5,5,DE10,-100,-12,-68,11,0,-32768,27

OK
//Query the serving cell information when the module is in NR 5G SA mode.
AT+QENG="servingcell"
+QENG:  "servingcell","NOCONN","NR5G-SA","FDD",460,00,175E7B001,424,46550B,152650,28,1,-112,-13,0,0,7

OK
//Query the neighbour cell information when the module is in LTE mode.
AT+QENG="neighbourcell"
+QENG: "neighbourcell intra","LTE",38950,276,-3,-88,-65,0,37,7,16,6,44
+QENG: "neighbourcell inter","LTE",39148,-,-,-,-,-,37,0,30,7
+QENG: "neighbourcell inter","LTE",37900,-,-,-,-,-,0,0,30,6

OK
```

5.16 AT+QNWCFG Configure and Query Network Parameters

This command configures and queries network parameters.

AT+QNWCFG Configure and Query Network Parameters	
Test Command **AT+QNWCFG=?**	Response **+QNWCFG: "lte_cell_id"** **+QNWCFG: "nr5g_cell_id"** **+QNWCFG: "data_roaming",(**list of supported **<data_roaming>**s**)** **+QNWCFG: "hplmn_search_timer",(**list of supported **<timer_value>**s**)** **+QNWCFG: "lte_cdrx",(**list of supported **<short_drx_enable>**s**),(**list of supported **<long_drx_enable>**s**)** **+QNWCFG: "nr5g_cdrx",(**list of supported **<short_drx_enable>**s**),(**list of supported **<long_drx_enable>**s**)** **…** **OK**
Maximum Response Time	300 ms
Characteristics	-

5.16.1 AT+QNWCFG="lte_cell_id" Read Cell ID Under LTE

This command reads ECGI, ECI, eNodeB ID under LTE.

AT+QNWCFG="lte_cell_id" Read Cell ID Under LTE	
Write Command **AT+QNWCFG="lte_cell_id"**	Response **[+QNWCFG: "lte_cell_id",<ECGI>,<ECI>,<eNodeB_ID>]** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<ECGI>	Integer type. E-UTRAN Cell Global Identifier in hexadecimal format (MCC + MNC + ECI).
<ECI>	Integer type. E-UTRAN Cell Identity in hexadecimal format (eNodeB ID + cell ID).

<eNodeB_ID>	Integer type. LTE base station ID in hexadecimal format.

Example

```
AT+QNWCFG="lte_cell_id"                    //Read Cell ID under LTE.
+QNWCFG: "lte_cell_id",64F0000D6B5C0,0D6B5C0,0D6B5

OK
AT+QNWCFG="lte_cell_id"                    //Read Cell ID under non-LTE mode.
OK
```

5.16.2 AT+QNWCFG="nr5g_cell_id" Read Cell ID Under NR5G SA

This command reads the NCGI, NCI, NR5G base station ID under 5G SA.

AT+QNWCFG="nr5g_cell_id" Read Cell ID Under NR5G SA	
Write Command **AT+QNWCFG="nr5g_cell_id"**	Response **[+QNWCFG: "nr5g_cell_id",<NCGI>,<NCI>,<gNodeB_ID>]** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<NCGI>	Integer type. NR Cell Global Identification in hexadecimal format (MCC + MNC + NCI).
<NCI>	Integer type. NR Cell Identification in hexadecimal format (gNodeB ID + cell ID).
<gNodeB_ID>	Integer type. NR5G base station ID in hexadecimal format.

Example

```
AT+QNWCFG="nr5g_cell_id"                   //Read Cell ID under NR5G SA.
+QNWCFG: "nr5g_cell_id",64F000170C23000,170C23000,170C23

OK
AT+QNWCFG="nr5g_cell_id"                   //Read Cell ID under non-NR5G SA.
OK
```

5.16.3 AT+QNWCFG="data_roaming " Control Data Roaming

This command controls the data roaming preference.

AT+QNWCFG="data_roaming" Control Data Roaming	
Write Command **AT+QNWCFG="data_roaming"[,<data_roaming>]**	Response If the optional parameter is omitted, query the current setting. **+QNWCFG: "data_roaming",<data_roaming>** **OK** If the optional parameter is specified, enable or disable data roaming. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<data_roaming>	Integer Type. Preference of data roaming.	
	0	On
	1	Off

Example

```
AT+QNWCFG="data_roaming"
+QNWCFG: "data_roaming",1

OK
AT+QNWCFG="data_roaming",0
OK
```

5.16.4 AT+QNWCFG="hplmn_search_timer" Set Higher Priority PLMN Search Timer

This command sets the higher priority PLMN search timer.

AT+QNWCFG="hplmn_search_timer" Set Higher Priority PLMN Search Timer	
Write Command **AT+QNWCFG="hplmn_search_timer"**	Response If the optional parameter is omitted, query the current setting.

[,<timer_value>]	**+QNWCFG: "hplmn_search_timer",<timer_value>** **OK** If the optional parameter is specified, set the higher priority PLMN search timer. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. This configuration is not saved.

Parameter

<timer_value>	Integer type. The higher priority PLMN search timer. Range: 0–1530. Unit: minute. When the value is 0, it indicates no higher priority PLMN search attempts (The higher priority PLMN search timer is turned off).

Example

```
AT+QNWCFG="hplmn_search_timer"
+QNWCFG: "hplmn_search_timer",480

OK
AT+QNWCFG="hplmn_search_timer",100
OK
```

5.16.5 AT+QNWCFG="lte_cdrx" Enable/Disable CDRX Function Under LTE

This command enables or disables CDRX function under LTE.

AT+QNWCFG="lte_cdrx" Enable/Disable CDRX Function Under LTE	
Write Command **AT+QNWCFG="lte_cdrx"[,<short_drx_enable>,<long_drx_enable>]**	Response If the optional parameters are omitted, query the current setting. **+QNWCFG: "lte_cdrx",<short_cdrx_enable>,<long_cdrx_enable>** **OK** If the optional parameters are specified, enable or disable

	CDRX function under LTE. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configurations are saved automatically.

Parameter

<short_cdrx_enable>	Integer type. Enable or disable short CDRX function. 0 Disable 1 Enable
<long_cdrx_enable>	Integer type. Enable or disable long CDRX function. 0 Disable 1 Enable

Example

```
AT+QNWCFG="lte_cdrx"                //Query the current configuration.
+QNWCFG: "lte_cdrx",1,1

OK
AT+QNWCFG="lte_cdrx",1,1            /Enable CDRX function.
OK
```

5.16.6 AT+QNWCFG="nr5g_cdrx" Enable/Disable CDRX Function Under 5G

This command enables or disables CDRX function under 5G.

AT+QNWCFG="nr5g_cdrx" Enable/Disable CDRX Function Under 5G	
Write Command **AT+QNWCFG="nr5g_cdrx"[,<short_drx_enable>,<long_drx_enable>]**	Response If the optional parameter is omitted, query the current setting. **+QNWCFG: "nr5g_cdrx",<short_cdrx_enable>,<long_cdrx_enable>** **OK** If the optional parameter is specified, enable or disable CDRX function under 5G.

	OK If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect after the module is rebooted. The configuration is saved automatically.

Parameter

<short_cdrx_enable>	Integer type. Enable or disable short CDRX function. 0 Disable 1 Enable
<long_cdrx_enable>	Integer type. Enable or disable long CDRX function. 0 Disable 1 Enable

Example

```
AT+QNWCFG="nr5g_cdrx"                  //Query the current configuration.
+QNWCFG: "nr5g_cdrx",1,1

OK
AT+QNWCFG="nr5g_cdrx",1,1              //Enable CDRX function.
OK
```

5.17 AT+QNWPREFCFG Configure Network Searching Preferences

This command configures the network searching preferences.

AT+QNWPREFCFG Configure Network Searching Preferences	
Test Command **AT+QNWPREFCFG=?**	Response **+QNWPREFCFG: "lte_band",(**list of supported **<LTE_band>**s**)** **+QNWPREFCFG: "nr5g_band",(**list of supported **<SA_NR5G_band>**s**)** **+QNWPREFCFG: "mode_pref",(**list of supported **<mode_pref>**s**)** **+QNWPREFCFG: "ue_usage_setting",(**list of supported **<setting>**s**)** **+QNWPREFCFG: "policy_band"**

	+QNWPREFCFG: "ue_capability_band" **+QNWPREFCFG: "policy_mode** **OK**
Maximum Response Time	300 ms
Characteristics	-

5.17.1 AT+QNWPREFCFG="lte_band" Set LTE Band

This command specifies the preferred LTE bands to be searched by UE.

AT+QNWPREFCFG="lte_band" Set LTE Band	
Write Command **AT+QNWPREFCFG="lte_band"[,<LTE_band>]**	Response If the optional parameter is omitted, query the current setting. **+QNWPREFCFG: "lte_band",<LTE_band>** **OK** If the optional parameter is specified, configure the preferred LTE bands to be searched. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<LTE_band>	String type. LTE bands to be configured. Format: **<band1>**:**<band2>**:…:**<band*x*>**.
<band>	Integer type. LTE bands supported by the module.

NOTE

1. See the specific module specification for the bands that are supported.
2. When the module locks to LTE, an error is reported if **<LTE_band>** is set to null.
3. Executing **AT+QNWPREFCFG="lte_band",<LTE_band>** writes data to NVM. Please proceed with caution.

Example

```
AT+QNWPREFCFG="lte_band"          //Query the currently configured LTE bands of the UE.
+QNWPREFCFG:  "lte_band",1:2:3:4:5:7:8:11:12:13:14:17:18:19:20:21:25:26:28:30:34:38:39:40:41:
42:43:48:66:71

OK
AT+QNWPREFCFG="lte_band",1:2      //Set LTE B1 and LTE B2.
OK
```

5.17.2 AT+QNWPREFCFG="nr5g_band" Set NR5G SA Band

This command specifies the preferred NR5G SA bands to be searched by UE.

AT+QNWPREFCFG="nr5g_band" Set NR5G SA Band	
Write Command **AT+QNWPREFCFG="nr5g_band"[,<SA_NR5G_band>]**	Response If the optional parameter is omitted, query the current setting. **+QNWPREFCFG: "nr5g_band",<SA_NR5G_band>** **OK** If the optional parameter is specified, configure the preferred NR5G SA bands to be searched. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<SA_NR5G_band>	String type. NR5G SA bands to be configured. Format: **<SA_band1>**:**<SA_band2>**:…:**<SA_band*x*>**.
<SA_band>	Integer type. NR5G SA bands supported by the module.

NOTE

1. See the specific module specification for the bands that are supported.
2. When the module locks to NR5G SA, an error is reported if **<SA_NR5G_band>** is set to null.
3. Executing **AT+QNWPREFCFG="nr5g_band",<SA_NR5G_band>** writes data to NVM. Please proceed with caution.

Example

```
AT+QNWPREFCFG="nr5g_band"       //Query the currently configured NR5G SA bands of the UE.
+QNWPREFCFG: "nr5g_band",1:3:7:20:28:40:41:71:77:78:79

OK
AT+QNWPREFCFG="nr5g_band",1:2  //Set NR5G SA n1 and NR5G SA n2.
OK
```

5.17.3 AT+QNWPREFCFG="mode_pref" Set Network Search Mode

This command specifies the network search mode.

AT+QNWPREFCFG="mode_pref" Set Network Search Mode	
Write Command **AT+QNWPREFCFG="mode_pref"[,<mode_pref>]**	Response If the optional parameter is omitted, query the current setting. **+QNWPREFCFG: "mode_pref",<mode_pref>** **OK** If the optional parameter is specified, set the network search mode. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<mode_pref>	String type without double quotes. RATs to be configured. Format: **<RAT1>:<RAT2>:…:<RAT*x*>**. RATs supported:	
	AUTO	LTE & NR5G
	LTE	LTE only
	NR5G	NR5G only

NOTE

Executing **AT+QNWPREFCFG="mode_pref",<mode_pref>** writes data to NVM. Please proceed with caution.

Example

```
AT+QNWPREFCFG="mode_pref"                 //Query the current setting.
+QNWPREFCFG: "mode_pref",AUTO

OK
AT+QNWPREFCFG="mode_pref",LTE             //Set RAT to LTE only.
OK
AT+QNWPREFCFG="mode_pref",LTE:NR5G        //Set RAT to LTE & NR5G.
OK
```

5.17.4 AT+QNWPREFCFG="ue_usage_setting" Set UE Usage Setting

This command specifies the usage setting of UE.

AT+QNWPREFCFG="ue_usage_setting" Set UE Usage Setting	
Write Command **AT+QNWPREFCFG="ue_usage_setting"[,<setting>]**	Response If the optional parameter is omitted, query the current setting. **+QNWPREFCFG: "ue_usage_setting",<setting>** **OK** If the optional parameter is specified, set the usage setting of UE. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<setting >	Integer type. Usage setting of UE.	
	0	Voice centric
	1	Data centric

NOTE

Executing **AT+QNWPREFCFG="ue_usage_setting",<setting>** writes data to NVM. Please proceed with caution.

Example

```
AT+QNWPREFCFG="ue_usage_setting"          //Query the current setting.
+QNWPREFCFG: "ue_usage_setting",1

OK
AT+QNWPREFCFG="ue_usage_setting",0        //Set voice centric.
OK
```

5.17.5 AT+QNWPREFCFG="policy_band" Read Carrier Policy Band

This command reads the band configured in the carrier policy.

AT+QNWPREFCFG="policy_band"	Read Carrier Policy Band
Write Command **AT+QNWPREFCFG="policy_band"**	Response **+QNWPREFCFG: "lte_band",<LTE_band>** **+QNWPREFCFG: "nr5g_band",<NR5G_band>** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<LTE_band>	String type. LTE bands to be configured. Format: **<band1>**:**<band2>**:…:**<band*x*>**.
<band>	Integer type. LTE bands supported by the module.
<NR5G_band>	String type. NR5G SA bands to be configured. Format: **<SA_band1>**:**<SA_band2>**:…:**<SA_band*x*>**
<SA_band>	Integer type. NR5G SA bands supported by the module .

NOTE

See the specific module specification for the bands supported.

Example

```
AT+QNWPREFCFG="policy_band"
+QNWPREFCFG: "lte_band",1:3:8
+QNWPREFCFG: "nr5g_band",78

OK
```

5.17.6 AT+QNWPREFCFG="ue_capability_band" Query UE Band Capability

This command queries the band configured in the UE capability.

AT+QNWPREFCFG="ue_capability_band" Query UE Band Capability	
Write Command **AT+QNWPREFCFG="ue_capability_band"**	Response **+QNWPREFCFG: "lte_band",<LTE_band>** **+QNWPREFCFG: "nr5g_band",<NR5G_band>** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<LTE_band>	String type. LTE bands to be configured. Format: **<band1>**:**<band2>**:…:**<band*x*>**.
<band>	Integer type. LTE bands supported by the module.
<NR5G_band>	String type. NR5G SA bands to be configured. Format: **<SA_band1>**:**<SA_band2>**:…:**<SA_band*x*>**
<SA_band>	Integer type. NR5G SA band supported by the module.

NOTE

See the specific module specification for the bands supported.

Example

```
AT+QNWPREFCFG="ue_capability_band"
+QNWPREFCFG: "lte_band",1:3:8
+QNWPREFCFG: "nr5g_band",78

OK
```

5.17.7 AT+QNWPREFCFG="policy_mode" Read Carrier Policy Mode

This command reads the carrier policy mode.

AT+QNWPREFCFG="policy_mode" Read Carrier Policy Mode	
Write Command **AT+QNWPREFCFG="policy_mode"**	Response **+QNWPREFCFG: "policy_mode",<curr_mcc>,<mode>**

	OK
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.

Parameter

<cur_mcc>	Integer type. The MCC of the cell currently registered or searched.
<mode>	String type without double quotes. RATs to be supported. Format: **<RAT1>**:**<RAT2>**:…:**<RAT*x*>**. RATs supported: AUTO LTE & NR5G LTE LTE only NR5G NR5G only

Example

```
AT+QNWPREFCFG="policy_mode"
+QNWPREFCFG: "policy_mode",502,AUTO

OK
```

6 Call Related Commands

6.1 ATA Answer an Incoming Call

This command connects the MT to an incoming voice or data call indicated by a **RING** URC.

ATA Answer an Incoming Call	
Execution Command **ATA**	Response MT sends off-hook to the remote station. In case of a data call, if successfully connected: **CONNECT<text>** MT switches to data mode. **<text>** is output only when **<value>** of **ATX** is greater than 0. When MT returns to command mode after call release: **OK** In case of a voice call, if successfully connected: **OK** If no call connection, or the command was aborted by reception of an additional character: **NO CARRIER**
Maximum Response Time	90 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

NOTE

1. Any additional commands that appear after **ATA** on the same command line are ignored.
2. This command may be aborted when the module receives a character before it enters data mode. However, the command will not be aborted during some connection establishment processes such as handshaking.

Example

```
RING##0                                  //Incoming call.
AT+CLCC
+CLCC: 1,1,4,0,0,"02154450290",129       //Incoming call.

OK
ATA                                      //Answer a voice call with ATA.
OK
```

6.2 ATD Originate a Call

This command sets up an outgoing voice or a data call. Supplementary services can also be controlled with this command.

ATD Originate a Call	
Execution Command **ATD<n>[<mgsm>][;]**	Response If no dial tone and **ATX2** or **ATX4** is set: **NO DIAL TONE** If busy and **ATX3** or **ATX4** is set: **BUSY** If a call connection cannot be established, or the command was aborted by reception of an additional character: **NO CARRIER** If a call connection is established successfully and a non-voice call is to be set: **CONNECT<text>** MT switches to data mode. **<text>** is output only when **<value>** of **ATX** is greater than 0. When MT returns to command mode after call release: **OK** If a call connection is established successfully or a voice call is set up: **OK** If there is any error: **ERROR**
Maximum Response Time	5 s, determined by the network.

Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	String of dialing digits and optional V.25ter modifiers. Dialing digits: 0-9, *, #, +, A, B, C Following V.25ter, optional modifiers ,(comma), T, P, !, W, @ are ignored.
<mgsm>	String of GSM modifiers: I Activate CLIR (presentation of own number to the called party disabled) i Deactivate CLIR (presentation of own number to the called party enabled) G Activates CUG invocation for this call only g Deactivates CUG invocation for this call only
<;>	It is required when setting up a voice call, and MT will return to command state after call release.

NOTE

1. This command may be aborted during execution if the module receives an **ATH** command or a character. However, the command will not be aborted during certain connection establishments such as handshaking.
2. Parameters "**I**" and "**i**" of **<mgsm>** are only valid when **<n>** doesn't contain "*" or "#".
3. See **ATX** for result codes format setting and call monitoring parameters control.
4. For voice calls, if dialing with **ATD**, there are two possible response modes:
   MT returns **OK** immediately, either after dialing is completed or after the call is established. The mode is controlled by **AT+COLP**. By default, **AT+COLP=0** is set, causing the MT to return **OK** immediately after the dialing is completed. Otherwise, MT returns **BUSY**, **NO DIAL TONE**, or **NO CARRIER**.
5. Using **ATD** during an active voice call:
   - When a user originates a second voice call while an active voice call is in progress, the first call will be automatically put on hold.
   - The current states of all calls can be easily checked at any time with **AT+CLCC**.

Example

```
ATD10086;                    //Dial a number.
OK
```

6.3 ATH Disconnect Existing Connection

This command disconnects data calls or voice calls. **AT+CHUP** is also used for disconnecting voice call.

ATH Disconnect Existing Connection	
Execution Command **ATH[<n>]**	Response **OK**
Maximum Response Time	90 s, determined by the network.
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type.	
	0	Disconnect existing call from the command line and terminate the call in progress

6.4 AT+CVHU Control Voice Call Hang Up

This command controls whether **ATH** can be used to disconnect existing voice call.

AT+CVHU Control Voice Call Hang Up	
Test Command **AT+CVHU=?**	Response **+CVHU: (**list of supported **<mode>**s**)** **OK**
Read Command **AT+CVHU?**	Response **+CVHU: <mode>** **OK**
Write Command **AT+CVHU=<mode>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-

Reference	*3GPP TS 27.007*

Parameter

<mode>	Integer type. 0 **ATH** can be used to disconnect existing voice call 1 **ATH** is ignored with only the response **OK** returned

6.5 AT+CHUP Hang Up Voice Call

This command cancels any voice call in Active, Waiting and Held state. For data call hang up, use **ATH**.

AT+CHUP Hang Up Voice Call	
Test Command **AT+CHUP=?**	Response **OK**
Execution Command **AT+CHUP**	Response **OK** Or **ERROR**
Maximum Response Time	90 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

Example

RING##0	//Incoming call.
AT+CHUP	//Hang up the call.
OK	

6.6 ATS0 Set Ring Count Before Automatic Answering

This command controls automatic answering mode for incoming calls. If **<n>** is set to a non-zero value, the ME automatically answers after the call indication (**RING**) reaches the set number of rings.

ATS0 Set Ring Count Before Automatic Answering	
Read Command **ATS0?**	Response **<n>**

	OK
Write Command **ATS0=<n>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type.	
	0	Disable automatic answering
	1–255	Enable automatic answering on specified ring count

NOTE

If the value of **<n>** is set too large, the calling party may hang up before the call is answered automatically.

Example

```
ATS0=3                  //Set three rings before automatically answering a call.
OK

RING##0                 //Call coming.

RING##0

RING##0                 //Call is automatically answered after three rings.
```

6.7 ATS6 Set Pause Before Blind Dialing

This command is implemented for compatibility reasons only, and has no effect.

ATS6 Set Pause Before Blind Dialing	
Read Command **ATS6?**	Response **<n>**

	OK
Write Command **ATS6=<n>**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Number of seconds to wait before blind dialing. Range: 0–10. Default value: 2.

6.8 ATS7 Set Waiting Time for Connection Completion

This command specifies the duration (unit: second) to wait for the connection completion in case of answering or originating a call. If no connection is established during the time, MT will be disconnected.

ATS7 Set Waiting Time for Connection Completion	
Read Command **ATS7?**	Response **<n>** **OK**
Write Command **ATS7=<n>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type.	
	0	Disabled
	1–255	Waiting time in second(s) for connection completion

6.9 ATS8 Set Waiting Time for Comma Dial Modifier

This command is implemented for compatibility reasons only, and has no effect.

ATS8 Set Waiting Time for Comma Dial Modifier	
Read Command **ATS8?**	Response **<n>** **OK**
Write Command **ATS8=<n>**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type.	
	0	No pause when "," (comma) encountered in dial string
	1–2–255	Waiting time in second(s) for comma dial modifier

6.10 ATS10 Set Disconnection Delay After Indicating Data Carrier Absence

This command determines the duration (unit: tenths of a second) during which the UE remains connected when no data carrier is present. If the data carrier is detected again before disconnection, MT remains connected.

ATS10 Set Disconnection Delay After Indicating Data Carrier Absence	
Read Command **ATS10?**	Response **<n>** **OK**
Write Command **ATS10=<n>**	Response **OK**
Maximum Response Time	300 ms

Characteristics	-
Reference	*ITU-T Recommendation V.25 ter*

Parameter

<n>	Integer type. Time to wait before disconnecting after UE has indicated the absence of received line signal. Range: 1–254. Default value: 15. Unit: tenth(s) of second.

6.11 AT+CSTA Select Type of Address

This command selects the type of number for further dialing commands **ATD** according to *3GPP TS 24.008*. The Test Command returns supported values as a compound value.

AT+CSTA Select Type of Address	
Test Command **AT+CSTA=?**	Response **+CSTA: (**list of supported **<type>**s**)** **OK**
Read Command **AT+CSTA?**	Response **+CSTA: <type>** **OK**
Write Command **AT+CSTA=[<type>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<type>	Integer type. Current address type setting.	
	129	Unknown type
	145	International type (contains the character "+")

6.12 AT+CLCC List Current Call of MT

This command returns the list of all current call(s). If the command is executed successfully, but there is no active call, no information will be provided in the response, and only **OK** will be sent to TE.

AT+CLCC List Current Call of MT	
Test Command **AT+CLCC=?**	Response **OK**
Execution Command **AT+CLCC**	Response **[+CLCC: <id1>,<dir>,<stat>,<mode>,<mpty>[,<number>,<type>[,<alpha>]]]** **[...]** **OK** If there is any error related to MT functionality: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<id>	Integer type. Call identification number as described in *3GPP TS 22.030*, which can be used in **AT+CHLD** operation.
<dir>	Integer type. 0 Mobile originated (MO) call 1 Mobile terminated (MT) call
<stat>	Integer type. State of the call. 0 Active 1 Held 2 Dialing (MO call) 3 Alerting (MO call) 4 Incoming (MT call) 5 Waiting (MT call)
<mode>	Integer type. Bearer/teleservice. 0 Voice 1 Data 2 Fax
<mpty>	Integer type. 0 Call is not a part of a multiparty (conference) call

	1 Call is a part of a multiparty (conference) call
<number>	String type. Phone number. Format specified by **<type>**.
<type>	Integer type. Octet address type (See *3GPP TS 24.008 subclause 10.5.4.7* for details). 129 Unknown type 145 International type (contains the character "+") 161 National type
<alpha>	String type. Alphanumeric representation for **<number>** corresponding to the entry found in phonebook.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
ATD10086;                                   //Dial a number.
OK
AT+CLCC
+CLCC: 1,0,0,0,0,"10086",129                //Established a call, and the call has been answered.

OK
```

6.13 AT+CRC Set Extended Format of Incoming Call Indication

This command controls whether to use the extended format of incoming call indication or not. When it is enabled, an incoming call is indicated to TE with URC **+CRING: <type>** instead of the usual **RING** notification.

AT+CRC Set Extended Format of Incoming Call Indication	
Test Command **AT+CRC=?**	Response **+CRC: (**list of supported **<mode>**s**)** **OK**
Read Command **AT+CRC?**	Response **+CRC: <mode>** **OK**
Write Command **AT+CRC=[<mode>]**	Response **OK**
Maximum Response Time	300 ms
Characteristics	This command takes effect immediately. The configuration is not saved.
Reference	*3GPP TS 27.007*

Parameter

<mode>	Integer type. Enables or disables the extended format of incoming call URC **+CRING: <type>**	
	0	Disable
	1	Enable
<type>	String type.	
	ASYNC	Asynchronous transparent
	SYNC	Synchronous transparent
	REL ASYNC	Asynchronous non-transparent
	REL SYNC	Synchronous non-transparent
	FAX	Facsimile
	VOICE	Voice

Example

```
AT+CRC=1                          //Enable extended format.
OK

+CRING: VOICE##0                  //Indicate incoming call of voice type to TE.
ATH
OK
AT+CRC=0                          //Disable extended format.
OK

RING##0                           //Indicate incoming call to TE.
ATH
OK
```

6.14 AT+QECCNUM Configure Emergency Call Number

This command queries, adds and deletes emergency call number (ECC number).

AT+QECCNUM Configure Emergency Call Number	
Test Command **AT+QECCNUM=?**	Response **+QECCNUM: (**list of supported **<mode>**s**)** **OK**
Write Command **AT+QECCNUM=<mode>[,<type>[,<eccnum1>[,<eccnum2>[,…[,<eccnum**	Response If **<mode>**=0, **<type>** is specified and **<eccnum>** is omitted, query the current ECC number type.

n>]]]]]	**+QECCNUM: <type>,<eccnum1>,<eccnum2>[,…]** **OK** If **<mode>**=1, **<type>**=0 or 1, and at least one **<eccnumN>** is specified, add ECC number with (U)SIM card or without (U)SIM card. **OK** If **<mode>**=2, **<type>**=0 or 1, and at least one **<eccnum>** is specified, delete ECC number with (U)SIM card or E without (U)SIM card. **OK** If **<mode>**=3, and both **<type>** and **<eccnum>** are omitted, ECC number will be reset to default configuration, and the reset will take effect after the module is rebooted. **OK** If there is any error: **ERROR**
Write Command **AT+QECCNUM=<mode>[,<type>,<eccnum1>,<category>]**	Response If **<mode>**=4, **<type>**, **<eccnum>** and **<category>** are specified, add an ECC number with assigned category. **OK** If **<mode>**=5, **<type>**, **<eccnum>** and **<category>** are omitted, query all the ECC numbers and their categories. **+QECCNUM: 0,<eccnum1>,<category>[,…]** **+QECCNUM: 1,<eccnum1>,<category>[,…]** **+QECCNUM: 2,<eccnum1>,<category>[,…]** **+QECCNUM: 3,<eccnum1>,<category>[,…]** **OK** If there is any error: **ERROR**
Read Command **AT+QECCNUM?**	Response **+QECCNUM: 0,<eccnum1>,<eccnum2>[,…]** **+QECCNUM: 1,<eccnum1>,<eccnum2>[,…]** **OK**
Maximum Response Time	300 ms

Characteristics	-

Parameter

<mode>	Integer type. ECC number operation. 0 Query ECC number. 1 Add ECC number with default category (valid only when **<type>**=0 or 1). 2 Delete ECC number (valid only when **<type>**=0 or 1). 3 Reset ECC number. 4 Add ECC number with specified category (valid only when **<type>**=0 or 1). 5 Query all emergency call numbers and their categories.
<type>	Integer type. ECC number type. 0 ECC number stored in module without (U)SIM card 1 ECC number stored in module with (U)SIM card 2 ECC number from network 3 ECC number from (U)SIM card
<category>	Integer type. ECC number category. 0 Default 1 Police 2 Ambulance 4 Fire Brigade 8 Marine Guard 16 Mountain Rescue 32 manually initiated eCall 64 automatically initiated eCall
<eccnum>	String type. ECC number (e.g."110", "119").

NOTE

1. If a number to be added into the type of ECC numbers with (U)SIM card already exists in the module, and has been obtained from the network and the (U)SIM card, it cannot be added.
2. The priority for reading ECC number list: ECC number from the network > ECC number from the (U)SIM card> ECC number stored in the module with/without (U)SIM card.
3. Executing **AT+QECCNUM=<mode>[,<type>[,<eccnum1>[,<eccnum2>[,…[,<eccnum*n*>]]]]]** writes data to NVM. Please proceed with caution.
4. Executing **AT+QECCNUM=<mode>[,<type>,<eccnum1>,<category>]** writes data to NVM. Please proceed with caution.

Example

```
AT+QECCNUM=?                //Query the supported ECC number operation mode.
+QECCNUM: (0-5)
```

```
OK
AT+QECCNUM?                 //Query ECC numbers stored in module with or without (U)SIM card.
+QECCNUM: 0,"911","112","00","08","110","999","118","119"
+QECCNUM: 1,"911","112"

OK
AT+QECCNUM=0,1              //Query ECC numbers stored in module with (U)SIM card.
+QECCNUM: 1,"911","112"

OK
AT+QECCNUM=1,1,"110","234"
//Add "110" and "234" to ECC numbers stored in module with (U)SIM card.
OK
AT+QECCNUM=0,1              //Query the ECC numbers stored in module with (U)SIM card.
+QECCNUM: 1,"911","112","110","234"

OK
AT+QECCNUM=2,1,"110"
//Delete "110" from ECC numbers stored in module with (U)SIM card.
OK
AT+QECCNUM=0,1              //Query the ECC numbers stored in module with (U)SIM card.
+QECCNUM: 1,"911","112","234"

OK
AT+QECCNUM=5                //Query all emergency call numbers and corresponding category.
+QECCNUM: 0,"911",0,"112",0,"00",0,"08",0,"110",0,"999",0,"118",0,"119",0
+QECCNUM: 1,"911",0,"112",0,"234",0
+QECCNUM: 2,"110",1,"120",2,"119",4,"122",8,"999",16
+QECCNUM: 3,"112",0,"000",0,"08",0,"118",0,"122",0,"911",0,"999",0,"119",0,"120",0,"110",0

OK
AT+QECCNUM=4,1,"123",1
//Add ECC number "123" of the Police category into ECC numbers stored in module with (U)SIM card.
OK
AT+QECCNUM=5                //Query all emergency call numbers and corresponding category.
+QECCNUM: 0,"911",0,"112",0,"00",0,"08",0,"110",0,"999",0,"118",0,"119",0
+QECCNUM: 1,"911",0,"112",0,"234",0,"123",1
+QECCNUM: 2,"110",1,"120",2,"119",4,"122",8,"999",16
+QECCNUM: 3,"112",0,"000",0,"08",0,"118",0,"122",0,"911",0,"999",0,"119",0,"120",0,"110",0

OK
AT+QECCNUM=3                //Reset the ECC number list, and such reset will take effect after the
                              module is rebooted.
OK
```

6.15 AT^DSCI Indicate Call Status

This command indicates the call status.

AT^DSCI Indicate Call Status	
Test Command **AT^DSCI=?**	Response **^DSCI: (**list of supported **<n>**s**)** **OK**
Read Command **AT^DSCI?**	Response **^DSCI: <n>** **OK**
Write Command **AT^DSCI=[<n>]**	Response **OK**
Characteristics	-
Reference	-

Parameter

<n>	Integer type. Enable or disable the URC of DSCI. 0 Disable 1 Enable

NOTE

When the presentation of the DSCI at the TE is enabled, an URC is returned after the action:
^DSCI: <id>,<dir>,<stat>,<type>,<number>,<num_type>

Parameter

<id>	Integer type. Call ID.
<dir>	Integer type. Call direction. 0 Mobile originated call 1 Mobile terminated call
<stat>	Integer type. Call state. 1 CALL_LOCAL_HOLD 2 CALL_ORIGINAL 3 CALL_CONNECT 4 CALL_INCOMING 5 CALL_WAITING

	6 CALL_END 7 CALL_ALERTING 8 CALL_REMOTE_HOLD 9 CALL_BOTH_HOLD
<type>	Integer type. Call type. 0 Voice call 1 PS call
<number>	String type. Phone number.
<num_type>	Integer type. Octet address type (See *3GPP TS 24.008 subclause 10.5.4.7* for details). Values: 129 Unknown type 145 International type (contains the character "+") 161 National type

Example

```
//Dial a call.
AT^DSCI=1                          //Enable DSCI.
OK
ATD10086;                          //Dial a number.
OK

^DSCI: 1,0,2,0,10086,129           //A call is originated.

^DSCI: 1,0,7,0,10086,129           //The call is alerting.

^DSCI: 1,0,3,0,10086,129           //The call is connected.

ATH
OK

^DSCI: 1,0,6,0,10086,129           //The call is ended.

//Incoming call.
RING##0

^DSCI: 1,1,4,0,13022100000,129     //A call is coming.

RING##0

^DSCI: 1,1,6,0,13022100000,129     //The call is ended.

NO CARRIER
```

6.16 AT+VTS Generate DTMF Tone

This command sends ASCII characters which cause MSC to transmit DTMF tones to a remote subscriber. This command can only be operated in a voice call.

AT+VTS DTMF and Tone Generation	
Test Command **AT+VTS=?**	Response **+VTS: (**list of supported **<DTMF_string>**s**),(**list of supported **<duration>**s**)** **OK**
Write Command **AT+VTS=<DTMF_string>[,<duration>]**	Response **OK** If there is any error related to MT functionality: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	Determined by the length of **<DTMF_string>** and **<duration>**.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<DTMF_string>	String type. ASCII characters in the set 0-9, #, *, A, B, C, D. Maximal length: 31 bytes. When sending multiple tones at a time, the time interval of two tones can be specified by **AT+VTD**.
<duration>	Integer type. Tone duration in 1/10 seconds with tolerance. Range: 0–255. If the duration is less than the minimum time specified by the network, the actual duration will be the network specified time. If this parameter is omitted, **<duration>** is specified by **AT+VTD**.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
ATD12345678900;                 //Dial a number.
OK
//Call connected
AT+VTS="1"                      //The remote caller can hear the DTMF tone.
OK
AT+VTS="1234567890A"            //Send multiple tones at a time.
```

OK

6.17 AT+VTD Set DTMF Tone Duration

This command sets the duration of DTMF tones. It can also set time interval of two tones when sending multiple tones at a time.

AT+VTD Set DTMFTone Duration	
Test Command **AT+VTD=?**	Response **+VTD: (**list of supported **<duration>**s**),(**list of supported **<interval>**s**)** **OK**
Read Command **AT+VTD?**	Response **+VTD: <duration>,<interval>** **OK**
Write Command **AT+VTD=<duration>[,<interval>]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The parameters are not saved.
Reference	*3GPP TS 27.007*

Parameter

<duration>	Integer type. Tone duration in 1/10 seconds with tolerance. Range: 0–255. Default value: 3. If the duration is less than the minimum time specified by the network, the actual duration will be network specified time.
<interval>	Integer type. Time interval of two tones in 1/10 seconds when sending multiple tones at a time by **AT+VTS**. Range: 0–255. Default value: 0.
<err>	Error codes. For more details, see ***Chapter 13.5***.

7 Phonebook Commands

7.1 AT+CNUM Get Subscriber Number

This command gets the subscribers' own number(s) from the (U)SIM.

AT+CNUM Get Subscriber Number	
Test Command **AT+CNUM=?**	Response **OK**
Execution Command **AT+CNUM**	Response **[+CNUM: [<alpha>],<number>,<type>]** **[…]** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<alpha>	String type. Alphanumeric string associated with **<number>**. The used character set should be the one selected with **AT+CSCS**.
<number>	String type. Phone number of format specified by **<type>**.
<type>	Integer type. Octet address type (See *3GPP TS 24.008 subclause 10.5.4.7*). 129 Unknown type 145 International type (contains the character "+") 161 National type
<err>	Error codes. For more details, see *Chapter **13.5***.

8 Short Message Service Commands

8.1 AT+CSMS Select Message Service

This command selects message service and queries the type of message supported by MT.

AT+CSMS Select Message Service	
Test Command **AT+CSMS=?**	Response **+CSMS: (**list of supported **<service>**s**)** **OK**
Read Command **AT+CSMS?**	Response **+CSMS: <service>,<mt>,<mo>,<bm>** **OK**
Write Command **AT+CSMS=<service>**	Response **+CSMS: <mt>,<mo>,<bm>** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<service>	Integer type. Message service type. 0 See *3GPP TS 23.040* and *3GPP TS 23.041* (the syntax of SMS AT commands is compatible with *3GPP TS 27.005 Phase 2 version 4.7.0*; Phase 2+ features which do not require new command syntax can be supported, e.g. correct routing of

	messages with new Phase 2+ data coding schemes). 1 See *3GPP TS 23.040* and *3GPP TS 23.041* (the syntax of SMS AT commands is compatible with *3GPP TS 27.005 Phase 2+ version*; the requirement of **<service>** setting 1 is mentioned under corresponding command descriptions).
<mt>	Integer type. Mobile terminated message. 0 Type not supported 1 Type supported
<mo>	Integer type. Mobile originated message. 0 Type not supported 1 Type supported
<bm>	Integer type. Broadcast type message. 0 Type not supported 1 Type supported
<err>	Error codes. For more details, see ***Chapter 13.6***.

Example

```
AT+CSMS=?                          //Test command.
+CSMS: (0,1)

OK
AT+CSMS=1                          //Set message service type to 1.
+CSMS: 1,1,1

OK
AT+CSMS?                           //Read command.
+CSMS: 1,1,1,1

OK
```

8.2 AT+CMGF Set Message Format

This command specifies the input and output format of the short messages. **<mode>** indicates the format of messages used with message send, list, read and write commands and URCs resulting from received messages.

The format of messages can be either PDU mode (entire TP data units used) or text mode (headers and body of messages given as separate parameters). Text mode uses the value of **<chset>** specified by **AT+CSCS** to inform the character set to be used in the message body in the TA-TE interface.

AT+CMGF Set Message Format	
Test Command **AT+CMGF=?**	Response **+CMGF: (**list of supported **<mode>**s**)** **OK**
Read Command **AT+CMGF?**	Response **+CMGF: <mode>** **OK**
Write Command/Execution Command **AT+CMGF[=<mode>]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<mode>	Integer type. Short message input and output format. 0 PDU mode 1 Text mode

8.3 AT+CSCA Set Service Center Address

The Write Command updates the SMSC address through which mobile originated SMSs are transmitted. In text mode, the setting is used by Write Command. In PDU mode, setting is used by the same command, but only when the length of the SMSC address is coded into **<pdu>** that equals zero.

AT+CSCA Set Service Center Address	
Test Command **AT+CSCA=?**	Response **OK**
Read Command **AT+CSCA?**	Response **+CSCA: <sca>,<tosca>** **OK**
Write Command **AT+CSCA=<sca>[,<tosca>]**	Response **OK**

	Or **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.005*

Parameter

<sca>	String type. Service center address. See *3GPP TS 24.011* RP SC address Address-Value field; BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*).
<tosca>	Integer type. Type of service center address in octet. See *3GPP TS 24.011* RP SC address Type-of-Address.
<pdu>	String type. Service center address in hexadecimal. In case of SMS: *3GPP TS 24.011* SC address followed by *3GPP TS 23.040* TPDU: ME/TA converts each octet of TPDU into two IRA characters, with each octet represented by a pair of hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).

Example

```
AT+CSCA="+8613800210500",145          //Set SMSC address.
OK
AT+CSCA?                              //Query SMSC address.
+CSCA: "+8613800210500",145

OK
```

8.4 AT+CPMS Select Message Memory Storage

This command selects memory storages to be used for reading, writing, etc.

AT+CPMS Select Message Memory Storage	
Test Command **AT+CPMS=?**	Response **+CPMS: (**list of supported **<mem1>**s**),(**list of supported **<mem2>**s**),(**list of supported **<mem3>**s**)** **OK**

Read Command **AT+CPMS?**	Response **+CPMS: <mem1>,<used1>,<total1>,<mem2>,<used2>,<total2>,<mem3>,<used3>,<total3>** **OK**
Write Command **AT+CPMS=<mem1>[,<mem2>[,<mem3>]]**	Response **+CPMS: <used1>,<total1>,<used2>,<total2>,<used3>,<total3>** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.005*

Parameter

<mem1>	String type. Messages to be read and deleted from this memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<mem2>	String type. Messages to be written and sent to this memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<mem3>	String type. Received messages to be placed in this memory storage if routing to PC is not set (see **AT+CNMI**). "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<used>	Integer type. Number of current message(s) in **<mem*n*>**.
<total>	Integer type. Number of total message(s) that can be stored in **<mem*n*>**.
<err>	Error codes. For more details, see ***Chapter 13.6***.

NOTE

Executing **AT+CPMS=<mem1>[,<mem2>[,<mem3>]]** writes data to NVM. Please proceed with caution.

Example

```
AT+CPMS?                                    //Query the current SMS message storage.
+CPMS: "ME",0,255,"ME",0,255,"ME",0,255

OK
AT+CPMS="SM","SM","SM"                      //Set SMS message storage as "SM".
+CPMS: 0,50,0,50,0,50

OK
AT+CPMS?                                    //Query the current SMS message storage.
+CPMS: "SM",0,50,"SM",0,50,"SM",0,50

OK
```

8.5 AT+CMGD Delete Message

This command deletes short message from the preferred message storage **<mem1>** location **<index>**. If **<delflag>** is presented and not set to 0, ME ignores **<index>** and follows the rules of **<delflag>** shown below.

AT+CMGD Delete Message	
Test Command **AT+CMGD=?**	Response **+CMGD: (**list of supported **<index>**s**),(**list of supported **<delflag>**s**)** **OK**
Write Command **AT+CMGD=<index>[,<delflag>]**	Response **OK** If there is any error: **ERROR** Or **+CMS ERROR:<err>**
Maximum Response Time	300 ms
Characteristics	-

Reference	*3GPP TS 27.005*

Parameter

<index>	Integer type. Location numbers supported by the memory storage.
<delflag>	Integer type. Flag indicating message deletion request. 0 Delete the message specified in **<index>** 1 Delete all read messages from **<mem1>** 2 Delete all read messages from **<mem1>** and sent mobile originated messages 3 Delete all read messages from **<mem1>**, sent and unsent mobile originated messages 4 Delete all messages from **<mem1>**
<mem1>	String type. Messages to be deleted from the memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<err>	Error codes. For more details, see ***Chapter 13.6***.

NOTE

Executing **AT+CMGD=<index>[,<delflag>]** writes data to NVM. Please proceed with caution.

Example

```
AT+CMGD=1                    //Delete the message specified in location 1.
OK
AT+CMGD=1,4                  //Delete all messages from the memory storage.
OK
```

8.6 AT+CMGL Read Message by Status

This command returns message(s) with status paprameter **<stat>** from preferred message storage **<mem1>** to TE. If the status of the message is "REC UNREAD", the status in the storage changes to "REC READ". When executing **AT+CMGL** without status parameter **<stat>**, it reports the list of SMS with "REC UNREAD" status.

AT+CMGL Read Message by Status	
Test Command **AT+CMGL=?**	Response **+CMGL: (**list of supported **<stat>**s**)**

	OK
Write Command **AT+CMGL[=<stat>]**	Response If in text mode (**AT+CMGF=1**) and the command is executed successfully: For SMS-SUBMITs and/or SMS-DELIVERs: **+CMGL: <index>,<stat>,<oa/da>,[<alpha>],[<scts>][,<toa/toda>,<length>]<CR><LF><data>[<CR><LF>]** **[...]** For SMS-STATUS-REPORTs: **+CMGL: <index>,<stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>[<CR><LF>]** **[...]** For SMS-COMMANDs: **+CMGL: <index>,<stat>,<fo>,<ct>[<CR><LF>]** **[…]** For CBM storage: **+CMGL: <index>,<stat>,<sn>,<mid>,<page>,<pages><CR><LF><data>[<CR><LF>]** **[...]** **OK** If in PDU mode (**AT+CMGF=0**) and the command is executed successfully: **+CMGL: <index>,<stat>,[<alpha>],<length><CR><LF><pdu>[<CR><LF>]** **[...]** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	The response time of **<stat>** operation depends on the storage of listed messages. The maximum response time is 300 ms.
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<stat>	Integer type (PDU mode), or string type (text mode). Message status in the storage. In text mode: "REC UNREAD" Received unread messages "REC READ" Received read messages "STO UNSENT" Stored unsent messages "STO SENT" Stored sent messages "ALL" All messages In PDU mode: 0 Received unread messages 1 Received read messages 2 Stored unsent messages 3 Stored sent messages 4 All messages
<mem1>	String type. Messages to be read and deleted from this memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<index>	Integer type. Location numbers supported by the memory storage.
<da>	String type. Destination address. See *3GPP TS 23.040* TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<toda>**.
<oa>	String type. Originating address. See *3GPP TS 23.040* TP-Originating-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<tooa>**.
<alpha>	String type. Alphanumeric representation of **<da>** or **<oa>** corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with **AT+CSCS** (see *3GPP TS 27.007*).
<scts>	String type. Service center time stamp. See *3GPP TS 23.040* TP-Service-Centre-Time-Stamp (format see **<dt>** in ***Chapter 8.7***).
<toda>	Integer type. Type of destination address in octet. See *3GPP TS 24.011* TP-Destination-Address Type-of-Address.
<tooa>	Integer type. Type of originating address in octet. See *3GPP TS 24.011* TP-Originating-Address Type-of-Address.
<length>	Integer type. Message length. In text mode (**AT+CMGF=1**): length of the message body **<data>** in characters. In PDU mode (**AT+CMGF=0**): length of the actual TPDU in octet (i.e. the RP layer SMSC address octets are not counted in the length).
<data>	In the case of SMS: *3GPP TS 23.040* TP-User-Data in text mode responses; Format:

	If **<dcs>** indicates that *3GPP TS 23.038* GSM 7-bit default alphabet is used and **<fo>** indicates that *3GPP TS 23.040* TP-User-Data-Header-Indication is not set. If TE character set other than "HEX" (see **AT+CSCS** in *3GPP TS 27.007*): ME/TA converts GSM alphabet into current TE character set according to rules in *3GPP TS 27.005 Annex A*. If TE character set is "HEX": ME/TA converts each 7-bit character of GSM 7-bit default alphabet into two IRA character long hexadecimal number (e.g. character Π (GSM 7-bit default alphabet 23) is presented as 17 (IRA 49 and 55)). If **<dcs>** indicates that 8-bit or UCS2 data coding scheme is used, or **<fo>** indicates that *3GPP TS 23.040* TP-User-Data-Header-Indication is set: ME/TA converts each 8-bit octet into two IRA characters, with each octet represented by a pair of hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)). In the case of CBS: *3GPP TS 23.041* CBM Content of Message in text mode responses; Format: If **<dcs>** indicates that *3GPP TS 23.038* GSM 7-bit default alphabet is used: If TE character set other than "HEX" (see **AT+CSCS** in *3GPP TS27.007*): ME/TA converts GSM alphabet into current TE character set according to rules of Annex A in *3GPP TS 27.005*. If TE character set is "HEX": ME/TA converts each 7-bit character of the GSM 7-bit default alphabet into two IRA characters, with each octet represented by a pair of hexadecimal numbers.
<fo>	Integer type. It depends on the command or result code: the first octet of *3GPP TS 23.040* SMS-DELIVER, SMS-SUBMIT (default value 17), SMS-STATUS-REPORT, or SMS-COMMAND (default value 2).
<mr>	Integer type. Message reference. See *3GPP TS 23.040* TP-Message-Reference.
<ra>	String type. Recipient address. See *3GPP TS 23.040* TP-Recipient-Address Address-Value field; BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see command **AT+CSCS** in *3GPP TS 27.007*).
<tora>	Integer type. Type of recipient address in octet. See *3GPP TS 24.011* TP-Recipient-Address Type-of-Address.
<dt>	String type. *3GPP TS 23.040* TP-Discharge-Time. Format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g., 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08".
<st>	Integer type. See *3GPP TS 23.040* TP-Status.
<ct>	Integer type. See *3GPP TS 23.040* TP-Command-Type. Default value: 0.
<sn>	Integer type. See *3GPP TS 23.041* CBM Serial Number.
<mid>	Integer type. See *3GPP TS 23.041* CBM Message Identifier.
<page>	Integer type. See *3GPP TS 23.041* CBM Page Parameter bits 4–7.
<pages>	Integer type. See *3GPP TS 23.041* CBM Page Parameter bits 0–3.
<pdu>	String type. Service center address in hexadecimal. In case of SMS: *3GPP TS*

	24.011 SC address followed by *3GPP TS 23.040* TPDU: ME/TA converts each octet of TP data unit into two IRA character long hexadecimal number (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<err>	Error codes. For more details, see ***Chapter 13.6***.

Example

```
AT+CMGF=1                          //Set SMS message format as text mode.
OK
AT+CMGL="ALL"                      //List all messages from message storage.
+CMGL: 1,"STO UNSENT","",,
<This is a test from Quectel>
+CMGL: 2,"STO UNSENT","",,
<This is a test from Quectel>

OK
```

8.7 AT+CMGR Read Message By Index

This command returns SMS message with location value **<index>** from message storage **<mem1>** to the TE. If status of the message is "REC UNREAD", status in the storage changes to "REC READ".

AT+CMGR Read Message By Index	
Test Command **AT+CMGR=?**	Response **OK**
Write Command **AT+CMGR=<index>**	Response If in text mode (**AT+CMGF=1**) and the command is executed successfully: For SMS-DELIVER: **+CMGR: <stat>,<oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>** **OK** For SMS-SUBMIT: **+CMGR: <stat>,<da>,[<alpha>][,<toda>,<fo>,<pid>,<dcs>,[<vp>],<sca>,<tosca>,<length>]<CR><LF><data>** **OK** For SMS-STATUS-REPORTs: **+CMGR: <stat>,<fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>**

	OK For SMS-COMMANDs: **+CMGR: <stat>,<fo>,<ct>[,<pid>,[<mn>],[<da>],[<toda>],<length><CR><LF><cdata>]** **OK** For CBM storage: **+CMGR: <stat>,<sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>** **OK** If in PDU mode (**AT+CMGF=0**) and command is executed successfully: **+CMGR: <stat>,[<alpha>],<length><CR><LF><pdu>** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	Depends on the length of message content.
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<index>	Integer type. Location number supported by the memory storage.
<mem1>	String type. Messages to be read from this memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<stat>	Integer type (PDU mode), or string type (text mode). Message status in the storage. In text mode: "REC UNREAD" Received unread messages "REC READ" Received read messages "STO UNSENT" Stored unsent messages

	"STO SENT"	Stored sent messages
	"ALL"	All messages
	In PDU mode:	
	0	Received unread messages
	1	Received read messages
	2	Stored unsent messages
	3	Stored sent messages
	4	All messages
<oa>	String type. Originating address. See *3GPP TS 23.040* TP-Originating-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<tooa>**.	
<alpha>	String type. Alphanumeric representation of **<da>** or **<oa>** corresponding to the entry found in MT phonebook. Implementation of this feature is manufacturer specified. The used character set should be the one selected with **AT+CSCS** (see *3GPP TS 27.007*).	
<scts>	String type. Service center time stamp. See *3GPP TS 23.040* TP-Service-Centre-Time-Stamp (see **<dt>**).	
<tooa>	Integer type. Type of originating address in octet. See *3GPP TS 24.011* TP-Originating-Address Type-of-Address.	
<fo>	Integer type in octet. It depends on the command or result code: the first octet of *3GPP TS 23.040* SMS-DELIVER, SMS-SUBMIT (default value 17), SMS-STATUS-REPORT, or SMS-COMMAND. If a valid value has been entered once, the parameter can be omitted.	
<pid>	Integer type. Protocol identifier. Default value: 0. See *3GPP TS 23.040* TP-Protocol-Identifier.	
<dcs>	Integer type. Data coding scheme. It depends on the command or result code: *3GPP TS 23.038* SMS Data Coding Scheme (default value 0), or Cell Broadcast Data Coding Scheme.	
<sca>	String type. Service center address. See *3GPP TS 24.011* RP SC address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<tosca>**.	
<tosca>	Integer type. Type of service center address in octet. See *3GPP TS 24.011* RP SC address Type-of-Address.	
<length>	Integer type. Message length. In text mode (**AT+CMGF=1**): length of the message body **<data>** (or **<cdata>**) in characters. In PDU mode (**AT+CMGF=0**): length of the actual TP data unit in octet (i.e. the RP layer SMSC address octets are not counted in the length).	
<data>	String type. Text of short message.	
<da>	String type. Destination address. See *3GPP TS 23.040* TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<toda>**.	

<toda>	Integer type. Type of destination address in octet. See *3GPP TS 24.011* TP-Destination-Address Type-of-Address.
<vp>	Integer type or time-string type. Validity period. It depends on SMS-SUBMIT **<fo>** setting: *3GPP TS 23.040* TP-Validity-Period (format see **<dt>**).
<mr>	Integer type. Message reference. See *3GPP TS 23.040* TP-Message-Reference.
<ra>	String type. Recipient address. See *3GPP TS 23.040* TP-Recipient-Address Address-Value field. BCD numbers (or GSM default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS**). The type of address is given by **<tora>**.
<tora>	Integer type. Type of recipient address in octet. See *3GPP TS 24.011* TP-Recipient-Address Type-of-Address.
<dt>	String type. *3GPP TS 23.040* TP-Discharge-Time. Format: "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minutes, seconds and time zone. E.g., 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08".
<st>	Integer type. See *3GPP TS 23.040* TP-Status.
<ct>	Integer type. See *3GPP TS 23.040* TP-Command-Type (default value 0).
<mn>	Integer type. Message number. See *3GPP TS 23.040* TP-Message-Number.
<cdata>	String type. See *3GPP TS 23.040* TP-Command-Data in text mode responses; ME/TA converts each 8-bit octet into two IRA characters, with each octet represented by a pair of hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<sn>	Integer type. See *3GPP TS 23.041* CBM Serial Number.
<mid>	Integer type. See *3GPP TS 23.041* CBM Message Identifier.
<page>	Integer type. See *3GPP TS 23.041* CBM Page Parameter bits 4–7.
<pages>	Integer type. See *3GPP TS 23.041* CBM Page Parameter bits 0–3.
<pdu>	String type. Service center address in hexadecimal. In case of SMS: *3GPP TS 24.011* SC address followed by *3GPP TS 23.040* TPDU: ME/TA converts each octet of TP data unit into two IRA characters, with each octet represented by a pair of hexadecimal numbers (e.g. octet with integer value 42 is presented to TE as two characters 2A (IRA 50 and 65)).
<err>	Error codes. For more details, see ***Chapter 13.6***.

Example

```
+CMTI: "SM",3          //A new message has been received and saved to <index>=3 of "SM".
AT+CSDH=1              //Show the values in result codes.
OK
AT+CMGR=3              //Read message.
+CMGR: "REC UNREAD","+8615021012496",,"13/12/13,15:06:37+32",145,4,0,0,"+8613800210500",145,27
<This is a test from Quectel>

OK
```

8.8 AT+CMGS Send Message

This command sends a short message from TE to the network (SMS-SUBMIT). After invoking the Write Command, wait for the prompt **>** and then write the message. After that, enter **CTRL** + **Z** to indicate the ending of PDU and initiate message sending. Tap **Esc** to cancel the sending. Abortion is acknowledged with **OK**, though the message will not be sent. On successful message delivery, the message reference **<mr>** is returned to TE. The value can be used to identify the message upon unsolicited delivery of a status report result code.

AT+CMGS Send Message	
Test Command **AT+CMGS=?**	Response **OK**
Write Command 1) If in text mode (**AT+CMGF=1**): **AT+CMGS=<da>[,<toda>]** 2) If in PDU mode (**AT+CMGF=0**): **AT+CMGS=<length>**	Response **>** After **>** is returned, input the message to be sent. Tap **CTRL** + **Z** to send the message or tap **Esc** to cancel the sending. If the message is sent successfully: **+CMGS: <mr>** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	120 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<da>	String type. Destination address. See *3GPP TS 23.040* TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*); type of address is given by **<toda>**.
<toda>	Integer type. Type of destination address. See *3GPP TS 24.011* TP-Destination-Address Type-of-Address octet.
<length>	Integer type. Message length. In text mode (**AT+CMGF=1**): length of the message body **<data>** (or **<cdata>**) in characters.

	In PDU mode (**AT+CMGF=0**): length of the actual TP data unit in octet (i.e. the RP layer SMSC address octets are not counted in the length).
<mr>	Integer type. Message reference. See *3GPP TS 23.040* TP-Message-Reference.
<err>	Error codes. For more details, see ***Chapter 13.6***.

Example

```
AT+CMGF=1                                  //Set SMS message format to text mode.
OK
AT+CSCS="GSM"                              //Set character set to GSM used by TE.
OK
AT+CMGS="15021012496"
>This is a test from Quectel              //Enter the message and tap CTRL + Z to send message
+CMGS: 247

OK
```

8.9 AT+CMMS Send Multiple Messages

This command controls the continuity of the SMS relay protocol link. If the feature is enabled (and supported by the network), multiple messages can be sent faster as the link is kept open.

AT+CMMS Send Multiple Messages	
Test Command **AT+CMMS=?**	Response **+CMMS: (**list of supported **<n>**s**)** **OK**
Read Command **AT+CMMS?**	Response **+CMMS: <n>** **OK**
Write/Execution Command **AT+CMMS[=<n>]**	Response **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	120 s, determined by network.
Characteristics	-

Reference	*3GPP TS 27.005*

Parameter

<n>	Integer type.	
	0	Feature disabled
	1	Keep feature enabled until the time between the response of the latest commands to be sent (**AT+CMGS**, **AT+CMSS**, etc.) and the next command to be sent exceeds 1–5 seconds (the exact value is up to ME implementation); then ME closes the link and MT switches **<n>** back to 0 automatically.
	2	Feature enabled. If the time between the response of the latest commands to be sent and the next command to be sent exceeds 1–5 seconds (the exact value is up to ME implementation), ME closes the link but MT not switch **<n>** back to 0 automatically.
<err>	Error codes. For more details, see ***Chapter 13.6***.	

NOTE

Once the Read Command is executed, a delay of 5–10 seconds is required before issuing the Write Command. Otherwise **+CMS ERROR: 500** may be returned.

8.10 AT+CMGW Write Message to Memory Storage

This command stores short messages from TE to memory storage **<mem2>**, and then the location **<index>** of the stored message is returned. Message status will be set to "STO UNSENT" by default; but **<stat>** also allows entering other status values.

The syntax of input text is the same as the one specified in **AT+CMGS** Write Command.

AT+CMGW Write Message to Memory Storage	
Test Command **AT+CMGW=?**	Response **OK**
Write Command 1) If in text mode (**AT+CMGF=1**): **AT+CMGW=<oa/da>[,<tooa/toda>[,<stat>]]** 2) If in PDU mode (**AT+CMGF=0**): **AT+CMGW=<length>[,<stat>]**	Response **>** After **>** is returned, input the message to be sent. Tap **CTRL** + **Z** to send the message or tap **Esc** to cancel the sending. If message writing is successful: **+CMGW: <index>** **OK**

	If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<da>	String type. Destination address. See *3GPP TS 23.040* TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<toda>**.
<oa>	String type. Originating address. See *3GPP TS 23.040* TP-Originating-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address given by **<tooa>**.
<tooa>	Integer type. Type of originating address in octet. See *3GPP TS 24.011* TP-Originating-Address Type-of-Address.
<stat>	Integer type (PDU mode), or string type (text mode). Message status in the storage. In text mode: "REC UNREAD" Received unread message "REC READ" Received read message "STO UNSENT" Stored unsent message "STO SENT" Stored sent message "ALL" All messages In PDU mode: 0 Received unread message 1 Received read message 2 Stored unsent message 3 Stored sent message 4 All messages
<toda>	Integer type. Type of destination address in octet. See *3GPP TS 24.011* TP-Destination-Address Type-of-Address.
<length>	Integer type. Message length. In text mode (**AT+CMGF=1**): length of the message body **<data>** (or **<cdata>**) in characters. In PDU mode (**AT+CMGF=0**): length of the actual TPDU in octet (i.e. the RP layer SMSC address octets are not counted in the length).
<index>	Integer type. Index of message in the memory storage **<mem2>**.

<mem2>	String type. Messages to be written and sent to the memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<err>	Error codes. For more details, see ***Chapter 13.6***.

NOTE

Executing **AT+CMGW** writes data to NVM. Please proceed with caution.

Example

```
AT+CMGF=1                          //Set SMS message format to text mode.
OK
AT+CSCS="GSM"                      //Set character set to GSM used by TE.
OK
AT+CMGW="15021012496"
>This is a test from Quectel      //Enter message in text and tap CTRL + Z to write message.
+CMGW: 4

OK
AT+CMGF=0                          //Set SMS message format to PDU mode.
OK
AT+CMGW=18
>0051FF00000008000A0500030002016D4B8BD5
+CMGW: 5

OK
```

8.11 AT+CMSS Send Messages from Memory Storage

This command sends a message with location parameter **<index>** from message storage **<mem2>** to the network. If a new recipient address **<da>** is given for SMS-SUBMIT, it should be used instead of the old one contained in the message stored in the memory storage. Reference value **<mr>** is returned to TE on successful message delivery. The value can be used to identify the message upon unsolicited delivery status report result code.

AT+CMSS Send Messages from Memory Storage	
Test Command	Response
AT+CMSS=?	**OK**

Write Command **AT+CMSS=<index>[,<da>[,<toda>]]**	Response If in text mode (**AT+CMGF=1**) and the message is sent successfully: **+CMSS: <mr>[,<scts>]** **OK** If in PDU mode (**AT+CMGF=0**) and the message is sent successfully: **+CMSS: <mr>[,<ackpdu>]** **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	120 s, determined by network.
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<index>	Integer type. Location numbers supported by the memory storage.
<da>	String type. Destination Address. See *3GPP TS 23.040* TP-Destination-Address Address-Value field. BCD numbers (or GSM 7-bit default alphabet characters) are converted to characters of the currently selected TE character set (see **AT+CSCS** in *3GPP TS 27.007*). The type of address is given by **<toda>**.
<toda>	Integer type. Type of destination address in octet. See *3GPP TS 24.011* TP-Destination-Address Type-of-Address.
<mr>	Integer type. Message reference. See *3GPP TS 23.040* TP-Message-Reference.
<scts>	String type. Service center time stamp. See *3GPP TS 23.040* TP-Service-Centre-Time-Stamp (format see **<dt>** in ***Chapter 8.7***).
<ackpdu>	String type. *3GPP TS 23.040* RP-User-Data element of RP-ACK PDU. Format is the same with **<pdu>** in case of SMS, but without *3GPP TS 24.011* SC address field.
<mem2>	String type. Messages to be written and sent to the memory storage. "SM" (U)SIM message storage "ME" Mobile equipment message storage "MT" Same as "ME" storage "SR" SMS status report storage location
<err>	Error codes. For more details, see ***Chapter 13.6*.**

Example

```
AT+CMGF=1                          //Set SMS message format to text mode.
OK
AT+CSCS="GSM"                      //Set character set to GSM used by TE.
OK
AT+CMGW="15021012496"
> Hello                            //Enter message in text and tap CTRL + Z to send message.
+CMGW: 4

OK
AT+CMSS=4                          //Send message of index 4 from memory storage.
+CMSS: 54

OK
```

8.12 AT+CNMA New Message Acknowledgement

This command confirms successful receipt of a new message (SMS-DELIVER or SMS-STATUS-REPORT) routed directly to TE. If UE does not receive acknowledgement within required time (network timeout), it will send an **RP-ERROR** message to the network. UE will automatically disable routing to TE by setting both **<mt>** and **<ds>** values of **AT+CNMI** to 0.

AT+CNMA New Message Acknowledgement	
Test Command **AT+CNMA=?**	Response If in text mode **(AT+CMGF=1):** **OK** If in PDU mode (**AT+CMGF=0**): **+CNMA: (**list of supported **<n>**s**)** **OK**
Execution Command If in text mode (**AT+CMGF=1**): **AT+CNMA**	Response **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Write Command If in PDU mode (**AT+CMGF=0**): **AT+CNMA=<n>[,<length>[<CR>**	Response **OK**

PDU is given**<Ctrl+Z/ESC>]]**	If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<n>	Integer type. Parameter required only for PDU mode. 0 Command operates similarly as in text mode. 1 Send positive (**RP-ACK**) acknowledgement to the network. Accepted only in PDU mode. 2 Send negative (**RP-ERROR**) acknowledgement to the network. Accepted only in PDU mode.
<length>	Integer type. Message length. The length of the actual TP data unit in octets (i.e. the RP layer SMSC address octets are not counted in the length) in PDU mode (**AT+CMGF=0**).
<err>	Error codes. For more details, see ***Chapter 13.6***.

NOTE

The Execution and Write Commands are only used when **<service>** of **AT+CSMS** equals 1 (phase 2+) and an appropriate URC has been issued by the MT, i.e.:

1) **+CMT** when **<mt>**=2 in **AT+CNMI**, i,e, incoming message classes 0, 1, 3 and none;
2) **+CMT** when **<mt>**=3 in **AT+CNMI**, i,e, incoming message classes 0 and 3;
3) **+CDS** when **<ds>**=1 in **AT+CNMI**.

Example

```
AT+CSMS=1
OK
AT+CNMI=1,2,0,0,0
OK
AT+CMGF=1                    //Set SMS message format to text mode.
OK
AT+CSDH=1                    //Show the values in result codes
OK
+CMT: "+8615021012496",,"13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel.  //Short message is outputted directly upon incoming SMS.
AT+CNMA                      //Send ACK to the network.
OK
```

AT+CNMA	//Send ACK to the network.
+CMS ERROR: 340	//An error is returned on the second attempt; only one ACK is required.

8.13 AT+CNMI Set New Message Indication

This command selects how the received new messages from the network are indicated to TE when TE is active, e.g., DTR is at low level (ON). If TE is inactive (e.g., DTR is at high level (OFF)), the message should be received as specified in *3GPP TS 23.038*.

AT+CNMI Set New Message Indication	
Test Command **AT+CNMI=?**	Response **+CNMI: (**list of supported **<mode>**s**),(**list of supported **<mt>**s**),(**list of supported **<bm>**s**),(**list of supported **<ds>**s**),(**list of supported **<bfr>**s**)** **OK**
Read Command **AT+CNMI?**	Response **+CNMI: <mode>,<mt>,<bm>,<ds>,<bfr>** **OK**
Write Command **AT+CNMI=[<mode>[,<mt>[,<bm>[,<ds>[,<bfr>]]]]]**	Response **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.
Reference	*3GPP TS 27.005*

Parameter

<mode>	Integer type. 0 Buffer URC in MT. If MT result code buffer is full, the indication can be buffered in some other place or the oldest indication may be discarded and replaced with the new received indication. 1 Discard the indication and reject new received message URC when MT-TE link is reserved (e.g. in data mode). Otherwise, forward directly to TE.

	2 Buffer URC in MT when MT-TE link is reserved (e.g. in data mode) and flush URC to TE after reservation. Otherwise forward directly to TE.
<mt>	Integer type. Rule for storing received message, which depends on its data coding scheme (see *3GPPTS 23.038*) and preferred memory storage (**AT+CPMS**) setting. 0 No SMS-DELIVER indication is routed to TE. 1 If SMS-DELIVER is stored into ME/TA, the indication of the memory location is routed to TE by URC: **+CMTI: <mem>,<index>**. 2 SMS-DELIVER (except Class 2) is routed directly to TE by URC: **+CMT: [<alpha>],<length><CR><LF><pdu>** (PDU mode enabled) or URC **+CMT: <oa>,[<alpha>],<scts>[,<*tooa*>,<*fo*>,<*pid*>,<*dcs*>,<*sca*>,<*tosca*>,<*length*>]<CR><LF><data>** (text mode enabled; about the parameters in italics, see **AT+CSDH**). Class 2 message results in indication as defined in **<mt>**=1. 3 Class 3 SMS-DELIVER is routed directly to TE by URC defined in **<mt>**=2. Message of other classes results in indication as defined in **<mt>**=1.
<bm>	Integer type. Rule for storing received CBM, which depends on its data coding scheme (see *3GPP TS 23.038*) and the setting of selected CBM types (**AT+CSCB**). 0 No CBM indication is routed to TE. 2 New CBM is routed directly to TE by URC: **+CBM: <length><CR><LF><pdu>** (PDU mode enabled); or URC **+CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>** (text mode enabled).
<ds>	Integer type. 0 No SMS-STATUS-REPORT is routed to TE. 1 SMS-STATUS-REPORT is routed to TE by URC: **+CDS: <length><CR><LF><pdu>** (PDU mode) or **+CDS: <fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>** (text mode) 2 If SMS-STATUS-REPORT is stored into ME/TA, the indication of the memory location is routed to TE by URC: **+CDSI: <mem>,<index>**
<bfr>	Integer type. 0 TA buffer of URC defined within this command is flushed to TE when **<mode>** is 1 or 2 (response **OK** shall be given before flushing). 1 TA buffer of URC defined within this command is cleared when **<mode>** is 1 or 2.
<err>	Error code. For more details, see ***Chapter 13.6***.

NOTE

1.	URC **+CMTI: <mem>,<index>**	A new message has been received
2.	URC **+CMT: [<alpha>],<length><CR><LF><pdu>**	A short message is output directly
3.	URC **+CBM: <length><CR><LF><pdu>**	A cell broadcast message is output directly

Example

```
AT+CMGF=1                    //Set SMS message format to text mode.
OK
```

```
AT+CSCS="GSM"                    //Set character set to GSM which is used by TE.
OK
AT+CNMI=1,2,0,1,0                //Set SMS-DELIVER to be routed directly to TE.
OK
AT+CSDH=1                        //Show text mode parameters.
OK
+CMT: "+8615021012496",,"13/03/18,17:07:21+32",145,4,0,0,"+8613800551500",145,28
This is a test from Quectel.     //Short message is output directly when an SMS is incoming.
```

8.14 AT+CSCB Select Cell Broadcast Message Type

This command selects the types of CBMs to be received by the ME.

AT+CSCB Select Cell Broadcast Message Type	
Test Command **AT+CSCB=?**	Response **+CSCB: (**list of supported **<mode>**s**)** **OK**
Read Command **AT+CSCB?**	Response **+CSCB: <mode>,<mids>,<dcss>** **OK**
Write Command **AT+CSCB=<mode>[,mids>[,<dcss>]]**	Response **OK** If there is any error: **ERROR** Or **+CMS ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<mode>	Integer type. 0 Message type specified in **<mids>** and **<dcss>** is accepted 1 Message type specified in **<mids>** and **<dcss>** is not accepted
<mids>	String type. All different possible combinations of CBM message identifiers (see **<mid>**) (default: empty string), e.g. "0,1,5,320–478,922".

<dcss>	String type. All different possible combinations of CBM data coding schemes (see **<dcs>**) (default: empty string), e.g. "0–3,5".
<err>	Error codes. For more details, see ***Chapter 13.6***.

8.15 AT+CSDH Show Text Mode Parameter

This command controls whether to show detailed header information in text mode result codes.

AT+CSDH Show Text Mode Parameter	
Test Command **AT+CSDH=?**	Response **+CSDH: (**list of supported **<show>**s**)** **OK**
Read Command **AT+CSDH?**	Response **+CSDH: <show>** **OK**
Write Command **AT+CSDH=[<show>]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<show>	Integer type.	
	0	Do not show detailed header information: for SMS-DELIVERs and SMS-SUBMITs in text mode, URCs **+CSCA** and **+CSMP** do not contain **<sca>**, **<tosca>**, **<fo>**, **<vp>**, **<pid>** or **<dcs>** and URCs **+CMT**, **+CMGL** and **+CMGR** do not contain **<length>**, **<toda>** or **<tooa>**.
	1	Show the values in result codes

Example

```
AT+CSDH=0                          //Disable text mode parameter presentation.
OK
AT+CMGR=2                          //Read the message whose <index> is 2.
+CMGR: "STO UNSENT" ,"",
```

```
<This is a test from Quectel>

OK
AT+CSDH=1                          //Enable text mode parameter presentation.
OK
AT+CMGR=2
+CMGR: "STO UNSENT","",,128,17,0,0,143,"+8613800551500",145,18
<This is a test from Quectel>

OK
```

8.16 AT+CSMP Set Text Mode Parameter

This Write Command selects values for additional parameters needed when SM is sent to the network or placed in a storage when text mode is selected (**AT+CMGF=1**). It is also possible to set the validity period starting from when a short message is received by SMSC (**<vp>** ranges from 0 to 255) or define the absolute time of the validity period termination (**<vp>** is a string).

AT+CSMP Set Text Mode Parameter	
Test Command **AT+CSMP=?**	Response **OK**
Read Command **AT+CSMP?**	Response **+CSMP: <fo>,<vp>,<pid>,<dcs>** **OK**
Write Command **AT+CSMP=<fo>[,<vp>[,<pid>[,<dcs>]]]**	Response **OK** Or **ERROR**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.005*

Parameter

<fo>	Integer type. It depends on the command or result code: the first octet of *3GPP TS 23.040* SMS-DELIVER, SMS-SUBMIT (default value 17), SMS-STATUS-REPORT or SMS-COMMAND. If a valid value has been entered once, the parameter can be omitted.
<vp>	Integer type or time-string type. Validity period. It depends on SMS-SUBMIT **<fo>**

	setting: *3GPP TS 23.040* TP-Validity-Period (format see **<dt>**). Default value: 167.
<pid>	Integer type. Protocol identifier. Default value: 0. See *3GPP TS 23.040* TP-Protocol-Identifier.
<dcs>	Integer type. Data coding scheme. It depends on the command or result code: *3GPP TS 23.038* SMS Data Coding Scheme (default value 0), or Cell Broadcast Data Coding Scheme.

9 Packet Domain Commands

9.1 AT+CGATT Attach to or Detach from PS

This command attaches or detaches MT to/from the packet domain service. After the command has been completed, the MT remains in V.250 command state. If MT is already in the requested state, the command will be ignored and the **OK** response will be returned. If the requested state cannot be achieved, an **ERROR** or **+CME ERROR** response will be returned.

AT+CGATT Attach to or Detach from PS	
Test Command **AT+CGATT=?**	Response **+CGATT: (**list of supported **<state>**s**)** **OK**
Read Command **AT+CGATT?**	Response **+CGATT: <state>** **OK**
Write Command **AT+CGATT=<state>**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	140 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<state>	Integer type. PS attachment state.	
	0	Detached
	1	Attached

<err>	Other values are reserved and will result in an **ERROR** response to the Write Command Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CGATT=1                  //Attach to PS service.
OK
AT+CGATT=0                  //Detach from PS service.
OK
AT+CGATT?                   //Query the current PS service attachement state.
+CGATT: 0

OK
```

9.2 AT+CGACT Activate or Deactivate PDP Context

This command activates or deactivates the specified PDP context(s). If a PDP context is already in the requested state, the state for that context remains unchanged. Failure to achieve the requested state will result in an **ERROR** or **+CME ERROR**. Extended error response is enabled by **AT+CMEE**.

If MT is not PS attached when the activation command is executed, MT will first attempt attachment and then activate the specified context. In case of attachment failure, MT responds with **ERROR** or, if extended error response is enabled, with the appropriate failure-to-attach error message.

For EPS, in case of an attempt to disconnect the last PDN connection, MT responds with **ERROR**, or, if extended error response is enabled, it responds with **+CME ERROR**. The activation request for an EPS bearer resource will be answered by the network by either an EPS dedicated bearer activation or an EPS bearer modification request. The request must be accepted by MT before the PDP context can be set to an established state.

For 5GS, the command is used to request or delete the specified QoS flow. The request for a specific QoS flow will be answered by the network by either a PDU session establishment accept message or a PDU session modification command message. The message must be accepted by the MT before the QoS flow can be set to active state.

AT+CGACT Activate or Deactivate PDP Contexts	
Test Command **AT+CGACT=?**	Response **+CGACT: (**list of supported **<state>**s**)** **OK**
Read Command **AT+CGACT?**	Response **+CGACT: <cid>,<state>**

	[…] **OK**
Write Command **AT+CGACT=<state>[,<cid>[,<cid2>[,…]]]]**	Response **OK** Or **NO CARRIER** If there is any error related to MT functionality: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	150 s, determined by network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<state>	Integer type. PDP context activation status. 0 Deactivated 1 Activated Other values are reserved and will result in an **ERROR** response to the Write Command.
<cid>	Integer type. Particular PDP context definition (see **AT+CGDCONT**).
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CGDCONT=4,"IP","UNINET"          //Define a PDP context.
OK
AT+CGACT=1,4                        //PDP activated .
OK
AT+CGACT?                           //Query the current PDP context state.
+CGACT: 1,1
+CGACT: 2,0
+CGACT: 3,0
+CGACT: 4,1
…

OK
AT+CGACT=0,4                        //Deactivated the PDP.
OK
```

9.3 AT+CGPADDR Show PDP Address

This command returns a list of PDP addresses for the specified context identifiers. If no **<cid>** is specified, the addresses for all defined contexts are returned.

AT+CGPADDR Show PDP Address	
Test Command **AT+CGPADDR=?**	Response **+CGPADDR: (**list of defined **<cid>**s**)** **OK**
Execution/Write Command **AT+CGPADDR[=<cid>[,<cid>[,…]]]**	Response **[+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]]]** **[…]** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<cid>	Integer type. Particular PDP context definition (see **AT+CGDCONT**).
<PDP_addr>	String type. MT in the address space applicable to PDP. The address may be static or dynamic. For a static address, it is the one set by **AT+CGDCONT** when the context is defined. For a dynamic address, it is the one assigned during the last PDP context activation that used the context definition referred to by **<cid>**. **<PDP_addr>** is omitted if no address is available.
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CGDCONT=1,"IP","UNINET"          //Define a PDP context.
OK
AT+CGACT=1,1                        //Activated the PDP.
OK
AT+CGPADDR=1                        //Show the PDP address.
```

```
+CGPADDR: 1,"10.76.51.180"

OK
```

9.4 AT+CGEREP Report Packet Domain Event

This command enables or disables sending of URC **+CGEV** from MT to TE in the case of certain event occurring in the packet domain MT or the network. **<mode>** controls the processing of URC specified within this command. **<bfr>** controls the effect on buffered codes when **<mode>** 1 or 2 is specified.

AT+CGEREP Report Packet Domain Event	
Test Command **AT+CGEREP=?**	Response **+CGEREP: (**list of supported **<mode>**s**),(**list of supported **<bfr>**s**)** **OK**
Read Command **AT+CGEREP?**	Response **+CGEREP: <mode>,<bfr>** **OK** If there is any error: **ERROR**
Write Command **AT+CGEREP=[<mode>[,<bfr>]]**	Response **OK** Or **ERROR**
Execution Command **AT+CGEREP**	Response **OK**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<mode>	Integer type.	
	0	Buffer URC in MT. If MT result code buffer is full, the oldest ones can be discarded. No codes are forwarded to TE.
	1	Discard URC when MT-TE link is reserved (e.g. in on-line data mode); otherwise

		forward directly to the TE.
	2	Buffer URC in MT when MT-TE link is reserved (e.g. in on-line data mode) and flush URC to TE when MT-TE link becomes available; otherwise forward directly to TE.
<bfr>	Integer type.	
	0	MT buffer of URC defined within this command is cleaned when **<mode>** 1 or 2 is specified.
	1	MT buffer of URC defined within this command is flushed to TE when **<mode>** 1 or 2 is specified (**OK** should be given before flushing the codes).

NOTE

The URCs and the corresponding events are defined as follows:

1. **+CGEV: REJECT <PDP_type>,<PDP_addr>**: A network request for PDP context activation occurs when the MT is unable to report it to TE with URC **+CRING** and is automatically rejected. This event is not applicable for EPS and 5GS.
2. **+CGEV: NW REACT <PDP_type>,<PDP_addr>[,<cid>]**: The network has requested a context reactivation. **<cid>** used to reactivate the context is provided if known to MT. This event is not applicable for EPS.
3. **+CGEV: NW DEACT <PDP_type>,<PDP_addr>[,<cid>]**: The network has forced a context deactivation. **<cid>** used to activate the context is provided if known to MT.
4. **+CGEV: ME DEACT <PDP_type>,<PDP_addr>[,<cid>]**: The mobile equipment has forced a context deactivation. **<cid>** used to activate the context is provided if known to MT.
5. **+CGEV: NW DETACH**: The network has forced a packet domain detach. This implies that all active contexts have been deactivated. These contexts are not reported separately.
6. **+CGEV: ME DETACH**: The mobile equipment has forced a packet domain detach. This implies that all active contexts have been deactivated. These are not reported separately.
7. **+CGEV: NW CLASS<class>**: The network has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS** in *3GPP 27.007 subclause 10.1.7*).
8. **+CGEV: ME CLASS<class>**: The mobile equipment has forced a change of MS class. The highest available class is reported (see **AT+CGCLASS** in *3GPP 27.007 subclause 10.1.7*).
9. **+CGEV: PDN ACT<cid>**: Activate a context. The context represents a PDN connection in LTE.
10. **+CGEV: PDN DEACT<cid>**: Deactivate a context. The context represents a PDN connection in LTE.

Parameter

<PDP_type>	Srting type. Packet data protocol type. "IP" IPv4 "IPV6" IPv6 "IPV4V6" IPv4v6
<PDP_addr>	String type. MT in the address space applicable to PDP. If the value is null or omitted, a value may be provided by TE during PDP.
<cid>	Integer type. PDP context identifier. The parameter is local to the TE-MT interface and is used in other PDP context-related commands. The range of permitted values

	(minimum value=1) are returned by the test form of **AT+CGDCONT**.	
<class>	String type. GPRS mobile class.	
	A	Class A (highest)
	B	Class B
	C	Class C in GPRS and circuit switched alternate mode
	CG	Class C in GPRS only mode
	CC	Class C in circuit switched only mode (lowest)

Example

```
AT+CGEREP=?             //Test command.
+CGEREP: (0-2),(0,1)

OK
AT+CGEREP?              //Query the current configuration.
+CGEREP: 0,0

OK
AT+CGEREP=2,1           //Report packet domain event.
OK
AT+CGACT=1,2            //Activated a context.
OK

+CGEV: PDN ACT2
AT+CGACT=0,2            //Deactivated a context.
OK

+CGEV: PDN DEACT2
```

10 Supplementary Service Commands

10.1 AT+CCFC Call Forwarding Number and Conditions Control

This command allows control of the call forwarding supplementary service according to *3GPP TS 22.082*. Registration, erasure, activation, deactivation and status query are supported.

AT+CCFC Call Forwarding Number and Conditions Control	
Test Command **AT+CCFC=?**	Response **+CCFC: (**list of supported **<reads>**s**)** **OK**
Write Command **AT+CCFC=<reads>,<mode>[,<number>[,<type>[,<class>[,<subaddr>[,<satype>[,<time>]]]]]]**	Response If **<mode>** is not equal to 2 and the command is executed successfully: **OK** If **<mode>**=2 and the command is executed successfully (only in connection with **<reads>**=(0–3)): For registered call forwarding numbers: **+CCFC: <status>,<class1>[,<number>,<type>[,<subaddr>,<satype>[,<time>]]]** **[...]** **OK** If no call forwarding number is registered (and therefore all classes are inactive): **+CCFC: <status>,<class>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**

Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<reads>	Integer type. Call forwarding condition. 0 Unconditional 1 Mobile busy 2 No reply 3 Not reachable 4 All call forwarding (see *3GPP TS 22.030*) 5 All conditional call forwarding (see *3GPP TS 22.030*)
<mode>	Integer type. Operation type. 0 Disable 1 Enable 2 Query status 3 Registration 4 Erasure
<number>	String type. Phone number of forwarding address in format specified by **<type>**.
<type>	Integer type. Address type. The default value is 145 when the dialing string includes international access code character "+"; otherwise 129.
<subaddr>	String type. Sub-address in the format specified by **<satype>**.
<satype>	Integer type. Sub-address type.
<classx>	Integer type. Each represents a class of information. 1 Voice (telephony) 2 Data (various bearer services included, with exceptions in cases where TA does not support values 16, 32, 64 and 128 with **<mode>**=2) 4 Fax (facsimile services) 7 Voice, data and fax 8 Short message service 16 Data circuit synchronization 32 Data circuit asynchronization 64 Dedicated packet access 128 Dedicated PAD access
<time>	Integer type. Time in seconds to wait before a call is forwarded when "no reply", "all call forwarding" or "all conditional call forwarding" is enabled or queried. Range: 1–30. Default value: 20
<status>	Integer type. 0 Not active 1 Active
<err>	Error codes. For more details, see ***Chapter 13.5***.

Example

```
AT+CCFC=0,3,"15021012496"          //Register the destination number for unconditional call
OK                                   forwarding (CFU).
AT+CCFC=0,2                        //Query the status of CFU without specifying <class>.
+CCFC: 1,1,"+8615021012496",145,,,

OK
AT+CCFC=0,4                        //Erase the registered CFU destination number.
OK
AT+CCFC=0,2                        //Query the status and there is no destination number.
+CCFC: 0,255

OK
```

10.2 AT+CCWA Call Waiting Control

This command allows control of the call waiting supplementary service according to *3GPP TS 22.083*. Activation, deactivation and status query are supported.

AT+CCWA Call Waiting Control	
Test Command **AT+CCWA=?**	Response **+CCWA: (**list of supported **<n>**s**)** **OK**
Read Command **AT+CCWA?**	Response **+CCWA: <n>** **OK**
Write Command **AT+CCWA=[<n>[,<mode>[,<class>]]]**	Response If **<mode>** is not equal to 2 and the command is executed successfully: **OK** If **<mode>**=2 and the command is executed successfully: **+CCWA: <status>,<class1>** **[+CCWA: <status>,<class2>** **[...]]** **OK** If there is any error:

	ERROR Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Enable or disable URC presentation. When call waiting is enabled and active on MT, and a terminating call occurs during an ongoing call, an URC is returned in the following format: **+CCWA: <number>,<type>,<class>[,<alpha>][,<CLI_validity>[,<subaddr>,<satype>[,<priority>]]]** 0 Disable 1 Enable
<mode>	Integer type. When **<mode>** is omitted, network is not interrogated. 0 Disable 1 Enable 2 Query status
<class>	Integer type. Each represents a class of information. 1 Voice (telephony) 2 Data (various bearer services included, with exceptions in cases where TA does not support values 16, 32, 64 and 128 with **<mode>**=2) 4 Fax (facsimile services) 7 Voice, data and fax 8 Short message service 16 Data circuit synchronization 32 Data circuit asynchronization 64 Dedicated packet access 128 Dedicated PAD access
<status>	Integer type. It indicates whether the status of the command is enabled or not. 0 Disable 1 Enable
<number>	String type. Phone number of calling address in format specified by **<type>**.
<type>	Integer type. Address type in octet. 128 Type specified by the network 129 Unknown type (ISDN format number) 145 International number type (ISDN format)
<alpha>	Optional string type. Alphanumeric representation of **<number>** corresponding to the entry found in the phonebook.
<CLI_validity>	Integer type. Reason why **<number>** does not contain a calling party BCD number

	(see *3GPP TS 24.008 subclause 10.5.4.30*). 0 CLI valid 1 CLI has been withheld by the originator (see *3GPP TS 24.008 table 10.5.135a/3GPP TS 24.008* code "Reject by user") 2 CLI is not available due to interworking problems or limitations of originating network (see *3GPP TS 24.008 table 10.5.135a/3GPP TS 24.008* code "Interaction with other service") 3 CLI is not available due to calling party being of type payphone (see *3GPP TS 24.008 table 10.5.135a/3GPP TS 24.008* code "Coin line/payphone") 4 CLI is not available due to other reasons (see *3GPP TS 24.008 table 10.5.135a/3GPP TS 24.008* code "Unavailable") If CLI is unavailable (**<CLI_validity>**=2, 3 or 4), **<number>** is an empty string ("") and **<type>** will not be significant. Nevertheless, TA may return the recommended value 128 for **<type>** (TON/NPI unknown in accordance with 3*GPP TS 24.008 subclause 10.5.4.7*). When CLI has been withheld by the originator, (**<CLI_validity>**=1) and CLIP is provisioned with the "override category" option (see *3GPP TS 22.081 and 3GPP TS 23.081*), both **<number>** and **<type>** are provided. Otherwise, TA returns the same setting for **<number>** and **<type>** as if the CLI is unavailable.
<subaddr>	String type. Sub-address of format specified by **<satype>**.
<satype>	Integer type. Sub-address in octet (see *3GPP TS 24.008 subclause 10.5.4.8*).
<priority>	Optional digit type. eMLPP priority level of the incoming call. Priority level value is as defined in eMLPP specification *3GPP TS 22.067*.
<err>	Error codes. For more details, see ***Chapter 13.5***.

NOTE

1. **<status>**=0 should be returned only if the service is not active for any **<class>**, i.e., **+CCWA: 0,7** will be returned in this case.
2. When **<mode>**=2, all active call waiting classes will be reported. In this mode the command is aborted by pressing any key.
3. Executing **AT+CCWA=<n>,<mode>,<class>** writes data to NVM. Please proceed with caution.

Example

```
AT+CCWA=1,1                          //Enable URC presentation.
OK
ATD10086;                            //Establish a call.
OK

+CCWA: "02154450293",129,1           //Waiting call.
```

10.3 AT+CHLD Call-Related Supplementary Services

This command allows the control of the following call related services:

- Temporary disconnection of a call from MT, while retaining the connection with the network;
- Multiparty conversation (conference calls);
- The served subscriber with two calls (one on hold and the other either active or alerting) can connect other parties and release their own connection.

Calls can be put on hold, recovered, released and added to a conversation, and transferred similarly as defined in *3GPP TS 22.030*.

This is based on the GSM/UMTS supplementary services:

- HOLD (Call Hold; see *3GPP TS 22.083 clause 2*);
- MPTY (MultiParty; see *3GPP TS 22.084*);
- ECT (Explicit Call Transfer; see *3GPP TS 22.091*).

The interaction of this command with other commands based on other GSM/UMTS supplementary services is described in the GSM/UMTS standards. Call Hold, MultiParty and Explicit Call Transfer are only applicable to teleservice 11.

AT+CHLD Call-Related Supplementary Services	
Test Command **AT+CHLD=?**	Response **+CHLD: (**list of supported **<n>**s**)** **OK**
Write Command **AT+CHLD=[<n>]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. 0 Terminate all held calls or UDUB (User Determined User Busy) for a waiting call.

		If a call is waiting, terminate the waiting call. Otherwise, terminate all held calls (if any)
	1	Terminate all active calls (if any) and accept the other call (waiting call or held call).
	1X	Terminate the specific call number X (X = 1–7)
	2	Place all active calls on hold (if any) and accept the other call (waiting call or held call) as the active call.
	2X	Place all active calls except call X (X = 1–7) on hold
	3	Add the held call to active calls
	4	Connect the two calls and disconnect the subscriber from both calls (ECT)
<err>	Error codes. For more details, see ***Chapter 13.5***.	

Example

```
ATD10086;                                  //Establish a call.
OK

+CCWA: "02154450293",129,1                 //Indication of a waiting call.
AT+CHLD=2                                  //Place the active call on hold and accept the waiting call as
                                             the active call.
OK
AT+CLCC
+CLCC: 1,0,1,0,0,"10086",129               //The first call is on hold.
+CLCC: 2,1,0,0,0,"02154450293",129         //The second call is active.

OK
AT+CHLD=21                                 //Place the active call except call X = 1 on hold.
OK
AT+CLCC
+CLCC: 1,0,0,0,0,"10086",129               //The first call is active.
+CLCC: 2,1,1,0,1,"02154450293",129         //The second call is on hold.

OK
AT+CHLD=3                                  //Add a held call to active calls to set up a conference
                                             (multiparty) call.
OK
AT+CLCC
+CLCC: 1,0,0,0,1,"10086",129
+CLCC: 2,1,0,0,1,"02154450293",129

OK
```

10.4 AT+CLIP Present Calling Line Identification

This command refers to the GSM/UMTS supplementary service CLIP (Calling Line Identification Presentation) that enables a called subscriber to get the calling line identity (CLI) of the calling party when receiving a mobile terminated call. It has no effect on the execution of the supplementary service CLIP in the network.

AT+CLIP Present Calling Line Identification	
Test Command **AT+CLIP=?**	Response **+CLIP: (**list of supported **<n>**s**)** **OK**
Read Command **AT+CLIP?**	Response **+CLIP: <n>,<m>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Write Command **AT+CLIP=[<n>]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	15 s, determined by network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Enable or disable reporting of URC presentation status to TE. When the CLIP presentation at TE is enabled (and permitted by the calling subscriber), an URC is returned after every **RING** (or **+CRING: <type>**) at a mobile terminating call: **+CLIP: <number>,<type>,[subaddr],[satype],[<alpha>],<CLI_validity>** 0 Disable URC 1 Enable URC
<m>	Integer type. Subscriber CLIP service status in the network.

	0	CLIP not provisioned
	1	CLIP provisioned
	2	Unknown (e.g., no network, etc.)
<number>	String type. Phone number calling address in format specified by **<type>**.	
<subaddr>	String type. Sub-address of format specified by **<satype>**.	
<satype>	Integer type. Sub-address type in octet (see *3GPP TS 24.008 subclause 10.5.4.8*).	
<type>	Integer type. Address type in octet.	
	129	Unknown type (ISDN format)
	145	International number type (ISDN format)
	161	National number
<alpha>	String type. Alphanumeric representation of **<number>** corresponding to the entry found in phone book.	
<CLI_validity>	Integer type. Reason why **<number>** does not contain a calling party BCD number.	
	0	CLI valid
	1	CLI has been withheld by the originator
	2	CLI is not available due to interworking problems or limitations of originating network
<err>	Error codes. For more details, see ***Chapter 13.5***.	

Example

```
AT+CLIP=1
OK

RING

+CLIP: "02151082965",129,,,"QUECTEL",0
```

10.5 AT+CLIR Restrict Calling Line Identification

This command refers to the CLIR (Calling Line Identification Restriction) supplementary service according to *3GPP TS 22.081* and the OIR (Originating Identification Restriction) supplementary service according to *3GPP TS 24.607* that allows a calling subscriber to enable or disable the presentation of the calling line identity (CLI) to the called party when originating a call.

The Write Command overrides the CLIR subscription (default is restricted or allowed) when temporary mode is provisioned as a default adjustment for all following outgoing calls. This adjustment can be revoked by using the opposite command.

AT+CLIR Restrict Calling Line Identification	
Test Command	Response
AT+CLIR=?	**+CLIR: (**list of supported **<n>**s**)**

	OK
Read Command **AT+CLIR?**	Response **+CLIR: <n>,<m>** **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Write Command **AT+CLIR=<n>**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	15 s, determined by network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Outgoing call adjustment.	
	0	Presentation indicator is used according to the subscription of the CLIR service
	1	CLIR invocation
	2	CLIR suppression
<m>	Integer type. Subscriber CLIR service status in the network.	
	0	CLIR not provisioned
	1	CLIR provisioned in permanent mode
	2	Unknown (e.g., no network, etc.)
	3	CLIR temporary mode presentation restricted
	4	CLIR temporary mode presentation allowed
<err>	Error codes. For more details, see ***Chapter 13.5***.	

10.6 AT+COLP Present Connected Line Identification

This command enables or disables a calling subscriber to get the connected line identity (COL) of the called party after setting up a mobile originated call, referring to the GSM/UMTS supplementary service

COLP (Connected Line Identification Presentation). MT enables or disables COL presentation at TE for a mobile originated call. It has no effect on the execution of the supplementary service COLR in the network.

AT+COLP Present Connected Line Identification	
Test Command **AT+COLP=?**	Response **+COLP: (**list of supported **<n>**s**)** **OK**
Read Command **AT+COLP?**	Response **+COLP: <n>,<m>** **OK**
Write Command **AT+COLP=[<n>]**	Response **OK** Or **ERROR**
Maximum Response Time	15 s, determined by network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Set/present the result code presentation status in MT. 0 Disable 1 Enable. When enabled (and permitted by the calling subscriber), an intermediate result code is returned before any +CR or V.25ter responses: **+COLP: <number>,<type>,[<subaddr>],[<satype>],[<alpha>]**
<m>	Integer type. Subscriber COLP service status in the network. 0 COLP not provisioned 1 COLP provisioned 2 Unknown (e.g., no network, etc.)
<number>	String type. Phone number; calling address in format specified by **<type>**.
<type>	Integer type. Address type in octet. 129 Unknown type (ISDN format number) 145 International number type (ISDN format)
<subaddr>	String type. Sub-address of format specified by **<satype>**.
<satype>	Integer type. Sub-address type in octet (see *3GPP TS 24.008 subclause 10.5.4.8*).
<alpha>	Optional string. Alphanumeric representation of **<number>** corresponding to the entry found in the phonebook.

Example

```
AT+COLP=1
OK
ATD02151082965;
+COLP: "02151082965",129,,,"QUECTEL"

OK
```

10.7 AT+CSSN Supplementary Service Notification

This command enables or disables the presentation of notification result codes from TA to TE.

AT+CSSN Supplementary Service Notification	
Test Command **AT+CSSN=?**	Response **+CSSN: (**list of supported **<n>**s**),(**list of supported **<m>**s**)** **OK**
Read Command **AT+CSSN?**	Response **+CSSN: <n>,<m>** **OK**
Write Command **AT+CSSN=<n>[,<m>]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<n>	Integer type. Enable or disable the **+CSSI** intermediate result code presentation status to TE. When **<n>**=1 and a supplementary service notification is received after a mobile originated call is set up, the **+CSSI: <code1>** intermediate result code is sent to TE before any other MO call setup result code. 0 Disable

	1 Enable
<m>	Integer type. Enable or disable the **+CSSU** URC presentation status to TE. When **<m>**=1 and a supplementary service notification is received during a mobile terminated call setup or during a call, the **+CSSU: <code2>** URC is sent to TE. 0 Disable 1 Enable
<code1>	Integer type. It is specified by manufacturer and supports the following codes: 0 Unconditional call forwarding is active 1 Some of the conditional call forwarding options are active 2 Call has been forwarded 3 Call is waiting 5 Outgoing call is barred
<code2>	Integer type. It is manufacturer specific and supports the following codes: 0 Incoming call is a forwarded call 2 Call has been put on hold (during a voice call) 3 Call has been retrieved (during a voice call) 5 Held call terminated by another party 10 Additional incoming call forwarded
<err>	Error codes. For more details, see ***Chapter 13.5***.

10.8 AT+CUSD Unstructured Supplementary Service Data

This command allows control of the USSD (Unstructured Supplementary Service Data) according to *3GPP TS 22.090*. Both network and mobile initiated operations are supported.

<mode> disables or enables the presentation of an URC. The value **<mode>**=2 cancels an ongoing USSD session. For USSD response from the network, or network initiated operation, the format is: **+CUSD: <status>[,<rspstr>,[<dcs>]]**.

When **<reqstr>** is given, a mobile-initiated USSD string or a response USSD string to a network-initiated operation is sent to the network. The response USSD string from the network is returned in a subsequent **+CUSD** URC.

AT+CUSD Unstructured Supplementary Service Data	
Test Command **AT+CUSD=?**	Response **+CUSD: (**list of supported **<mode>**s**)** **OK**
Read Command **AT+CUSD?**	Response **+CUSD: <mode>** **OK**

Write Command **AT+CUSD=[<mode>[,<reqstr>[,<dcs>]]]**	Response **OK** If there is any error: **ERROR** Or **+CME ERROR: <err>**
Maximum Response Time	120 s, determined by the network.
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<mode>	Integer type.Enable or disable the result code presentation status to TE. 0 Disable 1 Enable 2 Cancel session (not applicable to Read Command response)
<reqstr>	String type. USSD to be sent to the network. If this parameter is omitted, network is not queried.
<rspstr>	String type. USSD received from the network.
<dcs>	Integer type. See *3GPP TS 23.038* Cell Broadcast Data Coding Scheme (default value 15).
<status>	Integer type. USSD response from the network or the network-initiated operation. 0 No further user action required (network initiated USSD Notify, or no further information needed after mobile initiated operation) 1 Further user action required (network initiated USSD Request, or further information needed after mobile initiated operation) 2 USSD terminated by network 3 Another local client has responded 4 Operation not supported 5 Network time out
<err>	Error codes. For more details, see ***Chapter 13.5***.

11 Hardware-Related Commands

11.1 AT+QPOWD Power off

This command powers off MT. Once the command is executed successfully, UE returns **OK** immediately and deactivates the network. After the deactivation is completed, UE outputs **POWERED DOWN** and enters power-off state. The maximum time for unregistering network is 60 seconds. To avoid data loss, the power supply for the module cannot be disconnected before **POWERED DOWN** is outputted.

AT+QPOWD Power off	
Test Command **AT+QPOWD=?**	Response **+QPOWD: (**list of supported **<n>**s**)** **OK**
Write Command **AT+QPOWD=[<n>]**	Response **OK** **POWERED DOWN**
Maximum Response Time	300 ms
Characteristics	-
Reference	

Parameter

<n>	Integer type. 0 Immediate power-down 1 Normal power-down

11.2 AT+QADC Read ADC Value

This command reads the voltage value of ADC channel.

AT+QADC Read ADC Value	
Test Command **AT+QADC=?**	Response **+QADC: (**list of supported **<port>**s**)** **OK**
Read Command **AT+QADC=<port>**	Response **+QADC: <status>,<value>** **OK**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<port>	Integer type. ADC channel number. 0 ADC channel 0 1 ADC channel 1
<status>	Integer type. Whether the ADC value has been read successfully. 0 Failed 1 Successful
<value>	Integer type. Voltage of specified ADC channel. Unit: mV.

NOTE

This command is only supported on RG255C series module.

11.3 AT+CBC Battery Charge

The command returns battery charge status **<bcs>** and battery charge level **<bcl>** of MT.

AT+CBC Battery Charge	
Test Command **AT+CBC=?**	Response **+CBC: (**list of supported **<bcs>**s**),(**list of supported **<bcl>**s**),<voltage>**

	OK
Execution Command **AT+CBC**	Response **+CBC: <bcs>,<bcl>,<voltage>** **OK** If there is an error related to ME functionality: **+CME ERROR: <err>**
Maximum Response Time	300 ms
Characteristics	-
Reference	*3GPP TS 27.007*

Parameter

<bcs>	Integer type. Battery charge status	
	0	ME is not charging
	1	ME is charging
	2	Charging has been finished
<bcl>	Integer type. Battery charge level in percent. Range: 0–100.	
<voltage>	Battery voltage. Unit: mV.	
<err>	Error codes. For more details, see ***Chapter 13.5***.	

11.4 AT+QSCLK Set Sleep Mode

This command controls whether to enable the module to enter sleep mode. When sleep mode is enabled and MAIN_DTR is pulled up, the module can enter sleep mode directly. If sleep mode is enabled and MAIN_DTR is pulled down, you need to pull up the MAIN_DTR pin first to make the module enter sleep mode.

AT+QSCLK Set Sleep Mode	
Test Command **AT+QSCLK=?**	Response **+QSCLK: (**list of supported **<n>**s**),(**list of supported **<saved>**s**)** **OK**
Read Command **AT+QSCLK?**	Response **+QSCLK: <n>,<saved>**

	OK
Write Command **AT+QSCLK=<n>[,<saved>]**	Response **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately.
Reference	Quectel

Parameter

<n>	Integer type. Enable or disable sleep mode. 0 Disable 1 Enable. It is controlled by MAIN_DTR. MAIN_DTR is pulled up by default.
<saved>	Integer type. Whether to save the configuration into NVM. 0 Not save 1 Save

NOTE

Executing **AT+QSCLK=0,1** or **AT+QSCLK=1,1** writes data to NVM. Please proceed with caution.

12 QMAP-Related Commands

12.1 AT+QMAP Configure QMAP-Related Parameters

This command configures the QMAP-related parameters.

AT+QMAP Configure QMAP-Related Parameters	
Test Command **AT+QMAP=?**	Response **+QMAP: "WWAN",(**list of supported **<status>**s**),(**list of supported **<profileID>**s**),(**list of supported **<IP_family>**s**),<IP_address>** **+QMAP: "DMZ",(**list of supported **<enable>**s**),(**list of supported **<IP_family>**s**),<IP_address>** **+QMAP: "LANIP",<LAN_IP_start_address>,<LAN_IP_end_address>,<GW_IP_address>** **+QMAP: "VLAN",(**list of supported **<VLAN_ID>**s**),(**list of supported **<enable>**s**),(**list of supported **<VLAN_type>**s**)** **+QMAP: "MPDN_rule",(**list of supported **<rule_num>**s**),(**list of supported **<profileID>**s**),(**list of supported **<VLAN_ID>**s**),(**list of supported **<IPPT_mode>**s**),(**list of supported **<auto_connect>**s**),<IPPT_info>** **+QMAP: "IPPT_NAT",(**list of supported **<IPPT_NAT>**s**)** **+QMAP: "connect",(**list of supported **<rule_num>**s**),(**list of supported **<connect>**s**)** **+QMAP: "auto_connect",(**list of supported **<rule_num>**s**),(**list of supported **<auto_connect>**s**),(**list of supported **<profileID>**s**)** **+QMAP: "MPDN_status"** **+QMAP: "NAT_timeout",(**list of supported **<NAT_type>**s**),<timeout>** **…** **OK**
Maximum Response Time	300 ms
Characteristics	-

12.2 AT+QMAP="WWAN" Query IP Address of Default QMAP Data Call

This command queries the status and IP address of the default QMAP data call.

AT+QMAP="WWAN"	Query IP Address of Default QMAP Data Call
Write Command **AT+QMAP="WWAN"**	Response **+QMAP: "WWAN",<status>,<profileID>,<IP_family>,<IP_address>** **+QMAP: "WWAN",<status>,<profileID>,<IP_family>,<IP_address>** **OK** If there is any error: **ERROR**
Maximum Response Time	5 s
Characteristics	-

Parameter

<status>	Integer type. Status of default QMAP data call. 0 Disconnected 1 Connected
<profileID>	Integer type. Profile ID of default QMAP data call. Range: 1–16.
<IP_family>	String type. IP type. "IPV4" IPv4 "IPV6" IPv6
<IP_address>	String type. IP address of default QMAP data call. If IPv4 network is not connected, the address is "0.0.0.0". If IPv6 network is not connected, the address is "0:0:0:0:0:0:0:0".

Example

```
AT+QMAP="WWAN"                  //Query IP address of default QMAP data call
+QMAP: "WWAN",0,1,"IPV4","0.0.0.0"
+QMAP: "WWAN",0,1,"IPV6","0:0:0:0:0:0:0:0"

OK
```

12.3 AT+QMAP="DMZ" Query/Set DMZ of Default QMAP Data Call

This command queries or sets DMZ (Demilitarized Zone) of the default QMAP data call.

AT+QMAP="DMZ" Query/Set DMZ of Default QMAP Data Call	
Write Command **AT+QMAP="DMZ"[,<enable>,<IP_family>[,<IP_address>]]**	Response If the optional parameters are omitted, query the current setting. **+QMAP: "DMZ",<enable>,<IP_family>[,<IP_address>]** **+QMAP: "DMZ",<enable>,<IP_family>[,<IP_address>]** **OK** If the optional parameters are specified, enable and configure or disable DMZ. **OK** If there is any error: **ERROR**
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<enable>	Integer type. Enable or disable DMZ of default QMAP data call. 0 Disable 1 Enable
<IP_family>	Integer type. IP type. 4 IPv4 6 IPv6
<IP_address>	String type. Dotted decimal IPv4 or IPv6 address without double quotes. It is valid only when **<enable>** is 1.

NOTE

1. After DMZ is enabled, to change the DMZ address, disable DMZ first.
2. Executing **AT+QMAP="DMZ"[,<enable>,<IP_family>[,<IP_address>]]** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="DMZ"                          //Query the current setting of DMZ.
+QMAP: "DMZ",0,4
+QMAP: "DMZ",0,6

OK
AT+QMAP="DMZ",1,4,192.168.225.50       //Enable DMZ of IPv4 and the address is 192.168.225.50.
OK
AT+QMAP="DMZ",0,4                      //Disable DMZ of IPv4.
OK
```

12.4 AT+QMAP="LANIP" Query/Modify DHCP Address Pool of Default LAN Interface

This command queries or modifies DHCP address pool of the default LAN interface (VLAN0).

AT+QMAP="LANIP" Query/Modify DHCP Address Pool of Default LAN Interface	
Write Command **AT+QMAP="LANIP"[,<LAN_IP_start_address>,<LAN_IP_end_address>,<GW_IP_address>]**	Response If the optional parameters are omitted, query the current setting. **+QMAP: "LANIP",<LAN_IP_start_address>,<LAN_IP_end_address>,<GW_IP_address>** **OK** If the optional parameters are specified, set DHCP address pool of the default LAN interface. **OK** If there is any error: **ERROR**
Maximum Response Time	5 s
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<LAN_IP_start_address>	String type. Start address of DHCP address pool of default LAN interface. Format: Dotted decimal IPv4 address without double quotes.
<LAN_IP_end_address>	String type. End address of DHCP address pool of default LAN interface.

<GW_IP_address>	Format: Dotted decimal IPv4 address without double quotes. String type. Gateway address of DHCP address pool of default LAN interface. Format: Dotted decimal IPv4 address without double quotes.

NOTE

1. Executing **AT+QMAP="LANIP"[,<LAN_IP_start_address>,<LAN_IP_end_address>,<GW_IP_address>]** writes data to NVM. Please proceed with caution.
2. The third octet of **<GW_IP_address>** cannot be an odd number.

Example

```
AT+QMAP="LANIP"          //Query the current setting of DHCP address pool.
+QMAP: "LANIP",192.168.225.40,192.168.225.60,192.168.224.1

OK
//Set the DHCP address pool and the setting takes effect immediately.
AT+QMAP="LANIP",192.168.111.20,192.168.111.60,192.168.110.1
OK
```

12.5 AT+QMAP="VLAN" Query/Set VLAN

This command queries or sets VLAN of the module, including enabling or disabling VLAN and querying current enabled VLAN.

AT+QMAP="vlan" Query/Set VLAN	
Write Command **AT+QMAP="VLAN"[,<VLAN_ID>,<enable>[,<VLAN_type>]]**	Response If the optional parameters are omitted, query the enabled VLAN. **+QMAP: "VLAN",0** **+QMAP: "VLAN",<VLAN_ID1>,<VLAN_type1>** **[[+QMAP: "VLAN",<VLAN_ID2>,<VLAN_type2>]** **[…]]** If any of the optional parameters is specified, enable or disable the specified VLAN. **OK** If there is any error: **ERROR**
Maximum Response Time	5 s
Characteristics	See the note below for whether the command takes effect

	immediately or not. The configurations are saved automatically.

Parameter

<VLAN_ID>	Integer type. VLAN ID. Range: 0, 2–255. The value 0 is displayed only in the response string, indicating the default physical LAN interface rather than a VLAN ID. This LAN interface cannot be disabled.
<enable>	String type. Enable or disable VLAN specified by **<VLAN_ID>**. "enable" Enable "disable" Disable
<VLAN_type>	Integer type. VLAN type. It is valid only when **<enable>** is "enable". 1 ETH 2 ECM 3 RNDIS 4 ETH2 11 ETH without enabling VLAN data acceleration 12 ECM without enabling VLAN data acceleration 13 RNDIS without enabling VLAN data acceleration

NOTE

1. If **<VLAN_type>**=1/2/3/4, the module reboots automatically when you enable the first VLAN of any type or disable the last VLAN of the specified type.
2. In other conditions, VLAN enabling or disabling takes effect immediately and the module does not reboot automatically.
3. Executing **AT+QMAP="VLAN"[,<VLAN_ID>,<enable>[,<VLAN_type>]]** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="VLAN"                  //Query the list of the enabled VLAN IDs.
+QMAP: "VLAN",0
+QMAP: "VLAN",2,1               //VLAN 2 (eth0.2) of ETH is enabled.
+QMAP: "VLAN",3,1               ///VLAN 3 (eth0.3) of ETH is enabled.

OK
AT+QMAP="VLAN",4,"enable",1     //Enable VLAN 4 (eth0.4) of ETH.
OK
AT+QMAP="VLAN",4,"disable"      //Disable VLAN 4 (eth0.4) of ETH.
OK
```

12.6 AT+QMAP="MPDN_rule" Query/Modify QMAP Multiple Data Call Rule

This command queries or modifies the QMAP multiple data call rules.

AT+QMAP="MPDN_rule" Query/Modify QMAP Multiple Data Call Rule	
Write Command **AT+QMAP="MPDN_rule"[,<rule_num>[,<profileID>,<VLAN_ID>,<IPPT_mode>,<auto_connect>[,<IPPT_info>]]]**	Response If the optional parameters are omitted, query the current setting. **+QMAP: "MPDN_rule",<rule_num>,<profileID1>,<VLAN_ID>,<IPPT_mode>,<auto_connect>** **+QMAP: "MPDN_rule",<rule_num>,<profileID1>,<VLAN_ID>,<IPPT_mode>,<auto_connect>** **+QMAP: "MPDN_rule",<rule_num>,<profileID1>,<VLAN_ID>,<IPPT_mode>,<auto_connect>** **+QMAP: "MPDN_rule",<rule_num>,<profileID1>,<VLAN_ID>,<IPPT_mode>,<auto_connect>** **OK** If only **<rule_num>** is specified, disable a specified QMAP data call rule. **OK** If any of the optional parameters is specified, set the specified QMAP data call rule. **OK** If there is any error: **ERROR**
Maximum Response Time	5 s
Characteristics	See the note below for whether the command takes effect immediately or not. The configurations are saved automatically.

Parameter

<rule_num>	Integer type. Rule ID of QMAP multiple data call. Range: 0–3.
<profileID>	Integer type. APN profile ID used by QMAP data call rule. Range: 1–16.
<VLAN_ID>	Integer type. VLAN ID used by QMAP data call rule. Range: 0, 2–255. 0 is displayed only in the response string and indicates the physical default LAN

	interface rather than a VLAN ID.
<IPPT_mode>	Integer type. Enable or disable IPPT mode (IP Passthrough mode) in QMAP data call rule. 0 Disable IPPT mode 1 Enable IPPT mode (ETH) 2 Enable IPPT mode (Wi-Fi) 3 Enable IPPT mode (USB-ECM/RNDIS) 4 Enable IPPT mode (Any Device)
<auto_connect>	Integer type. Enable or disable automatic connection in QMAP data call rule. 1 Enable 0 Disable
<IPPT_info>	String type. If **<IPPT_mode>** is 0, **<IPPT_info>** does not need to be filled in. If **<IPPT_mode>** is 1, **<IPPT_info>** is the peer NIC MAC address bound in IPPT mode. ● If **<IPPT_info>** is set to "FF:FF:FF:FF:FF:FF", the module will always deliver the public network address to the newly connected ETH device. ● If **<IPPT_info>** is set to "00:00:00:00:00:00", the module will only deliver the public network address to the first connected ETH device. ● If **<IPPT_info>** is set to the MAC address of an ethernet device, the module will only deliver the public network address to the ETH device. If **<IPPT_mode>** is 2, **<IPPT_info>** is the peer NIC MAC address bound in IPPT mode. ● If **<IPPT_info>** is set to "FF:FF:FF:FF:FF:FF", the module will always deliver the public network address to the newly connected Wi-Fi device. ● If **<IPPT_info>** is set to "00:00:00:00:00:00", the module will only deliver the public network address to the first connected Wi-Fi device. ● If **<IPPT_info>** is set to the MAC address of a Wi-Fi device, the module will only deliver the public network address to the Wi-Fi device. If **<IPPT_mode>** is 3, **<IPPT_info>** is the peer host name or NIC MAC address bound in IPPT mode. ● If **<IPPT_info >** is set to "FF:FF:FF:FF:FF:FF", the module will always deliver the public network address to the newly connected USB device. ● If **<IPPT_info>** is set to "00:00:00:00:00:00", the module will only deliver the public network address to the first connected USB device. ● If **<IPPT_info>** is set to the NIC MAC address of the host's USB network card, the module will only deliver the public network address to the USB device ● When using the first three methods, please ensure that the NIC MAC address of the host's USB network card (ECM/RNDIS) remains unchanged, otherwise the module will consider it a different device. ● If **<IPPT_info>** is set to the hostname of a USB device, the module will only

deliver the public network address to the USB device.

If **<IPPT_mode>** is 4, **<IPPT_info>** means that the module can deliver the public IP address to any device with any interface type. The value can only be set as follows:

- If **<IPPT_info>** is set to "FF:FF:FF:FF:FF:FF", the module will always deliver the public IP address to the latest connected device of any interface type.
- If **<IPPT_info>** is set to "00:00:00:00:00:00", the module will only deliver the public network address to the first connected device of any interface type.
- In this case **<IPPT_info>** cannot be set to other values.

When IPPT mode is enabled,

- If the IPPT NAT working mode is WithNAT (**AT+QMAP="IPPT_NAT",1**), the LAN device specified by **<IPPT_info>** will obtain the public network address, other LAN devices will obtain the private network address, and the module will perform network address translation on all LAN device data.
- If the IPPT NAT working mode is WithoutNAT (**AT+QMAP="IPPT_NAT",0**), the LAN device specified by **<IPPT_info>** will obtain the public network address, and the module will not perform network address translation on the data of the LAN device, and other LAN devices will not obtain any IP addresses. In addition, in this mode, the IPPT function, as applied to the latest devices, will be invalid, and "FF:FF:FF:FF:FF:FF" will be treated as equivalent to "00:00:00:00:00:00".

NOTE

1. If only the physical default LAN interface is required to access network and there is no need to support QMAP multiple data call, you should set **<rule_num>**=0 and **<VLAN_ID>**=0.
2. The QMAP multiple data call is implemented by binding the WAN interfaces obtained from data calls of different APNs to the LAN/VLAN interface, and implementing the NAT configuration between the corresponding WAN and LAN/VLAN. In this way, the devices under different LAN/VLAN interfaces can access different network through the corresponding WAN interface.
3. When configuring QMAP data call rule, if you need to use a VLAN interface (**<VLAN_ID>** is not 0), you need to create a corresponding VLAN interface through **AT+QMAP="VLAN"** first.
4. IPPT mode (IP Passthrough mode), is a function of transparently transmitting the IP address (Public IP) assigned by the operator to the LAN device.
5. By default, when using a USB (ECM/RNDIS) interface to start a QMAP data call, if the IPPT mode is enabled, you need to set **<IPPT_mode>** to 3, and set the hostname of the LAN device in **<IPPT_info>**. In most cases, the MAC address of the USB virtual Ethernet interface (ECM/RNDIS) is not fixed. However, the module supports IPPT mode by setting **<IPPT_mode>** to 1 and setting the MAC address of the LAN USB device in **<IPPT_info>** in actual use.
6. WLAN interface does not support VLAN function, WLAN belongs to VLAN0. In actual use, to assign the public IP to the WLAN device, you need to set **<IPPT_mode>** to 2, and **<VLAN_ID>** can only be 0.
7. By default, the data call initiated with the first rule (**<rule_num>**=0) is the default QMAP data call.

8. The default QMAP data call is bound to the physical LAN interface (VLAN0) by default. If you change the bound LAN/VLAN interface of the default QMAP data call, the module reboots automatically. For example, execute **AT+QMAP="MPDN_rule",0,1,2,0,1** (bind the default QMAP data call rule to **<VLAN_ID>**=2). If **AT+QMAP="MPDN_rule",0** is executed to disable the default QMAP data call rule, the LAN/VLAN interface bound to the default QMAP data call rule automatically changes the physical LAN interface from **<VLAN_ID>**=2, and the module reboots automatically.
9. The module accesses the network through the data connection initiated by the default QMAP data call rule. That is, if **<rule_num>**=0 does not initiate a data connection, the module cannot access network.
10. When using adaptive IPPT with **<IPPT_mode>**=1, 2 or 3 and setting the NIC MAC to "FF:FF:FF:FF:FF:FF", only one LAN device with the specific type can be connected, while multiple other LAN devices that are not of the aforementioned specific type are allowed to be connected;
    When using adaptive IPPT with **<IPPT_mode>**=4 and setting the NIC MAC to "FF:FF:FF:FF:FF:FF", only one LAN device of ETH, Wi-Fi and USB-ECM/RNDIS can be connected, others are not allowed to be connected.
11. Executing **AT+QMAP="MPDN_rule"[,<rule_num>[,<profileID>,<VLAN_ID>,<IPPT_mode>,<auto_connect>[,<IPPT_info>]]]** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="MPDN_rule"                    //Query the current QMAP data call rules.
+QMAP: "MPDN_rule",0,0,0,0,0
+QMAP: "MPDN_rule",1,0,0,0,0
+QMAP: "MPDN_rule",2,0,0,0,0
+QMAP: "MPDN_rule",3,0,0,0,0

OK
AT+QMAP="MPDN_rule",0,1,0,0,1          //Configure and enable QMAP data call rule 0.
OK
AT+QMAP="MPDN_rule",1,5,2,0,1          //Configure and enable QMAP data call rule 1.
OK
AT+QMAP="MPDN_rule"                    //Query the current QMAP data call rules.
+QMAP: "MPDN_rule",0,1,0,0,1
+QMAP: "MPDN_rule",1,5,2,0,1
+QMAP: "MPDN_rule",2,0,0,0,0
+QMAP: "MPDN_rule",3,0,0,0,0

OK
AT+QMAP="MPDN_rule",1                  //Disable QMAP data call rule 1.
OK
AT+QMAP="MPDN_rule"                    //Query the current QMAP data call rules.
+QMAP: "MPDN_rule",0,1,0,0,1
+QMAP: "MPDN_rule",1,0,0,0,0
```

```
+QMAP: "MPDN_rule",2,0,0,0,0
+QMAP: "MPDN_rule",3,0,0,0,0

OK
```

12.7 AT+QMAP="IPPT_NAT" Query/Set IPPT NAT Working Mode of QMAP Data Call

This command queries or configures whether to use NAT (Network Address Translation) in IPPT mode.

AT+QMAP="IPPT_NAT" Query/Set IPPT NAT Working Mode of QMAP Data Call	
Write Command **AT+QMAP="IPPT_NAT"[,<IPPT_NAT>]**	Response If the optional parameter is omitted, query the current setting. **+QMAP: "IPPT_NAT",<IPPT_NAT>** **OK** If the optional parameter is specified, set IPPT NAT working mode. **OK** If there is any error: **ERROR**
Maximum Response Time	-
Characteristics	The command takes effect immediately. The configuration is saved automatically.

Parameter

<IPPT_NAT>	Integer type. IPPT NAT working mode. 0 WihoutNAT. NAT is not used in IPPT mode. 1 WithNAT. NAT is used in IPPT mode.

NOTE

1. Changing IPPT NAT working mode disconnects all QMAP data call connections. The disconnected QMAP data call can be reconnected automatically if automatic connection is enabled. If automatic connection is disabled, manually execute **AT+QMAP="connect"** to start a QMAP data call after changing IPPT NAT working mode.

2. If you change the IPPT NAT working mode to WithoutNAT from WithNAT, the IPPT modes configured in all QMAP data call rules change to WithoutNAT automatically. If you change the IPPT NAT working mode to WithNAT from WithoutNAT, the IPPT modes configured in all QMAP data call rules change to WithNAT automatically.
3. Executing **AT+QMAP="IPPT_NAT"** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="IPPT_NAT"                  //Query current configuration.
+QMAP: "IPPT_NAT",0

OK
AT+QMAP="IPPT_NAT",1                //Set to using NAT in IPPT mode.
OK
```

12.8 AT+QMAP="connect" Initiate/Terminate QMAP Data Call

This command initiates or terminates a QMAP data call.

AT+QMAP="connect" Initiate/Terminate QMAP Data Call	
Write Command **AT+QMAP="connect",<rule_num>,<connect>**	Response **OK** Or **ERROR**
Maximum Response Time	5 s
Characteristics	-

Parameter

<rule_num>	Integer type. Rule ID of QMAP multiple data call. Range: 0–3.
<connect>	Integer type. Initiate or terminate QMAP data call. 0 Terminate 1 Initiate

NOTE

1. If **<auto_connect>**=1 (see **AT+QMAP="MPDN_rule"**), the specified QMAP data call rule initiates an automatic data call, and you cannot initiate or terminate this data connection over **AT+QMAP="connect"**. If you want to control QMAP data call manually with **AT+QMAP="connect"**,

you should disable automatic connection in the rule with **AT+QMAP="MPDN_rule"**.

2. Executing **AT+QMAP="connect",<rule_num>,<connect>** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="connect",0,1          //Initiate QMAP data call of rule 0.
OK
AT+QMAP="connect",0,0          //Terminate QMAP data call of rule 0.
OK
```

12.9 AT+QMAP="auto_connect" Query/Modify Automatic Connection of QMAP Data Call

This command queries or modifies automatic connection of QMAP data call.

AT+QMAP="auto_connect"	Query/Modify Automatic Connection of QMAP Data Call
Write Command **AT+QMAP="auto_connect"[,<rule_num>[,<auto_connect>[,<profileID>]]]**	Response If the optional parameters are omitted, query the current settings of all QMAP data call rules. **+QMAP: "auto_connect",<rule_num>,<auto_connect>** **+QMAP: "auto_connect",<rule_num>,<auto_connect>** **+QMAP: "auto_connect",<rule_num>,<auto_connect>** **+QMAP: "auto_connect",<rule_num>,<auto_connect>** **OK** If only **<rule_num>** is specified, query the current setting of the specified QMAP data call rule. **+QMAP: "auto_connect",<rule_num>,<auto_connect>** **OK** If only **<rule_num>** and **<auto_connect>** are specified, enable or disable automatic connection for the specified QMAP data call rule. **OK** If all optional parameters are specified, enable automatic connection and set the APN Profile ID, or disable automatic

	connection for the specified QMAP data call rule. **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	The command takes effect immediately. The configuration are saved automatically.

Parameter

<rule_num>	Integer type. Rule ID of QMAP multiple data call. Range: 0–3.
<auto_connect>	Integer type. Enable or disable automatic connection in the QMAP data call. 0 Disable 1 Enable
<profileID>	Integer type. APN Profile ID used by the QMAP data call rule. Range: 1–16.

NOTE

1. Before modifying **<auto_connect>** of the specified QMAP data call rule, first ensure that the specified rule has been configured and enabled with **AT+QMAP="MPDN_rule"** in advance.
2. Executing **AT+QMAP="auto_connect"[,<rule_num>[,<auto_connect>[,<profileID>]]]** writes data to NVM. Please proceed with caution.

Example

```
AT+QMAP="auto_connect"          //Query the current setting.
+QMAP: "auto_connect",0,1
+QMAP: "auto_connect",1,0
+QMAP: "auto_connect",2,0
+QMAP: "auto_connect",3,0

OK
AT+QMAP="auto_connect",0        //Query automatic connection of rule 0.
+QMAP: "auto_connect",0,1

OK
AT+QMAP="auto_connect",1,1      //Set automatic connection of rule 1.
OK
AT+QMAP="auto_connect",2,1,6    //Set automatic connection of rule 2 and modify <profileID> to 6.
OK
```

12.10 AT+QMAP="MPDN_status" Query QMAP Multiple Data Call Status

This command queries status of QMAP multiple data call.

AT+QMAP="MPDN_status"	Query QMAP Multiple Data Call Status
Write Command **AT+QMAP="MPDN_status"**	Response **+QMAP: "MPDN_status",<rule_num>,<profileID>,<IPPT_status>,<connect_status>** **+QMAP: "MPDN_status",<rule_num>,<profileID>,<IPPT_status>,<connect_status>** **+QMAP: "MPDN_status",<rule_num>,<profileID>,<IPPT_status>,<connect_status>** **+QMAP: "MPDN_status",<rule_num>,<profileID>,<IPPT_status>,<connect_status>** **OK** If there is any error: **ERROR**
Maximum Response Time	300 ms
Characteristics	-

Parameter

<rule_num>	Integer type. Rule ID of QMAP multiple data call. Range: 0–3.
<profileID>	Integer type. APN profile ID used by the QMAP data call rule. Range: 1–16.
<IPPT_status>	Integer type. Whether IPPT mode is enabled in QMAP data call rule. 0 Enabled 1 Disabled
<connect_status>	Integer type. Status of QMAP data call. 0 Disconnected 1 Connected

Example

```
AT+QMAP="MPDN_status"                    //Query status of QMAP multiple data call.
+QMAP: "MPDN_status",0,1,0,1,1
+QMAP: "MPDN_status",1,2,2,0,1
+QMAP: "MPDN_status",2,3,3,0,0
+QMAP: "MPDN_status",3,0,0,0,0
```

OK

12.11 AT+QMAP="NAT_timeout" Set NAT Timeout

This command sets or queries NAT timeout.

AT+QMAP="NAT_timeout" Set NAT Timeout	
Write Command **AT+QMAP="NAT_timeout"[,<NAT_type>[,<timeout>]]**	If the optional parameters are omitted, query the timeouts of all **<NAT_type>**s. **+QMAP: "NAT_timeout",1,<timeout>** **+QMAP: "NAT_timeout",2,<timeout>** **+QMAP: "NAT_timeout",3,<timeout>** **+QMAP: "NAT_timeout",4,<timeout>** **+QMAP: "NAT_timeout",6,<timeout>** **OK** If only **<NAT_type>** is specified, query the timeout of specified **<NAT_type>**. **+QMAP: "NAT_timeout",<NAT_type>,<timeout>** **OK** If all optional parameters are specified, set specified NAT timeout. **OK** If there is any error: **ERROR**
Maximum Response Time	150 ms
Characteristics	The command takes effect immediately. The configurations are saved automatically.

Parameter

<NAT_type>	Integer type. NAT timeout of each protocol type. 1 General NAT timeout. 2 NAT timeout of ICMP. 3 NAT timeout of TCP. 4 NAT timeout of UDP. 6 NAT timeout of ICMPv6.

<timeout>	Integer type. NAT timeout. Minimum value: 30. Unit: second.

Example

```
AT+QMAP="NAT_timeout",4          //Query the NAT timeout of UDP.
+QMAP: "NAT_timeout",4,360

OK
AT+QMAP="NAT_timeout",4,60       //Set the NAT timeout of UDP to 60 s.
OK
AT+QMAP="NAT_timeout"            //Query the NAT timeout of all <NAT_type>s.
+QMAP: "NAT_timeout",1,200
+QMAP: "NAT_timeout",2,30
+QMAP: "NAT_timeout",3,3600
+QMAP: "NAT_timeout",4,60
+QMAP: "NAT_timeout",6,30

OK
```

13 Appendix References

13.1 Terms and Abbreviations

Table 3: Terms and Abbreviations

Abbreviation	Description
3GPP	3rd Generation Partnership Project
5GCN	5G Core Network
5GS	5G System
ADC	Analog-to-Digital Converter
AP	Access Point
APDU	Application Protocol Data Unit
APN	Access Point Name
ARFCN	Absolute Radio-Frequency Channel Number
ARM	Advanced RISC (Reduced Instruction Set Computing) Machine
ASCII	American Standard Code for Information Interchange
BCD	Binary Coded Decimal
BER	Bit Error Rate
CBM	Cell Broadcast Message
CDRX	Connected Discontinuous Reception
CLI	Calling Line Identification
CLIP	Calling Line Identification Presentation

CLIR	Calling Line Identification Restriction
CNSS	Compass Navigation Satellite System (i.e., BDS - BeiDou Navigation Satellite System)
COL	Connected Line Identification
COLP	Connected Line Identification Presentation
COLR	Connected Line Identification Restriction
CQI	Channel Quality Indicator
CS	Circuit Switch
CSD	Circuit Switch Data
DCE	Data Communication Equipment
DCS	Data Coding Scheme
DF	Dedicated File
DFOTA	Delta Firmware Upgrade Over-The-Air
DHCP	Dynamic Host Configuration Protocol
DL	Downlink
DMZ	Demilitarized Zone
DNS	Domain Name Server
DPCH	Dedicated Physical Channel
DRX	Discontinuous Reception
DTE	Data Terminal Equipment
DTMF	Dual-Tone Multifrequency
DTR	Data Terminal Ready
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
ECC	Emergency Communications Center
ECGI	E-UTRAN Cell Global Identifier
ECI	E-UTRAN Cell Identifier

ECM	Ethernet Control Model
eNodeB	Evolved Node B
EPS	Evolved Packet System
ETH	Ethernet
E-UTRAN	Evolved Universal Terrestrial Radio Access Network
FDD	Frequency Division Duplex
FDPCH	Fraction-Dedicated Physical Channel
FOTA	Firmware Upgrade Over-The-Air
GGSN	Gateway GPRS Support Node
GMT	Greenwich Mean Time
GPIO	General-Purpose Input/Output
GPRS	General Packet Radio Service
GPS	Global Positioning System
GRE	Generic Routing Encapsulation
GSM	Global System for Mobile Communications
HLR	Home Location Register
HSDPA	High Speed Downlink Packet Access
HSUPA	High Speed Uplink Packet Access
ICCID	Integrated Circuit Card Identifier
ID	Mostly refers to Identifier in terms of software
IETF	The Internet Engineering Task Force
IMEI	International Mobile Equipment Identity
IMS	IP Multimedia Subsystem
IMSI	International Mobile Subscriber Identity
IP	Internet Protocol

IPA	IP Application Accelerator
IPPT	IP Passthrough
IPv4	Internet Protocol version 4
IPv6	Internet Protocol version 6
IRA	International Reference Alphabet
ISDN	Integrated Services Digital Network
ISIM	IP Multimedia Service Identity Module
LAN	Local Area Network
LLC	Logical Link Control
LTE	Long-Term Evolution
MAC	Medium Access Control
MBIM	Mobile Broadband Interface Model
MCC	Mobile Country Code
ME	Mobile Equipment
MNC	Mobile Network Code
MO	Mobile Original
MS	Mobile Station
MSC	Mobile Switching Center
MT	Mobile Terminal
MTU	Maximum Transmission Unit
NAS	Non-Access Stratum
NAT	Network Address Translation
NCGI	NR Cell Global Identification
NCI	NR Cell Identification
NG-RAN	Next-Generation Radio Access Network

NIC	Network Interface Controller
NITZ	Network Identity and Time Zone
NR	New Radio
NSAPI	Network Service Access Point Identifier
NSSAI	Network Slice Selection Assistance Information
NVM	Non-Volatile Memory
OIR	Originating Identification Restriction
PAD	Packet Assembler/Disassembler
PCIe	Peripheral Component Interconnect Express
PCIe EP	PCI Express Endpoint Device
PCIe RC	PCI Express Root Complex
PCO	Protocol Configuration Options
PDN	Public Data Network
PDP	Packet Data Protocol
PDU	Protocol Data Unit
PIN	Personal Identification Number
PLMN	Public Land Mobile Network
PRX	Primary Receive
PS	Packet Switch
PSC	Primary Synchronization Code
PUK	PIN Unlock Key
QoS	Quality of Service
RAN	Radio Access Network
RAT	Radio Access Technology
RF	Radio Frequency

RFC	Request for Comments
RI	Ring Indicator
RmNET	Remote Network
RNDIS	Remote Network Driver Interface Specification
RP	Relay Protocol
RRC	Radio Resource Control
RSRP	Reference Signal Received Power
RSRQ	Reference Signal Received Quality
RSSI	Received Signal Strength Indicator
SA	Standalone
SD	Slice Differentiator
SFE	Shortcut Forwarding Engine
SINR	Signal to Interference plus Noise Ratio
SMS	Short Messaging Service
SMSC	Short Message Service Center
SNDCP	Sub Network Dependence Convergence Protocol
S-NSSAI	Single Network Slice Selection Assistance Information
SSC	Session and Service Continuity
SST	Slice/Service Type
TA	Terminal Adapter
TAC	Tracking Area Code
TDD	Time Division Duplex
TE	Terminal Equipment
TFT	Traffic Flow Template
UART	Universal Asynchronous Receiver/Transmitter

UCS2	Universal Character Set (UCS-2) Format
UE	User Equipment
UICC	Universal Integrated Circuit Card
UIM	User Identity Model
UL	Uplink
UMTS	Universal Mobile Telecommunications System
URC	Unsolicited Result Code
USB	Universal Serial Bus
USSD	Unstructured Supplementary Service Data
(U)SIM	(Universal) Subscriber Identity Module
UTRAN	Universal Terrestrial Radio Access Network UMTS Terrestrial Radio Access Network
VLAN	Virtual Local Area Network
VLR	Visitor Location Register
WAN	Wide Area Network
WIM	Wireless Identity Module
WLAN	Wireless Local Area Network

13.2 Factory Default Settings Restorable with AT&F

Table 4: Factory Default Settings Restorable with AT&F

AT Command	Parameters	Factory Defaults
ATE	**<value>**	1
ATQ	**<n>**	0
ATS0	**<n>**	0
ATS3	**<n>**	13

ATS4	**<n>**	10
ATS5	**<n>**	8
ATS6	**<n>**	2
ATS7	**<n>**	0
ATS8	**<n>**	2
ATS10	**<n>**	15
ATV	**<value>**	1
ATX	**<value>**	4
AT+CMEE	**<n>**	1
AT+CSCS	**<chset>**	"GSM"
AT+CSMS	**<service>,<mt>,<mo>,<bm>**	0,1,1,1
AT+CMGF	**<mode>**	0
AT+CSMP	**<fo>,<vp>,<pid>,<dcs>**	17,167,0,0
AT+CSDH	**<show>**	0
AT+CSCB	**<mode>,<mids>,<dcss>**	0,"",""
AT+CPMS	**<mem1>,<mem2>,<mem3>**	"ME","ME","ME"
AT+CNMI	**<mode>,<mt>,<bm>,<ds>,<bfr>**	2,1,0,0,0
AT+CMMS	**<n>**	0
AT+CGEREP	**<mode>,<brf>**	0,0
AT+CEREG	**<n>**	0

13.3 AT Command Settings Storable with AT&W

Table 5: AT Command Settings Storable with AT&W

AT Command	Parameters	Display with AT&V
ATE	**<value>**	Yes
ATQ	**<n>**	Yes
ATS0	**<n>**	Yes
ATS7	**<n>**	Yes
ATS10	**<n>**	Yes
ATV	**<value>**	Yes
ATX	**<value>**	Yes
AT+CEREG	**<n>**	No
AT+C5GREG	**<n>**	No
AT+IPR	**<value>**	No

13.4 AT Command Settings Storable with ATZ

Table 6: AT Command Settings Storable with ATZ

AT Command	Parameters	Factory Defaults
ATE	**<value>**	1
ATQ	**<n>**	0
ATS0	**<n>**	0
ATS7	**<n>**	0
ATS10	**<n>**	15

ATV	**<value>**	1
ATX	**<value>**	4
AT+CEREG	**<n>**	0
AT+C5GREG	**<n>**	0

13.5 Summary of CME ERROR Codes

Final result code **+CME ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. If **+CME ERROR: <err>** is the result code for any of the commands in a command line, none of the following commands in the same command line is executed (neither **ERROR** nor **OK** result code should be returned as a result of a completed command line execution).

<err> values are mostly used by common message commands. The following table lists most of general and GRPS related **ERROR** codes. For some GSM protocol failure cause described in GSM specifications, the corresponding **ERROR** codes are not included.

Table 7: Different Coding Schemes of +CME ERROR: <err>

Code of <err>	Meaning
0	Phone failure
1	No connection to phone
2	Phone-adaptor link reserved
3	Operation not allowed
4	Operation not supported
5	PH-SIM PIN required
6	PH-FSIM PIN required
7	PH-FSIM PUK required
10	(U)SIM not inserted
11	(U)SIM PIN required

12	(U)SIM PUK required
13	(U)SIM failure
14	(U)SIM busy
15	(U)SIM wrong
16	Incorrect password
17	(U)SIM PIN2 required
18	(U)SIM PUK2 required
20	Memory full
21	Invalid index
22	Not found
23	Memory failure
24	Text string too long
25	Invalid characters in text string
26	Dial string too long
27	Invalid characters in dial string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
40	Network personalization PIN required
41	Network personalization PUK required
42	Network subset personalization PIN required
43	Network subset personalization PUK required
44	Service provider personalization PIN required
45	Service provider personalization PUK required
46	Corporate personalization PIN required

47	Corporate personalization PUK required
901	Audio unknown error
902	Audio invalid parameters
903	Audio operation is not supported
904	Audio device is busy

13.6 Summary of CMS ERROR Codes

Final result code **+CMS ERROR: <err>** indicates an error related to mobile equipment or network. The operation is similar to **ERROR** result code. None of the following commands in the same command line is executed. Neither **ERROR** nor **OK** result code should be returned.

<err> values are mostly used by common message commands:

Table 8: Different Coding Schemes of +CMS ERROR: <err>

Code of <err>	Meaning
300	ME failure
301	SMS ME reserved
302	Operation not allowed
303	Operation not supported
304	Invalid PDU mode
305	Invalid text mode
310	(U)SIM not inserted
311	(U)SIM pin necessary
312	PH (U)SIM pin necessary
313	(U)SIM failure
314	(U)SIM busy
315	(U)SIM wrong

316	(U)SIM PUK required
317	(U)SIM PIN2 required
318	(U)SIM PUK2 required
320	Memory failure
321	Invalid memory index
322	Memory full
330	SMSC address unknown
331	No network
332	Network timeout
340	Not expected
500	Unknown
512	(U)SIM not ready
513	Message length exceeds
514	Invalid request parameters
515	ME storage failure
517	Invalid service mode
528	More message to send state error
529	MO SMS is not allowed
531	ME storage full

13.7 Summary of URCs

Table 9: Summary of URCs

Index	URC Display	Meaning	Condition
1	**+QUSIM: 1**	(U)SIM card initialization status.	-
2	**+QSIMSTAT: <enable>,<inserted_status>**	(U)SIM card insertion status.	**AT+QSIMSTAT=1**
3	**+CTZV: <tz>**	Time zone reporting.	**AT+CTZR=1**
4	**+CTZE: <tz>,<dst>,[<time>]**	Extended time zone reporting.	**AT+CTZR=2**
5	**+CEREG: <stat>**	EPS network registration status change in E-UTRAN.	**AT+CEREG=1**
6	**+CEREG: <stat>[,<lac>,<ci>[,<AcT>]]**	Network cell change in E-UTRAN.	**AT+CEREG=2**
7	**+C5GREG: <stat>**	Network registration status change in 5GS.	**AT+C5GREG=1**
8	**+C5GREG: <stat>[,[<tac>],[<ci>],[<AcT>],[<Allowed_NSSAI_length>],[<Allowed_NSSAI>]]**	Network cell change in 5GS or whether there is a network provided an allowed NSSAI.	**AT+C5GREG=2**
9	**+CMTI: <mem>,<index>**	New message is received and saved to memory.	See **AT+CNMI**
10	**+CMT: [<alpha>],<length><CR><LF><pdu>**	New message is received and output directly to TE (PDU mode).	See **AT+CNMI**
11	**+CMT: <oa>,[<alpha>],<scts>[,<tooa>,<fo>,<pid>,<dcs>,<sca>,<tosca>,<length>]<CR><LF><data>**	New short message is received and output directly to TE (Text mode).	See **AT+CNMI**
12	**+CBM: <length><CR><LF><pdu>**	New CBM is received and output directly (PDU mode)	See **AT+CNMI**
13	**+CBM: <sn>,<mid>,<dcs>,<page>,<pages><CR><LF><data>**	New CBM is received and output directly to TE (Text mode).	See **AT+CNMI**
14	**+CDS: <length><CR><LF><pdu>**	New CDS is received and output directly to TE (PDU mode).	See **AT+CNMI**
15	**+CDS: <fo>,<mr>,[<ra>],[<tora>],<scts>,<dt>,<st>**	New CDS is received and output directly to TE (Text mode).	See **AT+CNMI**

16	**+CDSI: <mem>,<index>**	New message status report is received and saved to memory.	See **AT+CNMI**
17	**+COLP: <number>,<type>,[<subaddr>],[<satype>],[<alpha>]**	COL (connected line) presentation at TE for a mobile originated call.	**AT+COLP=1**
18	**+CLIP: <number>,<type>,[subaddr],[satype],[<alpha>],<CLI_validity>**	Mobile terminating call indication.	**AT+CLIP=1**
19	**+CRING: <type>**	An incoming call is indicated to the TE with URC instead of normal **RING**.	**AT+CRC=1**
20	**+CCWA: <number>,<type>,<class>[,<alpha>][,<CLI_validity>[,<subaddr>,<satype>[,<priority>]]]**	Call waiting indication.	**AT+CCWA=1,1**
21	**+CSSI: <code1>**	**+CSSI** intermediate result code presentation status to TE.	**AT+CSSN=1**
22	**+CSSU: <code2>**	**+CSSU** URC presentation status to TE.	**AT+CSSN=<n>,1**
23	**RDY**	MT initialization is successful.	-
24	**+CFUN: 1**	All MT functions are available.	-
25	**+CPIN: <state>**	(U)SIM card pin state.	-
26	**+QIND: SMS DONE**	SMS initialization finished.	-
27	**+QIND: PB DONE**	Phonebook initialization finished.	-
28	**+CPIN: NOT READY**	(U)SIM card is not ready.	-
29	**POWERED DOWN**	Module power down.	**AT+QPOWD**
30	**+CGEV: REJECT <PDP_type>,<PDP_addr>**	A network request for PDP activation, and automatically rejected.	**AT+CGEREP=2,1**
31	**+CGEV: NW REACT <PDP_type>,<PDP_addr>,[<cid>]**	Network request PDP reactivation.	**AT+CGEREP=2,1**
32	**+CGEV: NW DEACT <PDP_type>,<PDP_addr>,[<cid>]**	Network-forced context deactivation.	**AT+CGEREP=2,1**
33	**+CGEV: ME DEACT <PDP_type>,<PDP_addr>,[<cid>]**	ME-forced context deactivation.	**AT+CGEREP=2,1**
34	**+CGEV: NW DETACH**	Network-forced packet domain detach.	**AT+CGEREP=2,1**
35	**+CGEV: ME DETACH**	Mobile equipment-forced packet domain detach.	**AT+CGEREP=2,1**

36	**+CGEV: NW CLASS <class>**	Network-forced change of MS class.	**AT+CGEREP=2,1**
37	**+CGEV: ME CLASS <class>**	Mobile equipment-forced change of MS class.	**AT+CGEREP=2,1**
38	**+CGEV: PDN ACT<cid>**	Context activated.	**AT+CGEREP=2,1**
39	**+CGEV: PDN DEACT<cid>**	Context deactivated.	**AT+CGEREP=2,1**
40	**^DSCI: <id>,<dir>,<stat>,<type>,<number>,<num_type>**	Call status indication.	**AT^DSCI=1**
41	**+CUSD: <status>[,<rspstr>,[<dcs>]]**	USSD response from network, or a network-initiated operation.	**AT+CUSD=1**

13.8 SMS Character Sets Conversions

In *3GPP TS 23.038* Data Coding Scheme (DCS), 3GPP defines three kinds of alphabets in SMS: GSM 7-bit default, 8-bit data, and UCS2 (16-bit) alphabets. **AT+CSMP** can set the DCS in text mode (**AT+CMGF=1**). In text mode, DCS (Data Coding Scheme) and **AT+CSCS** determine the way of SMS text input or output.

Table 10: SMS Text Input or Output Methods

DCS	AT+CSCS	The Way of SMS Text Input or Output
GSM 7-bit	GSM	Input or output GSM character sets.
GSM 7-bit	IRA	Input or output IRA character sets. Input: UE will convert IRA characters to GSM characters. Output: UE will convert GSM characters to IRA characters.
GSM 7-bit	UCS2	Input or output a hex string similar to PDU mode. Only characters 0–9 and A–F supported. Input: UE will convert the UCS2 hex string to GSM characters. Output: UE will convert the GSM characters to UCS2 hex string.
UCS2	-	Ignore the value of **AT+CSCS**, input or output a hex string similar to PDU mode. Only characters 0–9 and A–F supported.
8-bit	-	Ignore the value of **AT+CSCS**, input or output a hex string similar to PDU mode. Only characters 0–9 and A–F supported.

When DCS = GSM 7-bit, the input or output needs conversion. The detailed conversion tables are shown as follows.

Table 11: Input Conversions Table (DCS=GSM 7-bit and AT+CSCS="GSM")

No.	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71
2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73
4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	0B	Cancel	2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

Table 12: Output Conversions Table (DCS=GSM 7-bit and AT+CSCS="GSM")

No.	0	1	2	3	4	5	6	7
0	00	10	20	30	40	50	60	70
1	01	11	21	31	41	51	61	71
2	02	12	22	32	42	52	62	72
3	03	13	23	33	43	53	63	73

4	04	14	24	34	44	54	64	74
5	05	15	25	35	45	55	65	75
6	06	16	26	36	46	56	66	76
7	07	17	27	37	47	57	67	77
8	08	18	28	38	48	58	68	78
9	09	19	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	0B		2B	3B	4B	5B	6B	7B
C	0C	1C	2C	3C	4C	5C	6C	7C
D	0D	1A	2D	3D	4D	5D	6D	7D
E	0E	1E	2E	3E	4E	5E	6E	7E
F	0F	1F	2F	3F	4F	5F	6F	7F

Table 13: GSM Extended Characters (GSM Encode)

No.	0	1	2	3	4	5	6	7
0					1B40			
1								
2								
3								
4		1B14						
5								
6								
7								
8			1B28					
9			1B29					

A			
B			
C		1B3C	
D		1B3D	
E		1B3E	
F	1B2F		

Table 14: Input Conversions Table (DCS = GSM 7-bit and AT+CSCS="IRA")

No.	0	1	2	3	4	5	6	7
0		20	20	30	00	50	20	70
1	20	20	21	31	41	51	61	71
2	20	20	22	32	42	52	62	72
3	20	20	23	33	43	53	63	73
4	20	20	02	34	44	54	64	74
5	20	20	25	35	45	55	65	75
6	20	20	26	36	46	56	66	76
7	20	20	27	37	47	57	67	77
8	backspace	20	28	38	48	58	68	78
9	20	20	29	39	49	59	69	79
A	0A	Submit	2A	3A	4A	5A	6A	7A
B	20	Cancel	2B	3B	4B	1B3C	6B	1B28
C	20	20	2C	3C	4C	1B2F	6C	1B40
D	0D	20	2D	3D	4D	1B3E	6D	1B29
E	20	20	2E	3E	4E	1B14	6E	1B3D
F	20	20	2F	3F	4F	11	6F	20

Table 15: IRA Extended Characters

No.	A	B	C	D	E	F
0	20	20	20	20	7F	20
1	40	20	20	5D	20	7D
2	20	20	20	20	20	08
3	01	20	20	20	20	20
4	24	20	5B	20	7B	20
5	03	20	0E	20	0F	20
6	20	20	1C	5C	1D	7C
7	5F	20	09	20	20	20
8	20	20	20	0B	04	0C
9	20	20	1F	20	05	06
A	20	20	20	20	20	20
B	20	20	20	20	20	20
C	20	20	20	5E	07	7E
D	20	20	20	20	20	20
E	20	20	20	20	20	20
F	20	60	20	1E	20	20

Table 16: Output Conversions Table (DCS = GSM 7-bit and AT+CSCS="IRA")

No.	0	1	2	3	4	5	6	7
0	40	20	20	30	A1	50	BF	70
1	A3	5F	21	31	41	51	61	71
2	24	20	22	32	42	52	62	72
3	A5	20	23	33	43	53	63	73

4	E8	20	A4	34	44	54	64	74
5	E9	20	25	35	45	55	65	75
6	F9	20	26	36	46	56	66	76
7	EC	20	27	37	47	57	67	77
8	F2	20	28	38	48	58	68	78
9	C7	20	29	39	49	59	69	79
A	0D0A		2A	3A	4A	5A	6A	7A
B	D8		2B	3B	4B	C4	6B	E4
C	F8	C6	2C	3C	4C	D6	6C	F6
D	0D	E6	2D	3D	4D	D1	6D	F1
E	C5	DF	2E	3E	4E	DC	6E	FC
F	E5	C9	2F	3F	4F	A7	6F	E0

Table 17: GSM Extended Characters (ISO-8859-1/Unicode)

No.	0	1	2	3	4	5	6	7
0					7C			
1								
2								
3								
4		5E						
5								
6								
7								
8			7B					
9			7D					

A		
B		
C	5B	
D	7E	
E	5D	
F	5C	

Because the low 8-bit of UCS2 character is the same as the IRA character:

- The conversion table of DCS = GSM 7-bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt = GSM 7-bit and **AT+CSCS="GSM"** is similar to **AT+CSCS="GSM"**.
- The conversion table of fmt = GSM 7-bit and **AT+CSCS="IRA"** is similar to **AT+CSCS="IRA"**.
- The conversion table of fmt = GSM 7-bit and **AT+CSCS="UCS2"** is similar to **AT+CSCS="IRA"**.

The difference is the way of SMS text input or output. See ***Table 10*** for more details.