

# BG95-S5

# QuecCell Application Note

**Satellite Communication Module Series**

Version: 1.0

Date: 2024-11-01

Status: Released



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local offices. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>.

Or email us at: [support@quectel.com](mailto:support@quectel.com).

## Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

## Use and Disclosure Restrictions

### License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

### Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

## Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

## Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties ("third-party materials"). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

## Privacy Policy

To implement module functionality, certain device data are uploaded to Quectel's or third-party's servers, including carriers, chipset suppliers or customer-designated servers. Quectel, strictly abiding by the relevant laws and regulations, shall retain, use, disclose or otherwise process relevant data for the purpose of performing the service only or as permitted by applicable laws. Before data interaction with third parties, please be informed of their privacy and data security policy.

## Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2024. All rights reserved.**

# About the Document

## Revision History

Version	Date	Author	Description
-	2024-08-26	Water WANG	Creation of the document
1.0	2024-11-01	Water WANG	First official release

## Contents

About the Document.....	3
Contents .....	4
Table Index.....	5
<b>1 Introduction .....</b>	<b>6</b>
<b>2 Description of AT Commands .....</b>	<b>7</b>
2.1. AT Command Introduction .....	7
2.1.1. Definitions.....	7
2.1.2. AT Command Syntax .....	7
2.2. Declaration of AT Command Examples .....	8
2.3. AT+QENG Query Serving Cell and Neighbour Cell Information.....	8
2.4. AT+QCELLSCAN Scan Cell Information .....	13
<b>3 Appendix References .....</b>	<b>17</b>

Table Index

Table 1: Types of AT Commands ..... 7

Table 2: Terms and Abbreviations ..... 17

# 1 Introduction

This document presents the description of cell scanning command for Quectel BG95-S5 module.

# 2 Description of AT Commands

## 2.1. AT Command Introduction

### 2.1.1. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on the command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

### 2.1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

Table 1: Types of AT Commands

Command Type	Syntax	Description
Test Command	<b>AT+&lt;cmd&gt;=?</b>	Test the existence of the corresponding command and return information about the type, value, or range of its parameter.
Read Command	<b>AT+&lt;cmd&gt;?</b>	Check the current parameter value of the corresponding command.
Write Command	<b>AT+&lt;cmd&gt;=&lt;p1&gt;[,&lt;p2&gt;[,&lt;p3&gt;[...]]]</b>	Set user-definable parameter value.
Execution Command	<b>AT+&lt;cmd&gt;</b>	Return a specific information parameter or perform a specific action.



## 2.2. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about the use of the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendations or suggestions about how to design a program flow or what status to set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there is a correlation among these examples, or that they should be executed in a given sequence. The URLs, domain names, IP addresses, usernames/accounts, and passwords (if any) in the AT command examples are provided for illustrative and explanatory purposes only, and they should be modified to reflect your actual usage and specific needs.

## 2.3. AT+QENG Query Serving Cell and Neighbour Cell Information

The command queries serving cell and neighbour cell information.

AT+QENG Query Serving Cell and Neighbour Cell Information	
Test Command <b>AT+QENG=?</b>	Response <b>+QENG:</b> (list of supported <cell_type>s)  <b>OK</b>
Write Command Query the information of serving cell <b>AT+QENG="servingcell"</b>	Response In the case of GSM mode: <b>+QENG: "servingcell",&lt;state&gt;[,&lt;RAT&gt;,&lt;MCC&gt;,&lt;MNC&gt;,&lt;LAC&gt;,&lt;cellID&gt;,&lt;bsic&gt;,&lt;ARFCN&gt;,&lt;band&gt;,&lt;RxLev&gt;,&lt;txp&gt;,&lt;rla&gt;,&lt;DRX&gt;,&lt;c1&gt;,&lt;c2&gt;,&lt;GPRS&gt;,&lt;tch&gt;,&lt;ts&gt;,&lt;ta&gt;,&lt;MAIO&gt;,&lt;HSN&gt;,&lt;rxlevsub&gt;,&lt;rxlevfull&gt;,&lt;rxqualsub&gt;,&lt;rxqualfull&gt;,&lt;voicecodec&gt;]</b>  <b>OK</b>  In the case of LTE Cat M1/Cat NB2/IoT-NTN mode: <b>+QENG: "servingcell",&lt;state&gt;[,&lt;RAT&gt;,&lt;is_tdd&gt;,&lt;MCC&gt;,&lt;MNC&gt;,&lt;cellID&gt;,&lt;PCI&gt;,&lt;EARFCN&gt;,&lt;freq_band_ind&gt;,&lt;UL_bandwidth&gt;,&lt;DL_bandwidth&gt;,&lt;TAC&gt;,&lt;RSRP&gt;,&lt;RSRQ&gt;,&lt;RSSI&gt;,&lt;SINR&gt;,&lt;srxlev&gt;]</b>  <b>OK</b>
Write Command Query the information of neighbour cells: <b>AT+QENG="neighbourcell"</b>	Response In the case of GSM mode: <b>[+QENG: "neighbourcell",&lt;RAT&gt;,&lt;MCC&gt;,&lt;MNC&gt;,&lt;LAC&gt;,&lt;cellID&gt;,&lt;bsic&gt;,&lt;ARFCN&gt;,&lt;RxLev&gt;,&lt;c1&gt;,&lt;c2&gt;,&lt;c31&gt;,&lt;c3</b>

	2> [...]]  OK  In the case of LTE Cat M1/Cat NB2/IoT-NTN mode: [+QENG: "neighbourcell intra",<RAT>,<EARFCN>,<PCI>,<RSRQ>,<RSRP>,<RSSI>,<SINR>,<srxlev>,<cell_resel_priority>,<s_non_intra_search>,<thresh_serving_low>,<s_intra_search> [...]]  OK
Maximum Response Time	300 ms
Characteristics	-

## Parameter

<cell_type>	String type. Type of the cell, of which the information can be queried. "servingcell"      Serving cell "neighbourcell"    Neighbour cell
<state>	String type. UE state. "SEARCH"            UE is searching but could not (yet) find a suitable cell "LIMSRV"            UE is camping on a cell but has not registered on the network "NOCONN"            UE has camped on a cell and registered on the network, but it is in the idle mode "CONNECT"           UE has camped on a cell and registered on the network, and a call is in progress
<RAT>	String type. Radio access technologies. "GSM"                GSM "eMTC"                LTE Cat M1 "NB IoT"              LTE Cat NB2 "NTN NB IoT"        LTE Cat IoT-NTN
<MCC>	Integer type. A three-digit value indicating mobile country code (the first part of the PLMN code).
<MNC>	Integer type. A two-digit value indicating the mobile network code (the second part of the PLMN code).
<LAC>	Two-byte location area code in hexadecimal format (e.g., 00C1 equals 193 in decimal) of the cell that was scanned. Range: 0–0xFFFF.
<cellID>	Hexadecimal format. 16-bit (GSM) or 28-bit (LTE) cell ID. Range: 0–0xFFFFFFFF.
<bsic>	Integer type. Base station identification code. Range: 0–63.
<ARFCN>	Integer type. ARFCN of the cell that was scanned. Range: 0–1023.

<band>	Integer type. The current GSM band. 0 DCS1800 1 PCS1900 2 EGSM900 3 GSM850
<RxLev>	Integer type. The Rx level value for base station selection that is mapped from the measured signal level (see <i>3GPP 45.008</i> ). Range: 0–63. A dBm value will be got by subtracting 111 from the Rx level value.
<txp>	Integer type. The maximum Tx power level an MS may use when accessing the system. Range: 0–31.
<rla>	Integer type. The minimum received signal level at the MS required for access to the system. Range: 0–63.
<DRX>	Integer type. Discontinuous reception cycle. Unit: second.
<c1>	Integer type. Path loss criterion used for cell selection and reselection.
<c2>	Integer type. Cell reselection criterion.
<GPRS>	Integer type. Whether the current cell supports GPRS. 0 Not support 1 Support
<tch>	String or integer type. Displays 'h' in hopping; Displays the current ARFCN in voice call.
<ts>	Integer type. Timeslot number in voice call. Range: 0–7.
<ta>	Integer type. Timing advance in voice call. Range: 0–63.
<MAIO>	Integer type. Mobile allocation index offset in voice call. Range: 0–63.
<HSN>	Integer type. Hopping sequence number in voice call. Range: 0–63.
<rxqualsub>	Integer type. Rx quality (sub) in voice call. Range: 0–7.
<rxqualfull>	Integer type. Rx quality (full) in voice call. Range: 0–7.
<rxlevsub>	Integer type. Rx level (sub) in voice call. Range: 0–63.
<rxlevfull>	Integer type. Rx level (full) in voice call. Range: 0–63.
<voicecodec>	String format. Speech coding modes during a voice call. "HR" Half rate "FR" Full rate "EFR" Enhanced full rate "AMR" Adaptive multi-rate "AMRHR" AMR half rate "AMRFR" AMR full rate "AMRWB" AMR wide band
<is_tdd>	String type. LTE network mode. "FDD" LTE-FDD
<PCI>	Integer type. Physical cell identity.
<EARFCN>	Integer type. E-UTRA absolute radio frequency channel number.
<freq_band_ind>	Integer type. E-UTRA frequency bands (see <i>3GPP 36.101</i> ).
<UL_bandwidth>	Integer type. UL bandwidth. 0 1.4 MHz 1 3 MHz

	2	5 MHz
	3	10 MHz
	4	15 MHz
	5	20 MHz
<DL_bandwidth>	Integer type. DL bandwidth.	
	0	1.4 MHz
	1	3 MHz
	2	5 MHz
	3	10 MHz
	4	15 MHz
	5	20 MHz
<TAC>	Tracking area code in hexadecimal format (see 3GPP 23.003 subclause 19.4.2.3).	
<RSRP>	Reference signal received power (see 3GPP 36.214 subclause 5.1.1). Unit: dBm.	
<RSRQ>	Reference signal received quality (see 3GPP 36.214 subclause 5.1.3). Unit: dB.	
<RSSI>	Integer type. The received signal strength indication. Unit: dBm.	
<SINR>	Integer type. A converted value of SINR. The actual SINR = (1/5) × <SINR> - 20. Range: 0–250 (that is, the actual SINR ranges between -20 dB and 30 dB).	
<srxlev>	Integer type. Cell selection Rx level value (in dB) (see 3GPP 36.304).	
<c31>	Integer type. The signal level threshold criterion for hierarchical cell structures (HCS). The parameter is used to determine whether prioritised hierarchical GPRS and LSA cell re-selection shall apply.	
<c32>	Integer type. The cell ranking criterion which is used to select cells among those with the same priority.	
<cell_resel_priority>	Integer type. Cell reselection priority. Range: 0–7.	
<s_non_intra_search>	Integer type. Threshold to control non-intra frequency searches.	
<thresh_serving_low>	Integer type. The threshold of <srxlev> (in dB) used by the UE on the serving cell when reselecting towards a lower priority RAT/ frequency.	
<s_intra_search>	Integer type. Threshold to control intra-frequency searches.	

## Example

```
AT+QENG="servingcell"
```

```
+QENG: "servingcell","SEARCH"
```

```
OK
```

```
//If the module registers on GSM network.
```

```
AT+QENG="servingcell"
```

```
+QENG: "servingcell","NOCONN","GSM",460,00,550B,D89,35,59,2,-48,255,255,0,55,165,1,,,,,,,,,
```

```
OK
```

```
//If the module registers on NB-IoT network.
```

```
AT+QENG="servingcell"
```

```
+QENG: "servingcell","NOCONN","NBloT","FDD",460,11,DDA1451,280,2506,5,0,0,69C9,-84,-17,-67,8,44
```

OK

//If the module registers on eMTC network.

```
AT+QENG="servingcell"
```

```
+QENG: "servingcell","NOCONN","eMTC","FDD",460,11,690843E,314,1850,3,5,5,691D,-105,-14,-77,11,22
```

OK

//If the module registers on IoT-NTN network.

```
AT+QENG="servingcell"
```

```
+QENG: "servingcell","NOCONN","NTN NBloT","FDD",460,80,1A2D101,37,7500,23,0,0,2,-114,-10,-104,11,26
```

OK

//If the module registers on GSM network.

```
AT+QENG="neighbourcell"
```

```
+QENG: "neighbourcell","GSM",460,00,550B,D8A,41,63,-72,31,141,0,0
```

```
+QENG: "neighbourcell","GSM",460,00,550B,D58,58,57,-65,38,148,0,0
```

```
+QENG: "neighbourcell","GSM",460,00,550B,6395,11,64,-66,37,147,0,0
```

```
+QENG: "neighbourcell","GSM",460,00,550B,3C94,43,62,-70,33,143,0,0
```

OK

//If the module registers on NB-IoT network.

```
AT+QENG="neighbourcell"
```

```
+QENG: "neighbourcell intra","NBloT",2506,224,-12,-81,-68,0,59,0,50,0,50
```

```
+QENG: "neighbourcell intra","NBloT",2506,280,-14,-81,-67,0,47,0,50,0,50
```

```
+QENG: "neighbourcell intra","NBloT",2506,281,-15,-81,-66,0,58,0,50,0,50
```

OK

//If the module registers on eMTC network.

```
AT+QENG="neighbourcell"
```

```
+QENG: "neighbourcell intra","eMTC",1850,314,-15,-107,-78,0,21,7,20,10,58
```

```
+QENG: "neighbourcell intra","eMTC",1850,312,-16,-106,-81,0,21,7,20,10,58
```

```
+QENG: "neighbourcell intra","eMTC",1850,319,-20,-112,-83,0,15,7,20,10,58
```

OK

//If the module registers on IoT-NTN network.

**AT+QENG="neighbourcell"**

**+QENG: "neighbourcell intra", "NTN NBIoT", 7500, 37, -10, -114, -104, 0, 26, 0, 0, 0, 0**

**OK**

## 2.4. AT+QCELLSCAN Scan Cell Information

The command returns the information of all cells existing in the coverage area of the network that the module registers on.

### AT+QCELLSCAN Scan Cell Information

Test Command  
**AT+QCELLSCAN=?**

Response

**+QCELLSCAN: (list of supported <RAT>s), (list of supported <timeout>)**

**OK**

Write Command  
**AT+QCELLSCAN=<RAT>[,<timeout>]**

Response

If <RAT>=1 (in the GSM network):

**OK**

**+QCELLSCAN: <cell\_num>**

**+QCELLSCAN: "GSM", <MCC>, <MNC>, <LAC>, <cellID>, <bsic>, <RxLev>**

[...]

If <RAT>=8 (in the eMTC network):

**OK**

**+QCELLSCAN: <cell\_num>**

**+QCELLSCAN: "eMTC", <MCC>, <MNC>, <TAC>, <EARFCN>, <PCI>, <cellID>, <RSRP>, <RSRQ>, <RSSI>**

[...]

If <RAT>=9 (in the NB-IoT network):

**OK**

**+QCELLSCAN: <cell\_num>**

	<p><b>+QCELLSCAN: "NBloT",&lt;MCC&gt;,&lt;MNC&gt;,&lt;TAC&gt;,&lt;EARFCN&gt;,&lt;PCI&gt;,&lt;cellID&gt;,&lt;RSRP&gt;,&lt;RSRQ&gt;,&lt;RSSI&gt;</b></p> <p>[...]</p> <p>If &lt;RAT&gt;=14 (in the IoT-NTN network):</p> <p><b>OK</b></p> <p><b>+QCELLSCAN: &lt;cell_num&gt;</b></p> <p><b>+QCELLSCAN: "NTN NBloT",&lt;MCC&gt;,&lt;MNC&gt;,&lt;TAC&gt;,&lt;EARFCN&gt;,&lt;PCI&gt;,&lt;cellID&gt;,&lt;RSRP&gt;,&lt;RSRQ&gt;,&lt;RSSI&gt;</b></p> <p>[...]</p> <p>If there is a timeout error or any other error:</p> <p><b>+QCELLSCAN: &lt;err&gt;</b></p> <p>Or</p> <p><b>ERROR</b></p>
Maximum Response Time	Depending on the network environment.
Characteristics	<p>The command takes effect immediately.</p> <p>The configuration is not saved.</p>

## Parameter

<b>&lt;RAT&gt;</b>	Integer type. The access technology of the serving cell.
1	GSM
8	eMTC
9	NB-IoT
14	IoT-NTN
<b>&lt;timeout&gt;</b>	Integer type. The timeout value for the cell-scanning. Range: 5–65535. Default value: 120. Unit: second.
<b>&lt;cell_num&gt;</b>	Integer type. Number of cells scanned.
<b>&lt;MCC&gt;</b>	Integer type. A three-digit value indicating mobile country code.
<b>&lt;MNC&gt;</b>	Integer type. A two-digit value indicating the mobile network code.
<b>&lt;LAC&gt;</b>	Two-byte location area code in hexadecimal format (e.g., 00C1 equals 193 in decimal) of the cell that was scanned. Range: 0–0xFFFF.
<b>&lt;cellID&gt;</b>	Hexadecimal format. 16-bit (GSM) or 28-bit (LTE) cell ID. Range: 0–0xFFFFFFFF.
<b>&lt;bsic&gt;</b>	Integer type. Base station identification code. Range: 0–63.
<b>&lt;RxLev&gt;</b>	Integer type. The Rx level value for base station selection that is mapped from the measured signal level (see 3GPP 45.008). Range: 0–63. A dBm value will be got by subtracting 111 from the Rx level value.

<TAC>	Tracking area code in hexadecimal format. (see 3GPP 23.003 subclause 19.4.2.3).
<EARFCN>	Integer type. E-UTRA absolute radio frequency channel number.
<PCI>	Integer type. Physical cell identity.
<RSRP>	Reference signal received power (see 3GPP 36.214 subclause 5.1.1). Unit: dBm.
<RSRQ>	Reference signal received quality (see 3GPP 36.214 subclause 5.1.3). Unit: dB.
<RSSI>	Integer type. The received signal strength indication. Unit: dBm.
<err>	Integer type. Error code.
-1	Cell scanning failure

#### NOTE

When <timeout> is reached, cell scanning will be aborted but the response cannot be returned immediately unless no cell has been scanned before.

### Example

//If the module registers on GSM network.

**AT+QCELLSCAN=1**

OK

+QCELLSCAN: 3

+QCELLSCAN: "GSM",460,00,550B,34B8,63,58

+QCELLSCAN: "GSM",460,00,550B,D89,34,44

+QCELLSCAN: "GSM",460,00,550B,3C94,26,38

//If the module registers on eMTC network.

**AT+QCELLSCAN=8**

OK

+QCELLSCAN: 2

+QCELLSCAN: "eMTC",460,11,1,73A,314,690843E,-103,-12,-77

+QCELLSCAN: "eMTC",460,11,691D,1850,312,6908430,-108,-17,-77

//If the module registers on NB-IoT network.

**AT+QCELLSCAN=9**

OK

+QCELLSCAN: 2



+QCELLSCAN: "NBloT",460,00,2,E9A,471,84958B2,-73,-11,-62

+QCELLSCAN: "NBloT",460,00,4C10,3736,121,5C4EF33,-85,-10,-75

//If the module registers on IoT-NTN network.

**AT+QCELLSCAN=14**

OK

+QCELLSCAN: 1

+QCELLSCAN: "NTN NBloT",460,80,2,7500,37,1A2D101,-100,-10,-89

# 3 Appendix References

**Table 2: Terms and Abbreviations**

Abbreviation	Description
3GPP	3rd Generation Partnership Project
ARFCN	Absolute Radio Frequency Channel Number
DCS	Digital Cellular System
DL	Downlink
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
EGPRS	Enhanced General Packet Radio Service
eMTC	enhanced Machine-Type Communication
E-UTRA	Evolved Universal Terrestrial Radio Access
FDD	Frequency Division Duplex
GPRS	General Packet Radio Service
GSM	Global System for Mobile Communications
ID	Identifier
LTE	Long-Term Evolution
LSA	Local Service Area
MS	Mobile Station
NB-IoT	Narrowband Internet of Things
NTN	Non Terrestrial Network
PCS	Personal Communication Service
PLMN	Public Land Mobile Network

RAT	Radio Access Technology
Rx	Receive
SINR	Signal To Interference Plus Noise Ratio
TA	Terminal Adapter
TDD	Time Division Duplex
Tx	Transmit
UE	User Equipment
UL	Uplink
URC	Unsolicited Result Code
UTRA-ARFCN	UTRA Absolute Radio Frequency Channel Number